CASE

PROFESSIONAL PARTNER

PARTS CATALOG

LOADER BACKHOE

580M Series 2

7-9033 NA

Replaces 7-9032 NA

Revised 12-2005
Revised 05-2005
Revised 05-2004
Issued 02-2004

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

02-01	RADIATOR - MOUNTING
02-02	DEAERATION SYSTEM - MOUNTING
02-03	RADIATOR ASSY (WITH OR WITHOUT AIR CONDITIONING)
02-04	AIR CLEANER - AIR INTAKE PARTS (WITHOUT TURBOCHARGER)
02-04A	AIR CLEANER - AIR INTAKE PARTS (WITH TURBOCHARGER)
02-05	AIR CLEANER (WITHOUT TURBOCHARGER)
02-05A	AIR CLEANER (WITH TURBOCHARGER)
02-06	MUFFLER - EXHAUST SYSTEM (WITH TURBOCHARGER)
02-06A	MUFFLER, ASPIRATED & SPARK ARRESTOR - EXHAUST SYSTEM
02-06B	MUFFLER - EXHAUST SYSTEM (WITHOUT TURBOCHARGER)
02-07	ENGINE - MOUNTING
02-07A	ENGINE - BLOCK HEATER
02-08	ENGINE
02-09	CYLINDER BLOCK
02-10	CYLINDER BLOCK
02-11	OIL PUMP, PAN
02-12	CYLINDER BLOCK - COVERS
02-13	CYLINDER BLOCK - COVERS
02-14	CYLINDER BLOCK - COVERS
02-15	BREATHER - ENGINE
02-16	CYLINDER HEAD
02-17	CYLINDER HEAD - COVERS
02-18	CYLINDER HEAD - VALVE MECHANISM
02-19	MANIFOLD - INTAKE
02-20	MANIFOLD - EXHAUST
02-21	CRANKSHAFT
02-22	PISTONS - CONNECTING ROD
02-23	PISTONS - CONNECTING ROD
02-24	FLYWHEEL - ENGINE
02-25	PULLEY - CRANKSHAFT
02-26	DYNAMIC BALANCER, GEARS & SHAFTS
02-27	DYNAMIC BALANCER, GEARS & SHAFTS (2830952)
02-28	CAMSHAFT
02-29	TURBOCHARGER
02-30	ENGINE, OIL
02-31	OIL PUMP - ENGINE
02-32	OIL FILTERS - ENGINE
02-33	PIPING - ENGINE OIL
02-34	OIL FILTER AND COOLER
02-35	WATER PUMP
02-36	COOLING SYSTEM - ENGINE
02-37	THERMOSTAT - ENGINE COOLING SYSTEM
02-38	WATER PUMP - CONTROL
02-39	FAN DRIVE
02-40	POWER TAKE-OFF
02-41	ENGINE - LIFT HOOK
03-01	FUEL LINES, RESERVOIR
03-02	CONTROLS - THROTTLE, HAND
03-03	CONTROLS - THROTTLE, FOOT
03-04	FUEL INJECTION PUMP
03-05	FUEL INJECTION SYSTEM

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

03-06	FUEL INJECTION SYSTEM
03-07	FUEL INJECTION SYSTEM
03-08	FUEL FILTER
03-09	FUEL PUMP
03-10	FUEL INJECTION SYSTEM
03-11	FUEL INJECTION SYSTEM
04-01	STARTER
04-02	ALTERNATOR
04-03	STARTER MOUNTING - ALTERNATOR MOUNTING
04-04	HARNESS, ENGINE - MOUNTING AND CONNECTIONS
04-05	BATTERY CABLES (MODELS WITHOUT COLD START)
04-06	BATTERY, DUAL - COLD START
04-06A	COLD START GRID HEATER
04-07	HARNESS, FRONT CONSOLE - SWITCHES
04-08	HARNESS, FRONT CONSOLE - MOUNTING
04-09	HARNESS, SIDE CONSOLE - SWITCHES
04-10	INSTRUMENT PANEL, FRONT - COVERS
04-11	INSTRUMENT PANEL, SIDE - COVERS (RIGHT-HAND SIDE)
04-12	INSTRUMENT CLUSTER
04-13	ELECTRICAL - LAMPS, ROPS CANOPY
04-14	ELECTRICAL - LAMPS, ROPS CAB
04-15	LAMP ASSY (ROPS CANOPY MODELS)
04-16	HORN - ALARM, BACKUP
04-17	BEACON, ROTATING (CAB OR CANOPY MODELS)
04-18	ANTENNA, RADIO - HARNESS, RADIO
04-19	ELECTRICAL - BACKHOE AUXILIARY HYDRAULIC, UNI-DIRECTIONAL
04-20	ELECTRICAL - BACKHOE AUXILIARY HYDRAULIC, WITH PILOT CONTROLS
05-01	STEERING WHEEL - COLUMN
05-02	HYDRAULICS - STEERING
05-03	STEERING COLUMN
05-04	AXLE, FRONT (86990837) - MOUNTING
05-05	AXLE, FRONT (86990837) - HOUSING
05-06	AXLE, FRONT (86990837) - HOUSING, SWIVEL
05-07	AXLE, FRONT (86990837) - CYLINDER, STEERING
05-08	AXLE, FRONT (86990837) - HUB AND BEARINGS
05-09	WHEELS, FRONT - TIRES
06-01	AXLE, FRONT DRIVE - MOUNTING
06-02	AXLE, FRONT DRIVE - HOUSING
06-03	AXLE, FRONT DRIVE - HOUSING, SWIVEL
06-04	AXLE, FRONT DRIVE - CYLINDER, STEERING
06-05	AXLE, FRONT DRIVE - SHAFTS, AXLE
06-06	AXLE, FRONT DRIVE - PLANETARY
06-07	AXLE, FRONT DRIVE - DIFFERENTIAL
06-08	AXLE, FRONT DRIVE - RING AND PINION
06-09	DRIVE SHAFT, FRONT AXLE
06-10	COOLING SYSTEM - TRANSMISSION (WITH CUT HOSES AT COOLER)
06-10A	COOLING SYSTEM - TRANSMISSION (WITH FLARED FITTINGS AT COOLER)
06-11	TRANSMISSION - MOUNTING
06-12	TRANSMISSION ASSY - FILTER, OIL
06-13	TRANSMISSION ASSY (2WD) - HOUSING
06-14	TRANSMISSION ASSY (4WD) - HOUSING

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

06-15	TRANSMISSION ASSY - PUMP, OIL
06-16	TRANSMISSION ASSY - SHIFTER MECHANISM
06-17	TRANSMISSION ASSY - SHAFT, IDLER AND PRIMARY
06-18	TRANSMISSION ASSY - SHAFT, INPUT
06-19	TRANSMISSION ASSY - SHAFT, SECONDARY
06-20	TRANSMISSION ASSY (4WD) - SHAFT, OUTPUT
06-21	TRANSMISSION ASSY (86984097 OR 86984098) - VALVE, CONTROL
06-21A	TRANSMISSION ASSY (87456843 OR 87456844) - VALVE, CONTROL
06-21B	TRANSMISSION ASSY (87396484 OR 87396485) - VALVE, CONTROL
06-22	TRANSMISSION ASSY (4WD) - VALVE, SOLENOID
06-23	WHEELS, REAR - TIRES
06-24	AXLE, REAR DRIVE - MOUNTING
06-25	AXLE, REAR - DIFFERENTIAL LOCK
06-26	AXLE, REAR DRIVE - HOUSING
06-27	AXLE, REAR DRIVE - DIFFERENTIAL (384952A1 AXLE / 2 SPIDER DIFFERENTIAL)
06-27A	AXLE, REAR DRIVE - DIFFERENTIAL (87422891 AXLE / 4 SPIDER DIFFERENTIAL)
06-28	AXLE, REAR DRIVE - RING AND PINION
06-29	AXLE, REAR DRIVE - DIFFERENTIAL LOCK
06-30	AXLE, REAR DRIVE - PLANETARY
06-31	DRIVE SHAFT, REAR AXLE
07-01	AXLE, REAR DRIVE - BRAKE, DIFFERENTIAL
07-02	AXLE, REAR DRIVE - BRAKE, PARKING
07-03	BRAKE - PEDALS
07-04	HYDRAULICS - BRAKE MASTER CYLINDER
07-05	CYLINDER ASSY - BRAKE MASTER
07-06	CONTROLS - BRAKE, PARKING
08-01	HYDRAULICS - PUMP, FILTER AND LOADER VALVE
08-02	HYDRAULICS - LOADER VALVE AND FILTER TO BACKHOE VALVE
08-03	HYDRAULICS - COOLER, RETURN LINES AND FILTER
08-04	HYDRAULICS - CYLINDER, LOADER LIFT
08-05	HYDRAULICS - CYLINDER, LOADER BUCKET
08-06	HYDRAULICS - CYLINDER, LOADER CLAM
08-07	HYDRAULICS - CYLINDER, LOADER CLAM
08-08	HYDRAULICS - CYLINDER, BACKHOE STABILIZER (WITHOUT PILOT CONTROLS)
08-08A	HYDRAULICS - CYLINDER, BACKHOE STABILIZER (WITH PILOT CONTROLS)
08-09	HYDRAULICS - CYLINDER, BACKHOE SWING (WITHOUT PILOT CONTROLS)
08-09A	HYDRAULICS - CYLINDER, BACKHOE SWING (WITH PILOT CONTROLS)
08-10	HYDRAULICS - CYLINDER, BACKHOE BOOM
08-10A	HYDRAULICS - BACKHOE BOOM LOCK AND ELECTRICAL CIRCUIT
08-11	HYDRAULICS - CYLINDER, BACKHOE DIPPER
08-12	HYDRAULICS - CYLINDER, BACKHOE BUCKET (MODELS WITHOUT EXTENDABLE DIPPER)
08-13	HYDRAULICS - CYLINDER, BACKHOE BUCKET (MODELS WITH EXTENDABLE DIPPER)
08-14	HYDRAULICS - CYLINDER, BACKHOE EXTENDABLE DIPPER
08-15	HYDRAULICS - VALVE, PILOT CONTROL AND JOYSTICKS (6 SPOOL, W/O EXT DIPPER, W/O AUX HYDS)
08-16	HYDRAULICS - VALVE, PILOT CONTROL AND JOYSTICKS (6 SPOOL, W/O EXT DIPPER, W/ AUX HYDS)
08-17	HYDRAULICS - VALVE, PILOT CONTROL AND JOYSTICKS (7 SPOOL, W/ EXT DIPPER, W/O AUX HYDS)

Order the manual at mid-west-tech.com >

CAMSHAFT

REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTION
		REF			INSTRUCTION, Camshaft 529.5 mm Length; If Used
1		4895323		6	SCREW, Flange, M8 x 40
2		2852062		1	GEAR, 35 mm ID; Used W/ Ref 5
3		4899068		2	SCREW, Hex, M8 x 1.25 x 16, Flange, M8 x 16
4		4897457		1	FLANGE
5		4899610		1	CAMSHAFT, - ASSY; Incl. Ref 6; 529.5 mm Length; If Used
6		4899080		1	DOWEL
7		2852063		1	GEAR, DRIVEN, 52T; 32 mm ID
		REF			INSTRUCTION, Camshaft 554.5 mm Length; If Used
8		(2855099)		1	Camshaft Assy, 554.5 mm Length, Inc. 4899080, Ref 6
9		4899053		6	SCREW, Hex Flg, M8 x 45, M8 x 45; Used W/ Ref 8, 10 and 11
10		2854958		1	GEAR, DRIVEN, 40 mm ID; Used W/ Ref 8 and Ref 11
11		2854959		1	GEAR, DRIVEN, 52T; 40 mm ID; Used W/ Ref 8 and Ref 10

MidWestTech | Case 580M Series 2 Loader Backhoe Parts Catalog | Publication 7-9033NA Order the manual at mid-west-tech.com >

TRANSMISSION ASSY (87396484 OR 87396485) - VALVE, CONTROL

REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTION
		87396484		1	TRANSMISSION, Two Wheel Drive, Incl. Ref 1 - 23; Also Includes Parts On Figures 06-12 - 06-21B, Replaces 86984097, 87456843
		87396485		1	TRANSMISSION, Four Wheel Drive, Incl. Ref 1 - 23; Also Includes Parts On Figures 06-12 - 06-22, Replaces 86984098, 87456844
		87525756		1	KIT, REPAIR, Transmission Control Valve With Jumper Harness; Includes (1) 87456968 Forward/Reverse Jumper Harness, Ref 1; Plus (1) 87524409 Control Valve, Ref 1 - 23
1		87456968		1	HARNESS, WIRE, Jumper; If Used; Required On Transmissions Prior To Ones With Deutsch Connector Type Solenoids
		87524409		1	VALVE, CONTROL, Transmission Control, With Improved Snap Ring at Flow Divider Area; Incl. Ref 2 - 23
2		NSS		1	NOT SERVICED SEPARATELY, Housing
3		190442A1		1	PLUNGER
4		87456900		1	KIT, SERVICE, Solenoid; Includes (2) Solenoids, (1) Jumper Wire Used For Transmissions Prior to Ones With The Solenoids With Plastic Connections; See Figure 06-22, Ref 3 For Solenoids With Bullet Connectors
5		87524436		1	KIT, REPAIR, Seal; Includes (6) O-Rings; Component Parts Not Serviced Separately
7		87530365		1	PLUG
8		87524441		1	ASSEMBLY, Valve Body Kit; Component Parts Not Serviced Separately
9		181251A1		1	COVER, Modulation
10		87524439		1	KIT, REPAIR, Plate; Includes (1) Plate, (2) Gasket, (1) Ball, (1) Spring; Component Parts Not Serviced Separately
11		87524437		1	KIT, REPAIR, Gasket; Includes (4) Gasket Plates; Component Parts Not Serviced Separately

MidWestTech | Case 580M Series 2 Loader Backhoe Parts Catalog | Publication 7-9033NA Order the manual at mid-west-tech.com >

HYDRAULICS - COUPLER, LOADER TOOL QUICK

REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTION
25		218-5056		1	CONNECTOR, HYD., 1/2"-20, 37° x 1/2"-20, O-Ring, 1/2 fl x Or; Incl. Ref 26
26		237-6005		1	O-RING, 5-1, 90 Duro, .414" ID x .072" Thk
		REF			INSTRUCTION, COUPLER ONLY (SEE REF 38-49 FOR CLAMPING ON MODELS WITH COUPLER AND 3-SPOOL LOADER VALVE)
27		87427539		1	HOSE ASSY., 1815 mm (71-1/2 in); B Port
28		87427537		1	HOSE ASSY., 1815 mm (71-1/2 in); A Port
29		814-10090		1	BOLT, Hex, M10 x 90, 8.8
30		814-10070		1	BOLT, Hex, M10 x 70, 8.8, Used Without Washers, Ref 35, 36; If Used; Replaces 814-10060 Used On Some Models
31		D138055		6	CLAMP
31A		D143846		2	SHIN, CLAMP
32		120303A1		1	SPACER
33		832-10410		2	NUT, LOCK, M10 x 1.5, Cl 8
34		398675A2		1	SWITCH, Loader Tool Quick Coupler
35		892-11010		1	WASHER, LOCK, M10
36		896-11010		1	WASHER, M10 x 21.5 x 2.5, HT, FLAT
37		83931335		1	SCREW, Hex, M10 x 75, 8.8, M10 x 75; Used With Ref 35, 36 Washers; If Used
		REF			INSTRUCTION, COUPLER AND 3-SPOOL LOADER VALVE (SEE REF 27-37 FOR CLAMPING ON MODELS WITH COUPLER ONLY)
38		87427539		1	HOSE ASSY., 1815 mm (71-1/2 in); B Port
39		87427537		1	HOSE ASSY., 1815 mm (71-1/2 in); A Port
40		83931335		1	SCREW, Hex, M10 x 75, 8.8
41		892-11010		1	WASHER, LOCK, M10
42		D138055		5	CLAMP
43		120303A1		2	SPACER
44		896-11010		1	WASHER, M10 x 21.5 x 2.5, HT, Flat
45		832-10410		2	NUT, LOCK, M10 x 1.5, Cl 8
46		814-10090		1	BOLT, Hex, M10 x 90, 8.8
47		D143846		2	SHIN, Clamp
48		87447044		1	TUBE ASSY., Loader Clam; A Port

MidWestTech | Case 580M Series 2 Loader Backhoe Parts Catalog | Publication 7-9033NA Order the manual at mid-west-tech.com >