CASE

PROFESSIONAL PARTNER

PARTS CATALOG

LOADER BACKHOE

580 Super M Series 2

580 Super M+ Series 2

7-9043 NA

Replaces 7-9042 NA

Revised 12-2006
Revised 05-2005
Revised 05-2004
Issued 02-2004

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

02-01	RADIATOR - MOUNTING
02-02	DEAERATION SYSTEM - MOUNTING
02-03	RADIATOR ASSY (WITHOUT AIR CONDITIONING)
02-03A	RADIATOR ASSY (WITH AIR CONDITIONING)
02-04	AIR CLEANER - AIR INTAKE PARTS
02-05	AIR CLEANER
02-06	MUFFLER - EXHAUST SYSTEM (WITH TURBOCHARGER)
02-06A	MUFFLER, ASPIRATED & SPARK ARRESTOR - EXHAUST SYSTEM
02-07	ENGINE - MOUNTING
02-07A	ENGINE - BLOCK HEATER
02-08	ENGINE
02-09	CYLINDER BLOCK
02-10	CYLINDER BLOCK
02-11	OIL PUMP, PAN
02-12	CYLINDER BLOCK - COVERS
02-13	CYLINDER BLOCK - COVERS
02-14	CYLINDER BLOCK - COVERS
02-15	BREATHER - ENGINE
02-16	CYLINDER HEAD
02-17	CYLINDER HEAD - COVERS
02-18	CYLINDER HEAD - VALVE MECHANISM
02-19	MANIFOLD - INTAKE
02-20	MANIFOLD - EXHAUST
02-21	CRANKSHAFT
02-22	PISTONS - CONNECTING ROD
02-23	PISTONS - CONNECTING ROD
02-24	FLYWHEEL - ENGINE
02-25	PULLEY - CRANKSHAFT
02-26	DYNAMIC BALANCER, GEARS & SHAFTS
02-27	DYNAMIC BALANCER, GEARS & SHAFTS (2830952)
02-28	CAMSHAFT
02-29	TURBOCHARGER
02-30	ENGINE, OIL
02-31	OIL PUMP - ENGINE
02-32	OIL FILTERS - ENGINE
02-33	PIPING - ENGINE OIL
02-34	OIL FILTER AND COOLER
02-35	WATER PUMP
02-36	COOLING SYSTEM - ENGINE
02-37	THERMOSTAT - ENGINE COOLING SYSTEM
02-38	WATER PUMP - CONTROL
02-39	FAN DRIVE
02-40	POWER TAKE-OFF
02-41	ENGINE - LIFT HOOK
03-01	FUEL LINES, RESERVOIR
03-02	CONTROLS - THROTTLE, HAND
03-03	CONTROLS - THROTTLE, FOOT
03-04	FUEL INJECTION PUMP
03-05	FUEL INJECTION SYSTEM
03-06	FUEL INJECTION SYSTEM
03-07	FUEL INJECTION SYSTEM

MidWestTech | Case 580 Super M, M+ Series 2 Loader Backhoe Parts Catalog | Publicatio... Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

03-08	FUEL FILTER
03-09	FUEL PUMP
03-10	FUEL INJECTION SYSTEM
03-11	FUEL INJECTION SYSTEM
04-01	STARTER
04-02	ALTERNATOR
04-03	STARTER MOUNTING - ALTERNATOR MOUNTING
04-04	HARNESS, ENGINE - MOUNTING AND CONNECTIONS
04-05	BATTERY CABLES (MODELS WITHOUT COLD START)
04-06	BATTERY, DUAL - COLD START
04-06A	COLD START GRID HEATER
04-07	HARNESS, FRONT CONSOLE - SWITCHES
04-08	HARNESS, FRONT CONSOLE - MOUNTING
04-09	ELECTRICAL - TRANSMISSION, POWERSHIFT (WITHOUT COMFORT STEER)
04-09A	ELECTRICAL - TRANSMISSION, POWERSHIFT (WITH COMFORT STEER)
04-10	HARNESS, SIDE CONSOLE - SWITCHES
04-11	INSTRUMENT PANEL, FRONT - COVERS
04-12	INSTRUMENT PANEL, SIDE - COVERS (RIGHT-HAND SIDE)
04-13	INSTRUMENT CLUSTER
04-14	ELECTRICAL - LAMPS, ROPS CANOPY
04-15	ELECTRICAL - LAMPS, ROPS CAB
04-16	LAMP ASSY (ROPS CANOPY MODELS)
04-17	HORN - ALARM, BACKUP
04-18	BEACON, ROTATING (CAB OR CANOPY MODELS)
04-19	ANTENNA, RADIO - HARNESS, RADIO
04-20	ELECTRICAL - BACKHOE AUXILIARY HYDRAULIC, UNI-DIRECTIONAL
04-21	ELECTRICAL - BACKHOE AUXILIARY HYDRAULIC, WITH PILOT CONTROLS
05-01	STEERING WHEEL - COLUMN
05-02	HYDRAULICS - STEERING
05-02A	HYDRAULICS - STEERING (COMFORT STEER)
05-03	STEERING COLUMN
05-04	AXLE, FRONT (86990837) - MOUNTING
05-05	AXLE, FRONT (86990837) - HOUSING
05-06	AXLE, FRONT (86990837) - HOUSING, SWIVEL
05-07	AXLE, FRONT (86990837) - CYLINDER, STEERING
05-08	AXLE, FRONT (86990837) - HUB AND BEARINGS
05-09	WHEELS, FRONT - TIRES
06-01	AXLE, FRONT DRIVE - MOUNTING
06-02	AXLE, FRONT DRIVE - HOUSING
06-03	AXLE, FRONT DRIVE - HOUSING, SWIVEL
06-04	AXLE, FRONT DRIVE - CYLINDER, STEERING
06-05	AXLE, FRONT DRIVE - SHAFTS, AXLE
06-06	AXLE, FRONT DRIVE - PLANETARY
06-07	AXLE, FRONT DRIVE - DIFFERENTIAL
06-08	AXLE, FRONT DRIVE - RING AND PINION
06-09	DRIVE SHAFT, FRONT AXLE
06-10	COOLING SYSTEM - TRANSMISSION (MODELS WITHOUT POWERSHIFT)(WITH CUT HOSES AT COOLER)
06-11	COOLING SYSTEM - TRANSMISSION (MODELS WITH POWERSHIFT)(WITH CUT HOSES AT COOLER)
06-11A	COOLING SYSTEM - TRANSMISSION (WITH FLARED FITTINGS AT COOLER)

MidWestTech | Case 580 Super M, M+ Series 2 Loader Backhoe Parts Catalog | Publicatio... Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

06-12	TRANSMISSION - MOUNTING (MODELS WITHOUT POWERSHIFT)
06-13	TRANSMISSION - MOUNTING (MODELS WITH POWERSHIFT)
06-14	TRANSMISSION ASSY - FILTER, OIL (MODELS WITHOUT POWERSHIFT)
06-15	TRANSMISSION ASSY (2WD) - HOUSING (MODELS WITHOUT POWERSHIFT)
06-16	TRANSMISSION ASSY (4WD) - HOUSING (MODELS WITHOUT POWERSHIFT)
06-17	TRANSMISSION ASSY - PUMP, OIL (MODELS WITHOUT POWERSHIFT)
06-18	TRANSMISSION ASSY - SHIFTER MECHANISM (MODELS WITHOUT POWERSHIFT)
06-19	TRANSMISSION ASSY - SHAFT, IDLER AND PRIMARY (MODELS WITHOUT POWERSHIFT)
06-20	TRANSMISSION ASSY - SHAFT, INPUT (MODELS WITHOUT POWERSHIFT)
06-21	TRANSMISSION ASSY - SHAFT, SECONDARY (MODELS WITHOUT POWERSHIFT)
06-22	TRANSMISSION ASSY (4WD) - SHAFT, OUTPUT (MODELS WITHOUT POWERSHIFT)
06-23	TRANSMISSION ASSY (86984097 OR 86984098) - VALVE, CONTROL (MODELS WITHOUT POWERSHIFT)
06-23A	TRANSMISSION ASSY (87456843 OR 87456844) - VALVE, CONTROL (MODELS WITHOUT POWERSHIFT)
06-23B	TRANSMISSION ASSY (87396484 OR 87396485) - VALVE, CONTROL (MODELS WITHOUT POWERSHIFT)
06-24	TRANSMISSION ASSY (4WD) - VALVE, SOLENOID (MODELS WITHOUT POWERSHIFT)
06-25	TRANSMISSION ASSY, POWERSHIFT - HOUSING
06-26	TRANSMISSION ASSY, POWERSHIFT - HOUSING, REAR
06-27	TRANSMISSION ASSY, POWERSHIFT - TORQUE CONVERTER
06-28	TRANSMISSION ASSY, POWERSHIFT - PUMP, OIL
06-29	TRANSMISSION ASSY, POWERSHIFT - CLUTCH, FORWARD DRIVE
06-30	TRANSMISSION ASSY, POWERSHIFT - CLUTCH, REVERSE DRIVE
06-31	TRANSMISSION ASSY, POWERSHIFT - CLUTCH, PUMP DRIVE
06-32	TRANSMISSION ASSY, POWERSHIFT - CLUTCH, SECOND GEAR
06-33	TRANSMISSION ASSY, POWERSHIFT - CLUTCH, OUTPUT SHAFT
06-34	TRANSMISSION ASSY, POWERSHIFT - MOUNTING, VALVE
06-35	TRANSMISSION ASSY, POWERSHIFT - VALVE, CONTROL
06-36	TRANSMISSION ASSY, POWERSHIFT - PLATE, DRIVE
06-37	WHEELS, REAR - TIRES
06-38	AXLE, REAR DRIVE - MOUNTING
06-39	AXLE, REAR - DIFFERENTIAL LOCK
06-40	AXLE, REAR DRIVE - HOUSING
06-41	AXLE, REAR DRIVE - DIFFERENTIAL (CLOCKWISE INPUT, MODELS WITHOUT POWERSHIFT)
06-42	AXLE, REAR DRIVE - DIFFERENTIAL (COUNTER CLOCKWISE INPUT, MODELS WITH POWERSHIFT)
06-43	AXLE, REAR DRIVE - RING AND PINION
06-44	AXLE, REAR DRIVE - DIFFERENTIAL LOCK (CLOCKWISE INPUT, MODELS WITHOUT POWERSHIFT)
06-45	AXLE, REAR DRIVE - DIFFERENTIAL LOCK (COUNTER CLOCKWISE INPUT, MODELS WITH POWERSHIFT)
06-46	AXLE, REAR DRIVE - PLANETARY
06-47	DRIVE SHAFT, REAR AXLE
07-01	AXLE, REAR DRIVE - BRAKE, DIFFERENTIAL
07-02	AXLE, REAR DRIVE - BRAKE, PARKING
07-03	BRAKE - PEDALS
07-04	HYDRAULICS - BRAKE MASTER CYLINDER

MidWestTech | Case 580 Super M, M+ Series 2 Loader Backhoe Parts Catalog | Publicatio... Order the manual at mid-west-tech.com >

AXLE, REAR DRIVE - RING AND PINION

REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTION
		384956A1		1	AXLE, REAR, 580SM Models Without Powershift Transmission, Incl. Ref 1 - 12; Also Includes Parts On Figures 06-40 - 06-46, 07-01, 07-02
		86984108		1	AXLE DRIVE, 580SM+ Models Without Powershift Transmission, Incl. Ref 1 - 12; Also Includes Parts On Figures 06-40 - 06-46, 07-01, 07-02
		384958A1		1	AXLE, REAR, 580SM Models With Powershift Transmission, Incl. Ref 1 - 12; Also Includes Parts On Figures 06-40 - 06-46, 07-01, 07-02
		86984107		1	AXLE DRIVE, 580SM+ Models With Powershift Transmission, Incl. Ref 1 - 12; Also Includes Parts On Figures 06-40 - 06-46, 07-01, 07-02
		294189A1		1	SET, Ring and Pinion Gear Set, Clockwise, Incl. Ref 1, 3 - 6; 384956A1 or 86984108 Axle
		294190A1		1	SET, Ring and Pinion Gear Set, Counter Clockwise, Incl. Ref 1A, 3 - 6; 384958A1or 86984107 Axle
1		NSS		1	NOT SERVICED SEPARATELY, Gear Set, 294189A1 Gear Set
1A		NSS		1	NOT SERVICED SEPARATELY, Gear Set, 294190A1 Gear Set
3		K261065		1	WASHER
4		K261014		1	NUT, Ring
5		1349059C1		2	WASHER
6		295110A1		1	SPACER, Collapsible
7		190506A1		X	SHIM, 2,5 mm (0,098 in)
7		190508A1		X	SHIM, 2,6 mm (0,102 in)
7		190509A1		X	SHIM, 2,7 mm (0,106 in)
7		190510A1		X	SHIM, 2,8 mm (0,110 in)
7		190511A1		X	SHIM, 2,9 mm (0,114 in)
7		190512A1		X	SHIM, 3,0 mm (0,118 in)
7		190513A1		X	SHIM, 3,1 mm (0,122 in)
7		190514A1		X	SHIM, 3,2 mm (0,125 in)
7		190515A1		X	SHIM, 3,3 mm (0,129 in)
7		190516A1		X	SHIM, 3,4 mm (0,133 in)
8		E135762		1	BEARING, 45 x 100 mm

MidWestTech | Case 580 Super M, M+ Series 2 Loader Backhoe Parts Catalog | Publicatio... Order the manual at mid-west-tech.com >

HYDRAULICS - COUPLER, LOADER TOOL QUICK

REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTION
25		218-5056		1	CONNECTOR, HYD., 1/2"-20, 37° x 1/2"-20, O-Ring, 1/2 fl x Or; Incl. Ref 26
26		237-6005		1	O-RING, 5-1, 90 Duro, .414" ID x .072" Thk
		REF			INSTRUCTION, COUPLER ONLY (SEE REF 38-49 FOR CLAMPING ON MODELS WITH COUPLER AND 3-SPOOL LOADER VALVE)
27		87427539		1	HOSE ASSY., 1815 mm (71-1/2 in); B Port
28		87427537		1	HOSE ASSY., 1815 mm (71-1/2 in); A Port
29		814-10090		1	BOLT, Hex, M10 x 90, 8.8
30		814-10070		1	BOLT, Hex, M10 x 70, 8.8, M10 x 70; Used Without Washers, Ref 35, 36; If Used
31		D138055		6	CLAMP
31A		D143846		2	SHIN, CLAMP
32		120303A1		1	SPACER
33		832-10410		2	NUT, LOCK, M10 x 1.5, Cl 8
34		398675A2		1	SWITCH, Loader Tool Quick Coupler
35		892-11010		1	WASHER, LOCK, M10
36		896-11010		1	WASHER, M10 x 21.5 x 2.5, HT, FLAT
37		83931335		1	SCREW, Hex, M10 x 75, 8.8, M10 x 75; Used With Ref 35, 36 Washers; If Used
		REF			INSTRUCTION, COUPLER AND 3-SPOOL LOADER VALVE (SEE REF 27-37 FOR CLAMPING ON MODELS WITH COUPLER ONLY)
38		87427539		1	HOSE ASSY., 1815 mm (71-1/2 in); B Port
39		87427537		1	HOSE ASSY., 1815 mm (71-1/2 in); A Port
40		83931335		1	SCREW, Hex, M10 x 75, 8.8
41		892-11010		1	WASHER, LOCK, M10
42		D138055		5	CLAMP
43		120303A1		2	SPACER
44		896-11010		1	WASHER, M10 x 21.5 x 2.5, HT, Flat
45		832-10410		2	NUT, LOCK, M10 x 1.5, Cl 8
46		814-10090		1	BOLT, Hex, M10 x 90, 8.8
47		D143846		2	SHIN, Clamp
48		87447044		1	TUBE ASSY., Loader Clam; A Port
49		87449440		1	TUBE ASSY., Loader Clam; B Port

MidWestTech | Case 580 Super M, M+ Series 2 Loader Backhoe Parts Catalog | Publicatio... Order the manual at mid-west-tech.com >

CYLINDER ASSY - LOADER CLAM

REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTION
1		1346189C1		1	CYLINDER ASSY., 76 ID x 231 mm strk; Right-Hand; Incl. Ref 2 - 23; If Used
1		87454017		1	CYLINDER ASSY., 76 ID x 231 mm strk; Right-Hand; Incl. Ref 2 - 23; If Used
1		1346190C1		1	CYLINDER ASSY., 76 ID x 231 mm strk; Left-Hand; Incl. Ref 2 - 23; If Used
1		87454016		1	CYLINDER ASSY., 76 ID x 231 mm strk; Left-Hand; Incl. Ref 2 - 23; If Used
2		1346191C1		1	SLEEVE, HYD CYL, TUBE, Right-Hand; 1346189C1 Cylinder; Includes (2) 30634 Bushings; If Used
2		87454907		1	TUBE ASSY., TUBE, Right-Hand; 87454017 Cylinder; Includes (2) 30634 Bushings; If Used
2		1346192C1		1	SLEEVE, HYD CYL, TUBE, Left-Hand; 1346190C1 Cylinder; Includes (2) 30634 Bushings; If Used
2		87454908		1	TUBE ASSY., TUBE, Left-Hand; 87454016 Cylinder; Includes (2) 30634 Bushings; If Used
4		297281A1		1	CAP CYLINDER END, Gland
		1543267C1		1	KIT, GASKET, Seal Repair; Incl. Ref 5 - 11, 16 - 18
5		D95143		1	SEAL
6		G102425		1	BUSHING, LARGE
		1542875C1		1	SET OF PARTS, Rod and Buffer Seal; Incl. Ref 8, 9; Not Serviced Separately; Order 1543267C1 Seal Kit
8		NSS		1	NOT SERVICED SEPARATELY, Rod Seal; Order 1543267C1 Seal Kit
9		NSS		1	NOT SERVICED SEPARATELY, Buffer Seal; Order 1543267C1 Seal Kit
10		238-5231		1	O-RING, -231, 70 Duro, 2.609" ID x .139" Thk
11		G109298		1	RING
12		276-2446		1	SCREW, SELF TAP, Hex Hd, #8 x 3/8", Self-Tapping, No. 8 x 3/8
13		1346195C1		1	ROD, PISTON, 44 mm (1-3/4 in) dia; Incl. Ref 14
14		30634		2	BUSHING
15		1340798C1		1	PISTON
16		G102288		1	SEAL ASSY.
17		G100444		1	SEAL

MidWestTech | Case 580 Super M, M+ Series 2 Loader Backhoe Parts Catalog | Publicatio... Order the manual at mid-west-tech.com >