4-390, 4T390, 4TA-390 Engines

Service Manual

7-91612

CASE CONSTRUCTION

MidWestTech | Case 4-390, 4T390, 4TA-390 Engine Service Manual | Publication 7-91612

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

TORQUE SPECIFICATIONS - DECIMAL HARDWARE 2

TORQUE SPECIFICATIONS - METRIC HARDWARE 3

TORQUE SPECIFICATIONS - STEEL HYDRAULIC FITTINGS 4

TORQUE SPECIFICATIONS - STEEL HYDRAULIC FITTINGS 5

TORQUE SPECIFICATIONS - DECIMAL HARDWARE

Use the torques in this chart when special torques are not given. These torques apply to fasteners with both UNC and UNF threads as received from suppliers dry, or when lubricated with engine oil. Not applicable if special graphities, Molydisulfide greases, or other extreme pressure lubricants are used.

Grade 5 Bolts, Nuts, and Studs



Size	Pound-Inches	Newton metres
1/4 inch	108 to 132	12 to 15
5/16 inch	204 to 252	23 to 28
3/8 inch	420 to 504	48 to 57
Size	**Pound-Feet**	**Newton metres**
7/16 inch	54 to 64	73 to 87
1/2 inch	80 to 96	109 to 130
9/16 inch	110 to 132	149 to 179
5/8 inch	150 to 180	203 to 244
3/4 inch	270 to 324	366 to 439
7/8 inch	400 to 480	542 to 651
1.0 inch	580 to 696	787 to 944
1-1/8 inch	800 to 880	1085 to 1193
1-1/4 inch	1120 to 1240	1519 to 1681
1-3/8 inch	1460 to 1680	1980 to 2278
1-1/2 inch	1940 to 2200	2631 to 2983

Grade 8 Bolts, Nuts, and Studs



Size	Pound-Inches	Newton metres
1/4 inch	144 to 180	16 to 20
5/16 inch	288 to 348	33 to 39
3/8 inch	540 to 648	61 to 73
Size	**Pound-Feet**	**Newton metres**
7/16 inch	70 to 84	95 to 114
1/2 inch	110 to 132	149 to 179
9/16 inch	160 to 192	217 to 260
5/8 inch	220 to 264	298 to 358
3/4 inch	380 to 456	515 to 618
7/8 inch	600 to 720	814 to 976
1.0 inch	900 to 1080	1220 to 1465
1-1/8 inch	1280 to 1440	1736 to 1953
1-1/4 inch	1820 to 2000	2468 to 2712
1-3/8 inch	2380 to 2720	3227 to 3688
1-1/2 inch	3160 to 3560	4285 to 4827

NOTE: *Use thick nuts with Grade 8 bolts.*

Retyped November,

Rac 8-71602

Issued 11-91/ Revised 6-01

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

SPECIFICATIONS 3

FILTER REPLACEMENT 4

BLEEDING AIR FROM THE FUEL SYSTEM 6

LIFT PUMP SERVICE 7

PRIMER PUMP TESTING 11
- Diaphragm Style 11
- Piston Style 12

Rac 8-24214 Revised 5-99 Printed in U.S.A

MidWestTech | Case 4-390, 4T390, 4TA-390 Engine Service Manual | Publication 7-91612 Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

SPECIAL TOOLS 2

SPECIAL TORQUES 2

TROUBLESHOOTING GUIDE 3

FUEL INJECTION PUMP 4
- Removal 4
- Installation 6

INJECTION PUMP GEAR 8
- Removal 8
- Installation 10

INJECTION PUMP TIMING 11

FUEL SHUTOFF SOLENOID 14
- Removal and Disassembly 14
- Assembly and Installation 14

PRIMER PUMP 15
- Removal 15
- Installation 15

SPECIAL TOOLS



CAS -1690 ENGINE TURN OVER TOOL
FIRST USED ON PAGE 5



CAS -1691A GEAR PULLER
FIRST USED ON PAGE 5

SPECIAL TORQUES

Injection Pump Mounting Bolts	21 to 27 Nm
Injection Pump Nut	59 to 71 Nm
Fuel Line Inlet Bolt	22 to 28 Nm
Fuel Shutoff Solenoid	14 Nm
Leak Off Fitting	13 to 17 Nm
Injection Pump Lock Bolt (Lock Position)	7 Nm
Injection Pump Lock Bolt (Unlock Position)	20 Nm

Rac 7-37133 Revised 5-99 Printed in U.S.A

MidWestTech | Case 4-390, 4T390, 4TA-390 Engine Service Manual | Publication 7-91612 Order the manual at mid-west-tech.com >