445
445CT
Skid Steer

Parts Catalog

7-9162NA

Issued 11-2004
Revised 02-2005
Revised 05-2005

CASE CONSTRUCTION

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

02-01	RADIATOR - COOLANT RECOVERY SYSTEM
02-02	FAN - FAN BELT
02-03	EXHAUST SYSTEM
02-03A	EXHAUST SYSTEM, ASPIRATOR
02-04	AIR CLEANER - ENGINE
02-05	GRID HEATER
02-06	ENGINE - MOUNTING
02-06A	OIL FILL, ENGINE
02-07	ENGINE - BLOCK HEATER
02-08	ENGINE
02-09	CYLINDER BLOCK
02-10	CYLINDER BLOCK
02-11	OIL PUMP, PAN
02-12	CYLINDER BLOCK - COVERS
02-13	CYLINDER BLOCK - COVERS
02-14	CYLINDER BLOCK - COVERS
02-15	BREATHER - ENGINE
02-16	CYLINDER HEAD
02-17	CYLINDER HEAD - COVERS
02-18	CYLINDER HEAD - VALVE MECHANISM
02-19	MANIFOLD - INTAKE
02-20	MANIFOLD - EXHAUST
02-21	CRANKSHAFT
02-22	PISTONS - CONNECTING ROD
02-23	PISTONS - CONNECTING ROD
02-24	FLYWHEEL - ENGINE
02-25	PULLEY - CRANKSHAFT
02-26	CAMSHAFT
02-27	ENGINE, OIL
02-28	OIL PUMP - ENGINE
02-29	OIL FILTERS - ENGINE
02-30	OIL FILTER AND COOLER
02-31	WATER PUMP
02-32	COOLING SYSTEM - ENGINE
02-33	THERMOSTAT - ENGINE COOLING SYSTEM
02-34	WATER PUMP - CONTROL
02-35	FAN DRIVE
02-36	POWER TAKE-OFF
02-37	ENGINE - LIFT HOOK
03-01	FUEL LINES
03-02	CONTROLS - THROTTLE
03-03	FUEL INJECTION PUMP
03-04	FUEL INJECTION SYSTEM
03-05	FUEL INJECTION SYSTEM
03-06	FUEL INJECTION SYSTEM
03-07	FUEL FILTER
03-08	FUEL PUMP
03-09	FUEL INJECTION SYSTEM
03-10	FUEL INJECTION SYSTEM
04-01	STARTER
04-02	ALTERNATOR

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

04-03	ALTERNATOR MOUNTING
04-04	BATTERY - CABLES
04-05	DISCONNECT SWITCH - REMOTE JUMP START
04-06	HARNESS, FRONT - CHASSIS
04-07	HARNESS, REAR - CHASSIS
04-09	SWITCH MOUNTING - CHASSIS OPTIONS
04-10	SWITCH MOUNTING - LOCK, LOADER CONTROL
04-11	HARNESS - CAB, SEAT BAR
04-12	HARNESS - DOOR, FRONT
04-13	HARNESS, FRONT - AUXILIARY
04-14	WIPER, WINDSHIELD
04-15	CONTROLS, RIGHT HAND - HANDLE
04-15A	CONTROLS, RIGHT HAND - HANDLE
04-16	CONTROLS, LEFT HAND - HANDLE
04-16A	CONTROLS, LEFT HAND - HANDLE
04-17	LAMP ASSY - BEACON, ROTATING
04-18	HORN - MOUNTING
04-19	MOUNTING - LAMP, LICENSE PLATE (EUROPE)
04-20	LAMP ASSY - LICENSE PLATE (EUROPE)
04-21	MOUNTING - LAMP ASSY, COMBINATION, FRONT
04-22	MOUNTING - LAMP ASSY, COMBINATION, REAR
04-23	MOUNTING - LAMPS, ROAD (EUROPE)
04-24	LAMP, BRAKE (EUROPE)
04-25	BACKUP ALARM
04-26	ELECTRICAL ACCESSORIES SOCKET
06-01	OIL COOLER - MOUNTING
06-02	OIL COOLER - MOUNTING (HIGH FLOW)
06-03	HYDROSTATICS - CASE DRAIN
06-04	HYDROSTATICS - PUMP, SUPPLY AND RETURN (445)
06-04A	HYDROSTATICS - DRIVE MOTORS (445)
06-05	HYDROSTATICS - PUMP, SUPPLY AND RETURN (445CT)
06-05A	HYDROSTATICS - BRAKE VALVE (445CT)
06-05B	HYDROSTATICS - DRIVE MOTORS (445CT)
06-06	HYDROSTATICS - TWO SPEED
06-07	HYDROSTATICS - TWO SPEED, VALVE ASSY
06-08	FILTER ASSY - MOUNTING
06-09	PUMP, TANDEM - MOUNTING
06-10	PUMP, TANDEM
06-11	PUMP, TANDEM
06-12	PUMP, TANDEM
06-13	PUMP, TANDEM
06-14	PUMP, TANDEM
06-15	PUMP, TANDEM
06-16	PUMP, GEAR (WITHOUT HIGH FLOW)
06-17	PUMP, GEAR (HIGH FLOW)
06-18	MOTOR ASSY - SINGLE SPEED
06-19	MOTOR ASSY - SINGLE SPEED
06-20	MOTOR ASSY - SINGLE SPEED
06-20A	FINAL DRIVE (445CT)
06-21	MOTOR ASSY - TWO SPEED
06-22	MOTOR ASSY - TWO SPEED

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

06-23	MOTOR ASSY - TWO SPEED
06-24	DRIVE LINE
06-25	AXLE ASSY
06-26	WHEELS
06-26A	TRACK (445CT)
07-01	BRAKE SYSTEM - HYDRAULIC
08-01	HYDRAULICS - LOADER LIFT
08-02	HYDRAULICS - LOADER BUCKET
08-03	HYDRAULICS - SELF-LEVELING
08-04	VALVE ASSY, SELF LEVEL
08-05	HYDRAULICS - AUXILIARY SYSTEM
08-06	HYDRAULICS - RIDE CONTROL
08-07	HYDRAULICS - COUPLER SYSTEM
08-08	VALVE ASSY, CONTROL - HIGH FLOW
08-09	VALVE ASSY, CONTROL - LOADER
08-10	VALVE ASSY, CONTROL - LOADER
08-11	CYLINDER - LOADER LIFT
08-12	CYLINDER - LOADER BUCKET
08-13	HYDRAULICS, ATTACHMENT - HIGH FLOW, GEAR
08-14	HYDRAULICS, ATTACHMENT - HIGH FLOW, ACCUMULATOR
08-15	HYDRAULICS, ATTACHMENT - HIGH FLOW, SUPPLY AND RETURN
08-16	HYDRAULICS, ATTACHMENT - HIGH FLOW, CONTROL VALVE
08-17	SECONDARY FRONT AUXILIARY
08-18	SECONDARY FRONT AUXILIARY - VALVE ASSY
08-19	SECONDARY FRONT AUXILIARY
08-20	VALVE ASSY, CONTROL - HIGH FLOW
09-01	FRAME - LOADER LIFT
09-02	SUPPORT - LOADER FRAME
09-03	ARM, LOADER H-FRAME
09-04	COUPLER, MECHANICAL
09-05	COUPLER, HYDRAULIC
09-06	BUCKETS, LOADER - 1860 MM (73 IN) WIDE BUCKET
09-06A	BUCKETS, LOADER - 2083 MM (82 IN) WIDE BUCKET
09-07	BUCKETS, LOADER - 2134 MM (84 IN) WIDE BUCKET
09-07A	BUCKET, CUTTING EDGE (BOLT-ON CUTTING EDGE)
09-07B	PALLET FORK
09-08	CHASSIS (445)
09-08A	CHASSIS (445CT)
09-09	CHASSIS (445)
09-09A	CHASSIS (445CT)
09-10	CONSOLE, CONTROL
09-11	CONTROLS - LOADER AND GROUND DRIVE
09-12	LINKAGE - LOADER AND GROUND DRIVE
09-13	LINKAGE - AUXILIARY SYSTEM
09-14	HOOD
09-15	DOOR, REAR
09-16	SOUND PADS
09-17	COUNTERWEIGHTS
09-18	SEAT, MOUNTING - NON-SUSPENSION
09-19	SEAT, MOUNTING - SUSPENSION
09-20	SEAT - SUSPENSION

Order the manual at mid-west-tech.com >

PUMP, TANDEM

REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTION
		REF			INSTRUCTION Front Pump
		87043502		1	PUMP Incl. 1 - 29; Incl. Parts On Figure 06-10 - 06-15
1		402364A1		1	HOUSING
2		87039612		1	VALVE, BY-PASS Incl. Ref 3, 4
3		S99877		1	RING
4		86993475		1	O-RING 3/8 ID x 1/16; Included in 140008A1 Seal Kit
		H436101		2	POPPET, VALVE Incl. 5 - 7A
5		NSS		1	NOT SERVICED SEPARATELY Plug
6		237-6012		1	O-RING 59/64 ID x 7/64; Included in 140008A1 Seal Kit
7		NSS		1	NOT SERVICED SEPARATELY Valve, Relief
7A		86993468		1	SPRING
8		218-5212		2	PLUG 1-1/16 Or; Hex Socket; Incl. 9
9		237-6012		1	O-RING 59/64 ID x 7/64
10		218-5155		2	PLUG 9/16 Or; Incl. 11
11		237-6006		1	O-RING 15/32 ID x 5/64
12		F23137		1	PLUG
13		86993479		1	PLUG Pipe
14		86993480		1	ELBOW
15		86993467		1	CAP
16		303709A1		1	SEAL Filter Adapter; Included in 140008A1 Seal Kit
17		101462A1		1	ADAPTER Suction Line Filter
18		26-516		3	BOLT
19		218-5155		1	PLUG Hex, 9/16; Incl. Ref 20
20		237-6006		1	O-RING 15/32 ID x 5/64 in wide
		140008A1		1	KIT, GASKET Overhaul Seal And Gasket Kit; Incl. (10) Rings, (4) Bearings, (20) O-Rings, (6) Gaskets, (2) Seals; Incl. Ref 3, 4, 6, 16, 25
21		166-89		2	BOLT
22		218-5153		1	PLUG Hex 7/16; Incl. 23
23		237-6006		1	O-RING 15/32 ID x 5/64
24		87039611		1	PLUG Charge Relief; Incl. 25
25		237-6010		1	O-RING 3/4 ID x 3/32; Included in 140008A1 Seal Kit
26		H407767		1	KIT Shim
27		244898A1		1	SPRING

MidWestTech | Case 445, 445CT Skid Steer Parts Catalog | Publication 7-9162na Order the manual at mid-west-tech.com >

BUCKETS, LOADER - 1860 MM (73 IN) WIDE BUCKET

REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTION
1		244554A2		1	ATTACHMENT 1860 mm (73 in); Machinery Item; Incl. 2 - 4
2		H438919		1	EDGE, CUTTING 152 mm (6 in); Welded On
3		245109A2		2	EDGE, CUTTING Side; Welded On
4		857-12030		4	SCREW M12 x 30; 10.9
5		245078A2		1	BUCKET 1860 mm (73 in); Machinery Item; Incl. 6, 7
6		245108A1		1	EDGE, CUTTING Welded On
7		245109A2		1	EDGE, CUTTING Side; Welded On
8		857-12030		4	SCREW M12 x 30; 10.9; Use Existing Hardware
9		252645A2		1	HINGED SIDE Used With 244554A2
10		811-12035		2	SCREW 12 x 35 mm
11		86625256		2	WASHER 13,5 x 28 x 4 mm
12		825-1412		2	NUT M12; 10
13		H674862		1	BUCKET 1860 mm (73 in); Machinery Item; Incl. 10, 11
14		H438919		1	EDGE, CUTTING 152 mm (6 in); Welded On
15		H438259		2	EDGE Side; Welded On
16		294681A1		1	EDGE, CUTTING 1860 mm (73 in); Used With 244554A2
17		H439029		1	EDGE, CUTTING 152 mm (6 in) wide; Used With H674862
18		420-21036		12	BOLT 5/8 x 2-1/4; 8
19		329-1010		12	NUT 5/8; 8

MidWestTech | Case 445, 445CT Skid Steer Parts Catalog | Publication 7-9162na Order the manual at mid-west-tech.com >

DECALS - ITALIAN, NORWEGIAN, POLISH

REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTION
		REF			INSTRUCTION ITALIAN
1		297370A1		1	DECAL Danger, Crush Hazard
2		297398A1		1	DECAL Danger, Crush Hazard
3		321-7004		1	DECAL Caution, Always Inspect
4		297384A1		1	DECAL Warning, Tip Hazard
5		256457A1		1	ADHESIVE Warning, Ride Control
6		256468A1		1	ADHESIVE Warning, Accumulator
7		E137085		1	DECAL Do Not Operate
		REF			INSTRUCTION NORWEGIAN
1		297371A1		1	DECAL Danger, Crush Hazard
2		297399A1		1	DECAL Danger, Crush Hazard
3		297411A1		1	DECAL Caution, Always Inspect
4		297385A1		1	DECAL Warning, Tip Hazard
5		256462A1		1	DECAL Warning, Ride Control
6		256473A1		1	DECAL Warning, Accumulator
7		197381A1		1	TAG Do Not Operate
		REF			INSTRUCTION POLISH
1		297372A1		1	DECAL Danger, Crush Hazard
2		297400A1		1	DECAL Danger, Crush Hazard
3		297412A1		1	DECAL Caution, Always Inspect
4		297386A1		1	DECAL Warning, Tip Hazard
5		396700A1		1	DECAL Warning, Ride Control
6		396701A1		1	DECAL Warning, Accumulator
7		298520A1		1	TAG Do Not Operate

MidWestTech | Case 445, 445CT Skid Steer Parts Catalog | Publication 7-9162na Order the manual at mid-west-tech.com >