PARTS CATALOG

DC95
CRAWLER DOZER

7-9311 NA

NEW HOLLAND
CONSTRUCTION

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

02-01	ENGINE - MOUNTING
02-02	FAN - FAN BELT
02-03	RADIATOR - MOUNTING
02-04	RADIATOR ASSY
02-05	COOLANT RECOVERY SYSTEM
02-06	AIR CLEANER - MOUNTING
02-07	AIR CLEANER ASSY
02-08	MUFFLER - EXHAUST SYSTEM
02-09	ENGINE
02-10	CYLINDER BLOCK
02-11	CYLINDER BLOCK
02-12	CYLINDER BLOCK
02-13	OIL PAN
02-14	CYLINDER BLOCK - COVERS
02-15	CYLINDER BLOCK - COVERS
02-16	CYLINDER BLOCK - COVERS
02-17	BREATHER - ENGINE
02-18	CYLINDER HEAD
02-19	CYLINDER HEAD - COVERS
02-20	CYLINDER HEAD - VALVE MECHANISM
02-21	MANIFOLD - INTAKE
02-22	MANIFOLD - EXHAUST
02-23	CRANKSHAFT
02-24	PISTONS - CONNECTING ROD
02-25	PISTONS - CONNECTING ROD
02-26	FLYWHEEL - ENGINE
02-27	PULLEY - CRANKSHAFT
02-28	CAMSHAFT
02-29	TURBOCHARGER
02-30	ENGINE, OIL
02-31	OIL PUMP - ENGINE
02-32	OIL FILTERS - ENGINE
02-33	PIPING - ENGINE OIL
02-34	OIL FILTER AND COOLER
02-35	WATER PUMP
02-36	COOLING SYSTEM - ENGINE
02-37	THERMOSTAT - ENGINE COOLING SYSTEM
02-38	WATER PUMP - CONTROL
02-39	FAN DRIVE
02-40	POWER TAKE-OFF
02-41	ENGINE - LIFT HOOK
03-01	CONTROLS, THROTTLE - CABLE AND HAND LEVER
03-02	CONTROLS, THROTTLE - DECELERATOR PEDAL AND CROSS SHAFT
03-03	CONTROLS, THROTTLE - LINKAGE AT ENGINE
03-04	FUEL TANK
03-05	FUEL LINES
03-06	FUEL INJECTION PUMP
03-07	FUEL INJECTION SYSTEM
03-08	FUEL INJECTION SYSTEM
03-09	FUEL INJECTION SYSTEM
03-10	FUEL FILTER
03-11	FUEL PUMP

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

03-12	FUEL INJECTION SYSTEM
03-13	FUEL INJECTION SYSTEM
04-01	STARTER
04-02	ALTERNATOR ASSY (MODELS WITHOUT AIR CONDITIONING)
04-03	ALTERNATOR ASSY (MODELS WITH AIR CONDITIONING)
04-04	ALTERNATOR MOUNTING
04-05	BATTERY, SINGLE - CABLES
04-06	BATTERY, DUAL - CANOPY, ROPS
04-07	BATTERY, DUAL - CAB
04-08	HARNESS, ENGINE - FUSES AND RELAYS
04-09	HARNESS, ENGINE (RIGHT-HAND SIDE) - ALTERNATOR
04-10	HARNESS, ENGINE (LEFT-HAND SIDE AND REAR)
04-11	HARNESS, ENGINE AND REAR WIRE HARNESS
04-13	HARNESS, FRONT CONSOLE AND SWITCHES - CANOPY, ROPS
04-14	HARNESS, FRONT CONSOLE AND SWITCHES - CAB
04-15	HARNESS, CANOPY - HARNESS, MICROCONTROLLER
04-16	HARNESS, CAB - HARNESS, MICROCONTROLLER
04-17	CONSOLE, FRONT - CANOPY, ROPS
04-18	CONSOLE, FRONT - CAB
04-18A	INSTRUMENT CLUSTER
04-19	HARNESS, LAMP - CANOPY, ROPS
04-20	HARNESS, LAMP - CAB
04-21	ALARM, BACKUP - HORN
04-23	GRID HEATER - CABLES
04-24	GRID HEATER - SYSTEM CONTROL
04-25	WIPER, FRONT - CAB
04-26	WIPER, REAR - CAB
05-01	FRAME, TRACK - ROLLER AND RECOIL HOUSING
05-02	FRAME, TRACK - COVERS
05-03	SPROCKET, TRACK
05-04	TRACK ADJUSTER AND IDLER - MOUNTING
05-05	TRACK ADJUSTER
05-06	TRACK IDLER
05-07	TRACK ROLLER
05-08	TRACK GUARDS
05-09	TRACK CHAIN, SEALED
05-10	TRACK CHAIN, SEALED AND LUBRICATED
06-01	MOUNTING - PUMP, HYDROSTATIC TANDEM AND DRIVESHAFT
06-02	HYDROSTATICS - PUMP, TANDEM SUPPLY AND RETURN TO FILTER
06-03	HYDROSTATICS - MOTOR, DRIVE
06-04	DIAGNOSTIC LINES
06-05	MOUNTING - FINAL DRIVE
06-06	COVERS - FINAL DRIVE
06-07	FINAL DRIVE ASSY, DROP HOUSING
06-08	FINAL DRIVE ASSY, HUB
06-09	FILTER ASSY
06-10	CONTROLS, FORWARD AND REVERSE
06-11	HYDROSTATIC MOTOR
06-12	HYDROSTATIC MOTOR
06-13	PUMP ASSY - COMBINATION
06-14	PUMP ASSY - COMBINATION
07-01	BRAKES - PEDALS AND LINKAGE

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

07-02	BRAKE LINES
07-03	BRAKE, PARKING/LOCKOUT LEVERS
08-01	RESERVOIR, HYDRAULIC - COVERS
08-02	HYDRAULICS, EQUIPMENT - RESERVOIR TO PUMP AND CONTROL VALVE
08-03	HYDRAULICS, EQUIPMENT - CONTROL VALVE TO THERMAL BYPASS VALVE AND FILTER
08-04	VALVE ASSEMBLY, THERMAL BYPASS
08-05	HYDRAULICS - LIFT CIRCUIT
08-06	HYDRAULICS - TILT AND ANGLE CIRCUITS
08-07	HYDRAULICS - TILT CIRCUIT
08-08	HYDRAULICS - ANGLE CIRCUIT
08-09	HYDRAULICS - RIPPER, VALVE TO REAR OF TRACTOR
08-10	HYDRAULICS - RIPPER, REAR OF TRACTOR TO CYLINDERS
08-11	CYLINDER ASSY - LIFT
08-12	CYLINDER ASSY - TILT
08-13	CYLINDER ASSY - ANGLE
08-14	CYLINDER ASSY - RIPPER
08-15	VALVE, CONTROL - MOUNTING
08-16	CONTROLS - LEVER AND LINKAGE, THREE SPOOL VALVE
08-17	CONTROLS - LEVER AND LINKAGE, FOURTH SPOOL
08-18	VALVE, CONTROL
08-19	VALVE ASSY, RELIEF
08-20	SECTION ASSEMBLY - LIFT
08-21	SECTION ASSEMBLY - TILT, ANGLE, AND AUXILIARY
08-22	VALVE ASSY, CHECK - VALVE ASSY, ANTI-CAVITATION
08-23	VALVE ASSY, RELIEF
09-01	FRAME, LIFT - CYLINDERS, MOUNTING
09-02	DOZER BLADE - MOUNTING
09-03	BLADE, DOZER - EDGES, CUTTING
09-04	SHIELDS, DOZER HYDRAULICS
09-05	RIPPER
09-06	COUNTERWEIGHT, FRONT - HOOK, TOWING
09-07	DRAWBAR - HOOK, TOWING
09-08	FRAME, MAIN
09-09	UPPER MAIN FRAME, MOUNTING - HYDRAULIC AND FUEL TANK SEAT
09-10	DOOR, REAR - TANK, HYDRAULIC OIL
09-11	DOORS, REAR
09-12	HOOD AND SIDE PANELS
09-13	GUARD, RADIATOR BRUSH SCREEN - GRILLE, HOOD
09-14	SEAT ASSY, MECHANICAL SUSPENSION - MOUNTING
09-15	SEAT ASSY, MECHANICAL SUSPENSION
09-16	SEAT ASSY, AIR SUSPENSION - MOUNTING
09-17	SEAT ASSY, AIR SUSPENSION
09-18	CANOPY, ROPS - FRAME, MOUNTING AND GRAB HANDLES
09-19	CANOPY, ROPS - HEADLINER, FLOORMAT AND MIRROR
09-20	CANOPY, ROPS - ARMRESTS, TOOLBOX AND COVERS
09-21	CANOPY, ROPS - CONSOLES, SIDE
09-22	CANOPY, ROPS - SCREENS
09-23	CAB OR CANOPY - GUARD, BRUSH
09-24	CAB OR CANOPY - TILT COMPONENTS
09-25	CAB OR CANOPY - LAMP MOUNTING
09-26	CAB - FRAME AND MOUNTING

Order the manual at mid-west-tech.com >

CYLINDER ASSY - ANGLE

REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTION
		87432198		2	CYLINDER ASSY. 89 ID x 396 mm Stroke; Angle; Incl. Ref 1 - 21
1		87434175		1	TUBE Incl. Ref 2, 3
4		407539A1		1	BUSHING
5		103-21281		2	RING, SNAP No. 281
6		430296A1		1	ROD, PISTON 45 mm (1-3/4 inch) dia
7		407538A1		1	BUSHING
8		103-21281		2	RING, SNAP No. 281
9		355529A1		1	GLAND
10		1542875C1		1	SET OF PARTS Rod and Buffer Seal
11		238-5235		1	O-RING 3-1/8 ID x 1/8
12		D38858		1	GASKET
13		G102425		1	BUSHING, LARGE
14		D95143		1	SEAL
		190395A1			PISTON ASSY. Incl. 15 - 17
15		190332A1		1	SEAL
16		G100711		1	Ring, Wear Wear
17		1986982C1		1	PISTON
18		86642312		1	SCREW No. 8 x 3/8
19		86982437		1	BOLT, SPECIAL
21		219-1		1	NIPPLE, LUBE 1/8 PT x 21/32
		87433619		1	KIT, GASKET Incl. 10 - 16

MidWestTech | New Holland DC95 Crawler Dozer Parts Catalog | Publication 7-9311 Order the manual at mid-west-tech.com >

DOZER BLADE - MOUNTING

REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTION
1		REF		1	INSTRUCTION See Figure 09-03 For Dozer Blade Options
		87311753		1	LINK ASSY. Adjustable Link Assy; Pitch; Incl. 2 - 2B
2		NSS		1	NOT SERVICED SEPARATELY Connector
2A		87311754		1	LINK ASSY. Rod End; Left Hand Thread; Includes (1) 219-87 Grease Fitting, (1) 613524C91 Bearing
2B		87311755		1	LINK ASSY. Rod End; Right Hand Thread; Includes (1) 219-87 Grease Fitting, (1) 613524C91 Bearing
3		413-872		1	BOLT 1/2 x 4-1/2; GR5; If Used
4		896-15012		1	WASHER 13,5 x 28 x 4 mm
5		87453320		1	COVER ASSY Cover Pitch Link; Replaces 87434527
6		87311756		4	SPACER, RING Spacer
7		627-16035		1	SCREW Hex, M16 x 35, 10.9
8		627-16060		1	SCREW Hex, M16 x 60, 10.9, Use Loctite 243
9		895-30103		2	WASHER 17,5 x 56 x 5 mm
10		418981A1		1	SPACER Mounting
11		231-1448		1	NUT, LOCK 1/2
13		418868A1		1	PLATE, COVER
14		827-20080		4	SCREW M20 x 80
15		896-11020		6	WASHER 22 x 37 x 4 mm
17		405892A1		1	BUSHING
18		828-20180		1	BOLT M20 x 180
19		418828A1		1	WASHER
20		829-1420		1	NUT M20, Cl 10
21		827-20190		2	SCREW M20 x 190
22		219-1		1	NIPPLE, LUBE 1/8 PT x 21/32
23		892-11020			WASHER, LOCK 20 mm
		REF			INSTRUCTION Use Ref. 6,7,9 To Mount Fixed Link
24		87311834		1	LINK ASSY. Fixed Link Assy; Incl. 25-27
25		613524C91		2	BUSHING Bushing 1-3/4 ID
26		219-87		2	FITTING Lube Fitting 1/4-28 Taper
27		103-21281		4	RING, SNAP #281
28		104824A1		1	PIN, LARGE Includes Cable and Hair Pin; If Used
29		896-15012		1	WASHER 13,5 x 28 x 4 mm
30		627-16035		1	SCREW M16 x 35
31		627-16060		1	SCREW M16 x 60
32		895-30103		2	WASHER 17,5 x 56 x 5 mm

MidWestTech | New Holland DC95 Crawler Dozer Parts Catalog | Publication 7-9311 Order the manual at mid-west-tech.com >

SEAT ASSY, AIR SUSPENSION

REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTION
		87450940		1	SEAT ASSY. Air Suspension; Black Vinyl; Incl. Ref 1, 2, 3, 4, 5 - 21
		87450939		1	SEAT ASSY. Air Suspension; Gray Cloth; Incl. Ref 1A, 2A, 3A, 4A, 5 - 21
1		87454143		1	SEAT ACCESSORY Seat; Black Vinyl; Includes Seat and Backrest Cushion
1A		87454147		1	SEAT ACCESSORY Seat; Gray Cloth; Includes Seat and Backrest Cushion
2		87454144		1	SEAT ACCESSORY Cushion, Seat, Black Vinyl
2A		87454148		1	SEAT ACCESSORY Cushion, Seat, Gray Cloth
3		87454145		1	SEAT ACCESSORY Backrest Cushion, Black Vinyl
3A		87454149		1	SEAT ACCESSORY Backrest Cushion, Gray Cloth
4		87454146		1	SEAT ACCESSORY Backrest, Upper, Black Vinyl
4A		87454150		1	SEAT ACCESSORY Backrest, Upper, Gray Cloth
5		176091A1		1	PACKAGE, SERVICE Kit, Hog Ring; Cushion Retainer; Package Of 50; Not Illustrated
		87405470		1	SEAT ACCESSORY Cover, Back; Includes Manual Holder; Incl. 6, 7
6		NSS		1	NOT SERVICED SEPARATELY Cover, Back; Includes Manual Holder
7		1999693C1		1	KIT Clip; Package Of 12
8		1987212C1		1	PACKAGE Back Tilt Knob; Includes Knob, Handle, Screw
9		87405471		1	SEAT ACCESSORY Lever, Slide Release
10		86990111		1	SEAT ACCESSORY Slide; 6 in. Travel
11		86990112		1	SEAT ACCESSORY Slide; 6 in. Travel
12		182991A1		1	PLATE, LARGE Adapter
13		86990113		2	SEAT ACCESSORY Tether Belt
14		389085A1		1	KIT Seat Belt Mounting; Includes (2) Brackets, (3) Spacers, (1) Plate, (6) Bolts, (2) Nuts
15		86990128		1	SEAT ACCESSORY Suspension Assembly, Air; Boxed
		1344249C1		1	ROLLER ASSY. Kit, Roller Tube Bearing; Includes (4) Tube Bearings, (6) Rollers, (2) Suspension Shock Bearings, (1) 131-425 Push Nuts, (1) A45519 Plastic Washer

MidWestTech | New Holland DC95 Crawler Dozer Parts Catalog | Publication 7-9311 Order the manual at mid-west-tech.com >