PARTS CATALOG

LS190.B
LT190.B
SKID STEER

Issued 11-2004
Revised 01-2005
Revised 05-2005

7-9572 NA

NEW HOLLAND
CONSTRUCTION

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

02-01	RADIATOR - COOLANT RECOVERY SYSTEM
02-02	FAN - FAN BELT
02-03	EXHAUST SYSTEM
02-03A	MUFFLER - ASPIRATED
02-04	AIR CLEANER - ENGINE
02-05	ENGINE - MOUNTING
02-06	OIL FILL, ENGINE
02-07	ENGINE - BLOCK HEATER
02-07A	GRID HEATER
02-08	ENGINE
02-09	CYLINDER BLOCK
02-10	CYLINDER BLOCK
02-11	OIL PUMP, PAN
02-12	CYLINDER BLOCK - COVERS
02-13	CYLINDER BLOCK - COVERS
02-14	CYLINDER BLOCK - COVERS
02-15	BREATHER - ENGINE
02-16	CYLINDER HEAD
02-17	CYLINDER HEAD - COVERS
02-18	CYLINDER HEAD - VALVE MECHANISM
02-19	MANIFOLD - INTAKE
02-20	MANIFOLD - EXHAUST
02-21	CRANKSHAFT
02-22	PISTONS - CONNECTING ROD
02-23	PISTONS - CONNECTING ROD
02-24	FLYWHEEL - ENGINE
02-25	PULLEY - CRANKSHAFT
02-26	CAMSHAFT
02-27	ENGINE, OIL
02-28	OIL PUMP - ENGINE
02-29	OIL FILTERS - ENGINE
02-30	OIL FILTER AND COOLER
02-31	WATER PUMP
02-32	COOLING SYSTEM - ENGINE
02-33	THERMOSTAT - ENGINE COOLING SYSTEM
02-34	WATER PUMP - CONTROL
02-35	FAN DRIVE
02-36	POWER TAKE OFF
02-37	ENGINE - LIFT HOOK
03-01	FUEL TANK
03-02	CONTROLS - THROTTLE
03-03	FUEL INJECTION PUMP
03-04	FUEL INJECTION SYSTEM
03-05	FUEL INJECTION SYSTEM
03-06	FUEL INJECTION SYSTEM
03-07	FUEL FILTER
03-08	FUEL PUMP
03-09	FUEL INJECTION SYSTEM
03-10	FUEL INJECTION SYSTEM
04-01	STARTER MOUNTING - ALTERNATOR MOUNTING
04-01A	ALTERNATOR

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

04-02	BATTERY - CABLES
04-03	ELECTRIC, CAB
04-04	ELECTRIC, CAB - 4-WAY FLASHERS
04-05	ELECTRIC, ENGINE
04-06	ELECTRIC, MAIN
04-07	ELECTRIC, MAIN
04-08	ELECTRIC, CHASSIS
04-09	ELECTRIC, MOUNTING PLATE
04-10	BACKUP ALARM
04-11	HORN AND TURN SIGNAL
04-12	REMOTE JUMP START
04-13	ELECTRIC POWER KIT
04-14	WARNING BEACON LIGHT
06-01	PUMP, TANDEM - MOUNTING
06-01A	PUMP, TANDEM - MOUNTING (LT190.B)
06-02	HYDROSTATICS - TANDEM PUMP
06-02A	HYDROSTATICS - TANDEM PUMP (LT190.B)
06-03	HYDROSTATICS - PUMP TO MANIFOLD
06-03A	HYDROSTATICS - DRIVE MOTORS TO MANIFOLD (LT190.B)
06-04	HYDROSTATICS - TWO SPEED (LS190.B)
06-04A	HYDROSTATICS - TWO SPEED (LT190.B)
06-05	HYDROSTATICS - TWO SPEED, VALVE ASSY
06-06	PUMP, GEAR
06-07	PUMP, GEAR (HIGH FLOW)
06-08	MOTOR ASSY - SINGLE SPEED
06-09	MOTOR ASSY - SINGLE SPEED
06-10	MOTOR ASSY - SINGLE SPEED
06-11	MOTOR ASSY - TWO SPEED
06-12	MOTOR ASSY - TWO SPEED
06-13	MOTOR ASSY - TWO SPEED
06-14	PUMP, TANDEM
06-15	PUMP, TANDEM
06-16	PUMP, TANDEM
06-17	PUMP, TANDEM
06-18	PUMP, TANDEM
06-19	PUMP, TANDEM
06-20	FINAL DRIVE (LS190.B)
06-20A	FINAL DRIVE (LT190.B)
06-21	TRANSMISSION CENTERING
06-22	WHEELS
06-22A	TRACK
07-01	BRAKE SYSTEM - HYDRAULIC
08-01	CONTROL VALVE
08-02	HYDRAULICS - CONTROL VALVE
08-03	HYDRAULICS - BUCKET, STANDARD
08-04	HYDRAULICS - BUCKET, HIGH FLOW
08-05	HYDRAULICS - BOOM, STANDARD
08-06	HYDRAULICS - BOOM, HIGH FLOW
08-07	HYDRAULICS - HIGH FLOW
08-08	HYDRAULICS - HIGH FLOW
08-09	HYDRAULIC OIL COOLER - HIGH FLOW

MidWestTech | New Holland LS190.B, LT190.B Skid Steer Parts Catalog | Publication 7-95... Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

08-10	VALVE ASSY, CONTROL - HAND CONTROL
08-11	VALVE ASSY, CONTROL - FOOT CONTROL
08-11A	VALVE ASSY, CONTROL - SEAL REPLACEMENT KITS
08-12	VALVE ASSY, HIGH FLOW
08-12A	VALVE ASSY, HIGH FLOW
08-13	HYDRAULICS - MOUNTING PLATE
08-14	VALVE ASSY - MOUNTING PLATE
08-15	HYDRAULICS - MOUNTING PLATE, WITHOUT HIGH FLOW
08-16	HYDRAULICS - MOUNTING PLATE, HIGH FLOW
08-17	CYLINDER ASSY - MOUNTING PLATE
08-18	BUCKET CYLINDER
08-19	BOOM CYLINDER
08-20	FILTER AND RESERVOIR
08-21	FILTER ASSY
08-22	CONNECT UNDER PRESSURE COUPLERS
08-23	SECONDARY FRONT AUXILIARY
08-24	SECONDARY REAR AUXILIARY
08-25	SECONDARY AUXILIARY - VALVE ASSY
09-01	CHASSIS (LS190.B)
09-01A	CHASSIS (LT190.B)
09-02	PLATES, FLOOR
09-02A	FIRE EXTINGUISHER & INSIDE REAR-VIEW MIRROR
09-03	MOUNTING PLATE
09-04	BOOM
09-05	BOOM LOCK
09-05A	BOOM FLOAT KIT
09-06	BUCKETS - LOADER, DIRT / FOUNDRY
09-07	BUCKETS - LOADER, EXTENDED LOW PROFILE
09-08	BUCKETS - LOADER, UTILITY / LIGHT MATERIAL
09-09	BUCKETS - LOADER, MANURE / SLURRY
09-09A	BUCKET, CUTTING EDGE
09-09B	SPILL GUARD
09-10	PALLET FORK
09-11	FENDERS
09-11A	REAR FENDERS
09-12	CAB
09-13	THRESHOLD - REAR WINDOW
09-14	CAB - WINDOWS
09-15	CAB DOOR
09-16	CAB DOOR - WIPER
09-17	CAB DOOR
09-17A	DOOR - SWITCH ASSY
09-18	DEMOLITION DOOR
09-19	DOOR, REAR
09-20	REAR HOOD
09-21	CAB HEADLINER
09-22	HEADLINER, CAB HEATER
09-23	HEATER SYSTEM
09-24	CAB HEATER
09-25	HEATER AND AIR CONDITIONING
09-26	COMPRESSOR - CONDENSER, MODELS WITH AIR CONDITIONING

MidWestTech | New Holland LS190.B, LT190.B Skid Steer Parts Catalog | Publication 7-95... Order the manual at mid-west-tech.com >