CX80
Excavator

Parts Catalog

7-9610

CASE CONSTRUCTION

MidWestTech | Case CX80 Excavator Parts Catalog | Publication 7-9610na

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

02-01	ENGINE MOUNTING
02-02	AIR CLEANER
02-03	AIR CLEANER ASSY
02-04	EXHAUST SYSTEM - MUFFLER
02-05	RADIATOR AND CONNECTIONS
02-06	RADIATOR AND CONNECTIONS
02-06A	RADIATOR ASSY
02-07	CYLINDER HEAD COVER
02-08	CYLINDER HEAD
02-09	CYLINDER BLOCK
02-10	OIL PAN
02-11	CAMSHAFT - VALVE MECHANISM
02-12	PISTONS AND CRANKSHAFT - FLYWHEEL
02-13	FRONT GEAR COVER - FLYWHEEL HOUSING
02-14	MANIFOLD - INTAKE
02-15	MANIFOLD - EXHAUST
02-16	CYLINDER HEAD - BREATHER
02-17	WATER PUMP SYSTEM
02-18	THERMOSTAT AND HOUSING
02-19	WATER CIRCUIT
02-20	FAN DRIVE
02-21	OIL PUMP
02-22	OIL CIRCUIT
02-23	OIL FILTER
03-01	FUEL TANK
03-02	FUEL LINES
03-03	FUEL LINES
03-04	WATER SEPARATOR ASSY
03-05	ENGINE SHUTOFF
03-06	FUEL INJECTION PUMP AND DRIVE
03-07	FUEL INJECTION SYSTEM
03-08	FUEL INJECTION - NOZZLE
03-09	COUPLING, FUEL INJECTION PUMP
03-10	FUEL INJECTION PUMP - DRIVE
03-11	FUEL FILTER - SUPPORT
03-12	PUMP - FUEL SYSTEM
04-01	HARNESS, MAIN - CHASSIS, UPPERSTRUCTURE
04-02	HARNESS, MAIN - CHASSIS, UPPERSTRUCTURE
04-03	HARNESS, MAIN - CHASSIS, UPPERSTRUCTURE
04-04	ELECTRICAL - CAB
04-05	ELECTRICAL - CAB
04-06	ELECTRICAL - CAB
04-07	MONITOR ASSY
04-08	RADIO
04-09	RADIO (AUSTRALIA)
04-10	HORN
04-11	LAMP, WORK - CAB
04-12	LAMP, WORK - STANDARD BOOM
04-13	LAMP, WORK - ELECTRICAL PARTS
04-14	WINDSHIELD WASHER
04-15	BATTERIES

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

04-16	ELECTRICAL ACCESSORIES - ENGINE
04-17	ALTERNATOR ASSY
04-18	TRAVEL ALARM
04-19	ELECTRICAL PARTS - MODELS WITH LOAD HOLD
05-01	UNDERCARRIAGE
05-02	GUIDE, CHAIN
05-03	UNDERCARRIAGE COVER, LOWER
05-04	TRACK CHAINS - STEEL (450 MM - 600 MM)
05-05	TRACK CHAINS - RUBBER (450 MM)
05-06	TRACK - IDLER
05-07	CYLINDER ASSY - ADJUSTER
05-08	TRACK - ROLLER, UPPER
05-09	TRACK - ROLLER, LOWER
06-01	TRACK DRIVE ASSY
06-02	MOTOR ASSY - GEAR ASSY, REDUCTION
06-03	MOTOR ASSY - TRAVEL, INLET AND OUTLET
06-04	VALVE ASSY, RELIEF - MOTOR, HYDRAULIC
06-05	HYDRAULICS - TRACK DRIVE
08-01	HYDRAULIC RESERVOIR
08-02	PUMP ASSY, HYDRAULIC - COUPLING
08-03	HYDRAULICS - PUMP SUCTION LINE
08-04	HYDRAULICS - CONTROL VALVE SUPPLY
08-05	HYDRAULICS - CONTROL VALVE SUPPLY
08-06	HYDRAULICS - RESERVOIR RETURN
08-07	HYDRAULICS - RESERVOIR RETURN
08-08	HYDRAULICS - RESERVOIR RETURN
08-09	HYDRAULICS - BYPASS FILTER
08-10	HYDRAULICS - BYPASS FILTER
08-11	HYDRAULICS - DRAIN LINE, SINGLE ACTING CIRCUIT
08-12	HYDRAULICS - DRAIN LINE, SINGLE ACTING CIRCUIT
08-13	HYDRAULICS - DRAIN LINE, MULTI-PURPOSE + 3 WAY VALVE
08-14	HYDRAULICS - DRAIN LINE, MULTI-PURPOSE + 3 WAY VALVE
08-15	HYDRAULICS - DRAIN LINE, STANDARD AND DOUBLE ACTING CIRCUIT
08-16	HYDRAULICS - DRAIN LINE, STANDARD AND DOUBLE ACTING CIRCUIT
08-17	HYDRAULICS - TRAVEL
08-18	HYDRAULICS - SWING
08-19	HYDRAULICS - BOOM
08-20	HYDRAULICS - BOOM, DOUBLE ACTING CIRCUIT
08-21	HYDRAULICS - BOOM SWING
08-22	HYDRAULICS - BOOM SWING CYLINDER LINE
08-23	HYDRAULICS - BOOM CYLINDER LINE, MODELS WITH LOAD HOLD
08-24	HYDRAULICS - ARM AND BUCKET
08-25	HYDRAULICS - ARM AND BUCKET
08-26	HYDRAULICS - ARM CYLINDER, MODELS WITHOUT LOAD HOLD
08-27	HYDRAULICS - ARM CYLINDER, MODELS WITH LOAD HOLD
08-28	HYDRAULICS - BUCKET, 1,7 METER (5 FT 7 IN) STANDARD ARM
08-29	HYDRAULICS - BUCKET, 2,1 METER (6 FT 11 IN) STANDARD ARM
08-30	HYDRAULICS - BLADE, DOZER
08-31	HYDRAULICS - BLADE CYLINDER LINE, MODELS WITHOUT LOAD HOLD
08-32	HYDRAULICS - BLADE CYLINDER LINE, MODELS WITH LOAD HOLD
08-33	PILOT CONTROL LINES - STANDARD, MODELS WITHOUT LOAD HOLD

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

08-34	PILOT CONTROL LINES - STANDARD, MODELS WITHOUT LOAD HOLD
08-35	PILOT CONTROL LINES - STANDARD, MODELS WITHOUT LOAD HOLD
08-36	PILOT CONTROL LINES - STANDARD, MODELS WITHOUT LOAD HOLD
08-37	PILOT CONTROL LINES - STANDARD, MODELS WITHOUT LOAD HOLD
08-38	PILOT CONTROL LINES - MODELS WITH CONTROL SELECTOR VALVE
08-39	PILOT CONTROL LINES - MODELS WITH CONTROL SELECTOR VALVE
08-40	PILOT CONTROL LINES - MODELS WITH CONTROL SELECTOR VALVE
08-41	PILOT CONTROL LINES - MODELS WITH CONTROL SELECTOR VALVE
08-42	PILOT CONTROL LINES - MODELS WITH CONTROL SELECTOR VALVE
08-43	PILOT CONTROL LINES - MODELS WITH LOAD HOLD
08-44	PILOT CONTROL LINES - MODELS WITH LOAD HOLD
08-45	HYDRAULICS - PILOT PRESSURE, RETURN LINES
08-46	HYDRAULICS - PILOT PRESSURE, RETURN LINES
08-47	HYDRAULICS - PILOT PRESSURE, RETURN LINES
08-48	HYDRAULICS - PILOT PRESSURE, RETURN LINES
08-49	HYDRAULICS, AUXILIARY - SINGLE ACTING CIRCUIT
08-50	HYDRAULICS, AUXILIARY - SINGLE ACTING CIRCUIT
08-51	HYDRAULICS, AUXILIARY - MULTI-PURPOSE + 3 WAY VALVE
08-52	HYDRAULICS, AUXILIARY - MULTI-PURPOSE + 3 WAY VALVE
08-53	HYDRAULICS, AUXILIARY - MULTI-PURPOSE + 3 WAY VALVE
08-54	HYDRAULICS, AUXILIARY - DOUBLE ACTING CIRCUIT
08-55	HYDRAULICS, AUXILIARY - DOUBLE ACTING CIRCUIT
08-56	HYDRAULICS, AUXILIARY ATTACHMENT - 1,70 M (5 FT 7 IN) ARM
08-57	HYDRAULICS, AUXILIARY ATTACHMENT - 2,10 M (6 FT 11 IN) ARM
08-58	PUMP ASSY, HYDRAULIC - PISTON
08-59	PUMP ASSY, HYDRAULIC - DRIVE
08-60	PUMP ASSY, HYDRAULIC - REGULATOR
08-61	PUMP ASSY, HYDRAULIC - REGULATOR
08-62	PUMP ASSY, HYDRAULIC - GEAR PUMP DRIVE
08-63	MOUNTING - SWING MOTOR
08-64	GEAR ASSY, REDUCTION - MOTOR, SWING
08-65	MOTOR ASSY - SWING
08-66	MOTOR ASSY, SWING - VALVE ASSY, RELIEF
08-67	HYDRAULICS - JOINT, SWIVEL CENTER
08-68	CONTROL VALVE - SUPPORT
08-69	CONTROL VALVE - VALVE, PORT RELIEF
08-70	VALVE ASSY, DIRECTIONAL
08-71	VALVE ASSY - HAND CONTROL
08-72	VALVE ASSY, REMOTE CONTROL - DOZER BLADE
08-72A	VALVE ASSY, REMOTE CONTROL - BOOM SWING
08-73	VALVE ASSY - PEDAL CONTROL
08-74	VALVE ASSY - PEDAL CONTROL, OPTIONAL
08-75	VALVE ASSY - AUXILIARY CONTROL
08-76	VALVE, SOLENOID
08-77	VALVE, SOLENOID - PILOT PRESSURE, RETURN LINES
08-78	VALVE ASSY - PILOT CONTROL LINES
08-79	VALVE ASSY - PILOT CONTROL LINES
08-80	VALVE, PILOT - PILOT CONTROL LINES
08-81	CYLINDER ASSY, STANDARD BOOM - MODELS WITHOUT LOAD HOLD
08-82	CYLINDER ASSY, STANDARD BOOM - MODELS WITH LOAD HOLD
08-83	CYLINDER ASSY, STANDARD ARM - MODELS WITHOUT LOAD HOLD

Order the manual at mid-west-tech.com >

PISTONS AND CRANKSHAFT - FLYWHEEL

REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTION
1		86990171		1	CRANKSHAFT CRANKSHAFT
10		86990172		5	BEARING, CRANKSHAFT Blue
10		86990173		5	BEARING, CRANKSHAFT Black
10		86990174		5	BEARING, CRANKSHAFT Green
12		86990064		1	FLYWHEEL Incl. 35
21		355117A1		1	SCREW
28		355097A1		1	GEAR
31		86990175		1	KEY
35		353953A1		1	GEAR
38		355113A1		1	PLATE
40		355114A1		8	SCREW
42		86990176		2	RING SET, PISTON
56		87405527		1	PULLEY
59		355119A1		1	WASHER
63		86990178		4	PISTON ASSY
68		86990179		4	RING SET, PISTON
73		362174A1		4	BEARING SET
83		86990180		4	PIN
84		86990065		4	ROD, CONNECTING Incl. 85 - 87
85		86990182		1	BUSHING
86		86990183		2	BOLT M11 x 44.5
87		86990184		2	NUT
126		86990181		8	RING

MidWestTech | Case CX80 Excavator Parts Catalog | Publication 7-9610na Order the manual at mid-west-tech.com >

FUEL INJECTION - NOZZLE

REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTION
32		355445A1		4	NOZZLE INJECTION Incl. 35 - 140
33		86990188		1	NOZZLE
35		355417A1		1	NUT
43		355418A1		1	SEAT, SPRING
44		355419A1		1	SPRING
46		355420A1		2	DOWEL
47		355421A1		1	SPACER
140		355422A1		X	SHIM 0,540 mm (0,0213 in)
140		355424A1		X	SHIM 0,550 mm (0,0217 in)
140		355427A1		X	SHIM 0,200 mm (0,0079 in)
140		355429A1		X	SHIM 0,560 mm (0,0220 in)
140		355430A1		X	SHIM 0,570 mm (0,0224 in)
140		355431A1		X	SHIM 0,590 mm (0,0232 in)
140		355432A1		X	SHIM 0,530 mm (0,0209 in)
140		355433A1		X	SHIM 0,580 mm (0,0228 in)
140		355434A1		X	SHIM 0,510 mm (0,0201 in)
140		355435A1		X	SHIM 0,500 mm (0,0197 in)
140		355436A1		X	SHIM 0,300 mm (0,0118 in)
140		355437A1		X	SHIM 0,400 mm (0,0157 in)
140		355438A1		X	SHIM 0,100 mm (0,0039 in)
140		355439A1		X	SHIM 0,520 mm (0,0205 in)
140		362202A1		X	SHIM 0,600 mm (0,0236 in)

MidWestTech | Case CX80 Excavator Parts Catalog | Publication 7-9610na Order the manual at mid-west-tech.com >

HYDRAULICS, AUXILIARY - MULTI-PURPOSE + 3 WAY VALVE

REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTION
71		154467A1		1	O-RING
72		161841A1		1	NIPPLE, LUBE
73		150933A1		2	ELBOW Incl. 74
74		154467A1		1	O-RING
76		KHJ2237		1	HOSE ASSY.
77		KHJ2044		1	HOSE ASSY.
78		152127A1		2	ADAPTER Incl. 78
79		154467A1		1	O-RING
80		KHJ1655		1	VALVE BLOCK
81		KAJ4715		1	BRACKET
82		827-8060		2	SCREW
83		153081A1		2	WASHER
84		166346A1		2	BOLT
85		150821A1		1	PLUG
86		152127A1		2	ADAPTER Incl. 87
87		154467A1		1	O-RING
89		KHJ2063		1	HOSE ASSY. See Figure 08-52
90		KHJ2067		1	HOSE ASSY. See Figure 08-52
91		KHJ2069		1	HOSE See Figure 08-52
94		152127A1		1	ADAPTER Incl. 95
95		154467A1		1	O-RING
96		KHJ2042		1	HOSE ASSY.
97		150913A1		1	ELBOW Incl. 98
98		154467A1		1	O-RING
99		KHJ1714		1	VALVE, SOLENOID See Figure 08-76
100		627-6016		2	SCREW M6 x 16; 10.9
101		183-106VR		2	WASHER, SPRING
102		150933A1		1	ELBOW Incl. 103
103		154467A1		1	O-RING
104		152127A1		1	ADAPTER Incl. 105
105		154467A1		1	O-RING
106		KHJ2238		1	HOSE
113		KAR1434		1	HARNESS, WIRE See Figure 08-51

MidWestTech | Case CX80 Excavator Parts Catalog | Publication 7-9610na Order the manual at mid-west-tech.com >