750K Series 2 Crawler

Parts Catalog

7-9661 NA

Issued 11-2005

CASE CONSTRUCTION

MidWestTech | Case 750K Series 2 Crawler Parts Catalog | Publication 7-9661na

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

02-01	ENGINE - MOUNTING
02-02	FAN - FAN BELT
02-03	RADIATOR - MOUNTING
02-04	RADIATOR ASSY
02-05	COOLANT RECOVERY SYSTEM
02-06	AIR CLEANER - MOUNTING
02-07	AIR CLEANER ASSY
02-08	MUFFLER - EXHAUST SYSTEM
02-09	ENGINE
02-10	CYLINDER BLOCK
02-11	CYLINDER BLOCK
02-12	OIL PUMP, PAN
02-13	GEAR COVER - REAR HOUSING
02-14	CYLINDER BLOCK - COVERS
02-15	FLYWHEEL HOUSING
02-16	BREATHER - ENGINE
02-17	CYLINDER HEAD
02-18	CYLINDER HEAD - COVERS
02-19	CYLINDER HEAD - VALVE MECHANISM
02-20	MANIFOLD - INTAKE
02-21	MANIFOLD - EXHAUST
02-22	CRANKSHAFT
02-23	PISTONS - CONNECTING ROD
02-24	PISTONS - CONNECTING ROD
02-25	FLYWHEEL - ENGINE
02-26	PULLEY - CRANKSHAFT
02-27	DYNAMIC BALANCER, GEARS & SHAFTS
02-28	CAMSHAFT
02-29	TURBOCHARGER
02-30	ENGINE, OIL
02-31	OIL PUMP - ENGINE
02-32	OIL FILTERS - ENGINE
02-33	PIPING - ENGINE OIL
02-34	OIL FILTER AND COOLER
02-35	WATER PUMP
02-36	COOLING SYSTEM - ENGINE
02-37	THERMOSTAT - ENGINE COOLING SYSTEM
02-38	WATER PUMP - CONTROL
02-39	FAN DRIVE
02-40	POWER TAKE-OFF
02-41	ENGINE - LIFT HOOK
03-01	CONTROLS, THROTTLE - CABLE AND HAND LEVER
03-02	CONTROLS, THROTTLE - DECELERATOR PEDAL AND CROSS SHAFT
03-03	CONTROLS, THROTTLE - LINKAGE AT ENGINE
03-04	FUEL TANK
03-05	FUEL LINES
03-06	FUEL INJECTION PUMP
03-07	FUEL INJECTION SYSTEM
03-08	FUEL INJECTION SYSTEM
03-09	FUEL INJECTION SYSTEM
03-10	FUEL FILTER
03-11	FUEL PUMP

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

03-12	FUEL INJECTION SYSTEM
03-13	FUEL INJECTION SYSTEM
04-01	STARTER
04-02	ALTERNATOR ASSY (MODELS WITHOUT AIR CONDITIONING)
04-03	ALTERNATOR ASSY (MODELS WITH AIR CONDITIONING)
04-04	ALTERNATOR MOUNTING
04-05	BATTERY, SINGLE - CABLES
04-06	BATTERY, DUAL - CANOPY, ROPS
04-07	BATTERY, DUAL - CAB
04-08	HARNESS, ENGINE - FUSES AND RELAYS
04-09	HARNESS, ENGINE (RIGHT-HAND SIDE) - ALTERNATOR
04-10	HARNESS, ENGINE (LEFT-HAND SIDE AND REAR)
04-11	HARNESS, ENGINE AND REAR WIRE HARNESS
04-13	HARNESS, FRONT CONSOLE AND SWITCHES - CANOPY, ROPS
04-14	HARNESS, FRONT CONSOLE AND SWITCHES - CAB
04-15	HARNESS, CANOPY - HARNESS, MICROCONTROLLER
04-16	HARNESS, CAB - HARNESS, MICROCONTROLLER
04-17	CONSOLE, FRONT - CANOPY, ROPS
04-18	CONSOLE, FRONT - CAB
04-19	INSTRUMENT CLUSTER
04-20	LAMPS, ROPS CAB
04-21	LAMPS, ROPS CANOPY
04-22	ALARM, BACKUP - HORN
04-23	GRID HEATER - CABLES
04-24	GRID HEATER - SYSTEM CONTROL
04-25	WIPER, FRONT - CAB
04-26	WIPER, REAR - CAB
05-01	FRAME, TRACK - ROLLER AND RECOIL HOUSING
05-02	FRAME, TRACK - COVERS
05-03	SPROCKET, TRACK
05-04	TRACK ADJUSTER AND IDLER - MOUNTING
05-05	TRACK ADJUSTER
05-06	TRACK IDLER
05-07	TRACK ROLLER
05-08	TRACK GUARDS
05-09	TRACK CHAIN, SEALED
05-10	TRACK CHAIN, CASE LUBRICATED
05-11	TRACK CHAIN, EXTENDED LIFE
06-01	MOUNTING - PUMP, HYDROSTATIC TANDEM AND DRIVESHAFT
06-02	HYDROSTATICS - PUMP, TANDEM SUPPLY AND RETURN TO FILTER
06-03	HYDROSTATICS - MOTOR, DRIVE
06-04	DIAGNOSTIC LINES
06-05	MOUNTING - FINAL DRIVE
06-06	COVERS - FINAL DRIVE
06-07	FINAL DRIVE ASSY, DROP HOUSING
06-08	FINAL DRIVE ASSY, HUB
06-09	FILTER ASSY
06-10	CONTROLS, FORWARD AND REVERSE
06-11	HYDROSTATIC MOTOR
06-12	HYDROSTATIC MOTOR
06-13	PUMP ASSY - COMBINATION
06-14	PUMP ASSY - COMBINATION

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

07-01	BRAKES - PEDALS AND LINKAGE
07-02	BRAKE LINES
07-03	BRAKE, PARKING/LOCKOUT LEVERS
08-01	RESERVOIR, HYDRAULIC - COVERS
08-02	HYDRAULICS, EQUIPMENT - RESERVOIR TO PUMP AND CONTROL VALVE
08-03	HYDRAULICS, EQUIPMENT - CONTROL VALVE TO THERMAL BYPASS VALVE AND FILTER
08-04	VALVE ASSEMBLY, THERMAL BYPASS
08-05	HYDRAULICS - LIFT CIRCUIT
08-06	HYDRAULICS - TILT AND ANGLE CIRCUITS
08-07	HYDRAULICS - TILT CIRCUIT
08-08	HYDRAULICS - ANGLE CIRCUIT
08-09	HYDRAULICS - RIPPER, VALVE TO REAR OF TRACTOR
08-10	HYDRAULICS - RIPPER, REAR OF TRACTOR TO CYLINDERS
08-11	CYLINDER ASSY - LIFT
08-12	CYLINDER ASSY - TILT
08-13	CYLINDER ASSY - ANGLE
08-14	CYLINDER ASSY - RIPPER
08-15	VALVE, CONTROL - MOUNTING
08-16	CONTROLS - LEVER AND LINKAGE, THREE SPOOL VALVE
08-17	CONTROLS - LEVER AND LINKAGE, FOURTH SPOOL
08-18	VALVE, CONTROL
08-19	VALVE ASSY, RELIEF
08-20	SECTION ASSEMBLY - LIFT
08-21	SECTION ASSEMBLY - TILT, ANGLE, AND AUXILIARY
08-22	VALVE ASSY, CHECK - VALVE ASSY, ANTI-CAVITATION
08-23	VALVE ASSY, RELIEF
09-01	FRAME, LIFT - CYLINDERS, MOUNTING
09-02	DOZER BLADE - MOUNTING
09-03	BLADE, DOZER - EDGES, CUTTING
09-04	SHIELDS, DOZER HYDRAULICS
09-05	RIPPER
09-06	COUNTERWEIGHT, FRONT - HOOK, TOWING
09-07	DRAWBAR - HOOK, TOWING
09-08	FRAME, MAIN
09-09	MOUNTING - FUEL TANK/HYDRAULIC RESERVOIR
09-10	DOOR, REAR - TANK, HYDRAULIC OIL
09-11	DOORS, REAR
09-12	HOOD AND SIDE PANELS
09-13	GUARD, RADIATOR BRUSH SCREEN - GRILLE, HOOD
09-14	SEAT ASSY, MECHANICAL SUSPENSION - MOUNTING
09-15	SEAT ASSY, MECHANICAL SUSPENSION
09-16	SEAT ASSY, AIR SUSPENSION - MOUNTING
09-17	SEAT ASSY, AIR SUSPENSION
09-18	CANOPY, ROPS - FRAME, MOUNTING AND GRAB HANDLES
09-19	CANOPY, ROPS - HEADLINER, FLOORMAT AND MIRROR
09-20	CANOPY, ROPS - ARMRESTS, TOOLBOX AND COVERS
09-21	CANOPY, ROPS - CONSOLES, SIDE
09-22	CANOPY, ROPS - GUARD, BRUSH
09-23	CANOPY, ROPS - SCREENS
09-24	CAB OR CANOPY - TILT COMPONENTS
09-25	CAB - FRAME AND MOUNTING

Order the manual at mid-west-tech.com >

LAMPS, ROPS CAB

REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTION
		REF			INSTRUCTION CAB WORK LIGHTS WITHOUT SWEEPS; Use Ref 1 - 7
		REF			INSTRUCTION CAB WORK LIGHTS WITH SWEEPS; Use Ref 1 - 4, 7
1		398847A3		3-6	LIGHT ASSY. 12V, 55W; Front and Rear Flood and Work Lamps; Incl. 1312210C2 Lamp and 276498A1 Lens; Two Wire Connector, Pin/Recepticle; Used With 87410145 Cab Lamp Harness, Ref 8; If Used
		1312210C2		1	BULB 12V, 55W Lamp
		276498A1		1	LENS With Hardened Glass
1A		87317577		3-6	LIGHT ASSY. 12V, 55W; Front and Rear Flood and Work Lamps; Incl. 1312210C2 Lamp; Single Wire Connector, Round Socket; Used With 87438394 Cab Lamp Harness, Ref 8A; If Used
2		87455059		2	BRACKET Light Mount
3		895-15010		3-6	WASHER 11 x 24 x 2mm
4		614-10016		3-6	SCREW M10 x 16; Replaces 614-10020 M10 x 20 Bolt Used On Some Models
5		896-11016		4	WASHER 17.5 x 30 x 4mm
6		627-16040		4	SCREW Hex, M16 x 40; Replaces 627-16035 M16 x 35 Bolt Used On Some Models
7		L18331		4	STRAP
8		87410145		1	HARNESS, WIRE Cab Lamps; Used With 398847A3 Lamps, Ref 1; If Used
8A		(87438394)		1	Cab Lamps; Used With 87317577 Lamps, Ref 1A; If Used

MidWestTech | Case 750K Series 2 Crawler Parts Catalog | Publication 7-9661na Order the manual at mid-west-tech.com >

TRACK CHAIN, EXTENDED LIFE

REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTION
		REF			INSTRUCTION EACH MASTER LINK HAS TWO BOLT HOLES
		418604A1		2	TRACK ASSY, CRAWLER 457 mm (18 inch); Chain; Incl. Shoes; Incl. 407020A1, Ref 1 - 18; 19, 20, 21
		87404009		2	TRACK ASSY, CRAWLER 508 mm (20 inch); Chain; Incl. Shoes; Incl. 407020A1, Ref 1 - 18; 19A, 20, 21
		418607A1		2	TRACK ASSY, CRAWLER 610 mm (24 inch); Chain; Incl. Shoes; Incl. 407020A1, Ref 1 - 18; 19B, 20, 21
		418611A1		2	TRACK ASSY, CRAWLER 711 mm (28 inch); Chain; Incl. Shoes; Incl. 407020A1, Ref 1 - 18; 19C, 20, 21
		407020A1		1	CHAIN, TRACK Incl. Ref 1 - 18; Order 418499A1, Ref 30
1		295178A2		38	LINK Right-Hand
2		295177A2		38	LINK Left-Hand
3		114402A1		39	BUSHING 54mm (2-1/8 in) OD
4		323875A1		39	BUSHING
5		R51131		39	PIN, LARGE
6		R51132		78	SPACER
7		R50830		78	SEAL
8		R50441		39	PLUG
		299237A1		1	KIT Master Link; Right-Hand; Incl. Ref 9 - 13
		NSS		1	NOT SERVICED SEPARATELY Link Assy; Master; Right-Hand; Incl. Ref 9, 10
9		NSS		1	NOT SERVICED SEPARATELY Link; Fits Over Track Pin On Outside Of Regular Track Link
10		NSS		1	NOT SERVICED SEPARATELY Link; Fits Over Bushing On Inside Of Regular Track Link
11		295325A1		2	BOLT 5/8 NF x 3-1/4
13		178328A3		1	TAG Installation Instructions
		299234A1		1	KIT Master Link; Left-Hand; Incl. Ref 14 - 18
		NSS		1	NOT SERVICED SEPARATELY Link Assy; Master; Left-Hand; Incl. Ref 14, 15
14		NSS		1	NOT SERVICED SEPARATELY Link; Fits Over Track Pin On Outside Of Regular Track Link; Not Illustrated

MidWestTech | Case 750K Series 2 Crawler Parts Catalog | Publication 7-9661na

Order the manual at mid-west-tech.com >

HOOD AND SIDE PANELS

REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTION
1		87446374		1	PLATE, COVER
2		87355874		1	DOOR ASSY. Right-Hand; Incl. Ref 4, 5; Replaces 87421310
3		87355875		1	DOOR ASSY. Left-Hand; Incl. Ref 4, 5; Replaces 87421307
4		R56221		1	LATCH LOCK; Tri/Mark Vendor Part Number 12166-16; Used With 87421310, 87421307 Doors
4		87353954		1	LATCH LOCK; Tri/Mark Vendor Part Number 18530; Heavy Duty; Used With 87355874, 87355875 Doors
5		151-567		4	RIVET 1/4 x 5/8
6		430363A2		2	PLATE, COVER Incl. Ref 7
7		A161780		3	BUMPER
8		449674A1		4	SEAL
9		418479A2		4	PIN
10		832-10412		4	NUT M12
11		431707A3		1	HINGE Left-Hand
12		431708A3		1	HINGE Right-Hand
13		811-12040		4	SCREW M12 x 40
14		896-11012		4	WASHER 13,5 x 24 x 3 mm
15		832-10412		4	NUT M12
16		627-12030		4	BOLT M12 x 30
17		896-11012		4	WASHER 13,5 x 24 x 3 mm
18		346104A1		2-4	MOUNTING PARTS Bumper; 75.13 mm (3 in) Long; Upper and Lower; Some Models Use Two Upper and Two of 87330642 Lower
18		87330642		2	BUMPER 59.8 mm (2-3/8 in) Long; Replaces Two 346104A1 75.13 mm (3 in) Long Lower Bumpers Used On Some Models
19		425-115		4	NUT 5/16
20		419392A2		2	PLATE, RETAINING
21		627-6020		4	BOLT M6 x 20
22		896-11006		AR	WASHER 6,6 x 12,5 x 2 mm
23		R29799		2	SHOCK ABSORBER
24		R40262		2	WASHER
25		811-12050		2	BOLT M12 x 50
26		832-10412		2	NUT M12
27		87403801		2	SPRING If Used

MidWestTech | Case 750K Series 2 Crawler Parts Catalog | Publication 7-9661na Order the manual at mid-west-tech.com >