CASE

PROFESSIONAL PARTNER

PARTS CATALOG
SKID STEER

420
420CT

7-9712 NA

Revised 01-2006
Issued 02-2006

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

02-01	RADIATOR - COOLANT RECOVERY SYSTEM
02-02	FAN MOUNTING
02-03	EXHAUST SYSTEM
02-03A	EXHAUST SYSTEM, IF USED (SEE REF 16, 17)
02-03B	EXHAUST SYSTEM, ASPIRATOR
02-04	AIR CLEANER - ENGINE
02-05	ENGINE - MOUNTING
02-06	OIL FILL, ENGINE
02-07	CYLINDER BLOCK - OIL FILTER
02-08	CYLINDER HEAD
02-08A	ENGINE - BLOCK HEATER
02-09	VALVE COVER & CRANKSHAFT PULLEY
02-10	ROCKER ARMS
02-11	CAMSHAFT
02-12	CRANKSHAFT & PISTONS
02-13	INTAKE MANIFOLD
02-14	TURBOCHARGER
02-15	TIMING GEAR CASE, GOVERNOR
02-16	OIL PAN
02-17	OIL PUMP & SUCTION FILTER
02-18	WATER PUMP
02-19	FLYWHEEL, BELL HOUSING
03-01	FUEL LINES- FILTER, PUMP
03-02	CONTROLS - THROTTLE
03-02A	CONTROLS - THROTTLE, FOOT
03-03	FUEL INJECTION SYSTEM
03-04	INJECTOR
04-01	STARTER
04-02	ALTERNATOR ASSY
04-03	ALTERNATOR MOUNTING
04-04	BATTERY - CABLES
04-05	ENGINE, ELECTRICAL
04-05A	ENGINE, ELECTRICAL
04-06	HARNESS, CHASSIS
04-07	HARNESS - CAB
04-08	FUSES AND RELAYS
04-09	OPTIONS, ELECTRICAL
04-10	OPTIONS, ELECTRICAL - MOUNTING
04-11	HARNESS, FRONT - AUXILIARY
04-12	CONTROLS, RIGHT HAND - HANDLE
04-13	CONTROLS, LEFT HAND - HANDLE
04-14	DISCONNECT SWITCH - REMOTE JUMP START
04-15	HORN - MOUNTING
04-16	BACKUP ALARM
04-17	BEACON, ROTATING
04-18	ELECTRICAL ACCESSORIES SOCKET - EUROPE
04-18A	ELECTRICAL ACCESSORIES SOCKET - NORTH AMERICA
04-19	ROAD LIGHTS AND MOUNTING - EUROPE
04-20	SPECIAL PARTS FOR ITALY - LICENSE PLATE LIGHT
04-21	LOCK, LOADER DISCONNECT - EUROPE
04-22	SPECIAL PARTS FOR ITALY - BRAKE LIGHT HARNESS
06-01	OIL COOLER - MOUNTING

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

06-02	OIL COOLER ASSY - HIGH FLOW
06-02A	OIL COOLER - HIGH FLOW
06-03	HYDROSTATICS - CASE DRAIN
06-04	HYDROSTATICS - PUMP, SUPPLY AND RETURN (420)
06-04A	HYDROSTATICS - PUMP, SUPPLY AND RETURN (420CT)
06-05	HYDROSTATICS - DRIVE MOTORS (420)
06-05A	HYDROSTATICS - BRAKE VALVE (420CT)
06-06	FILTER ASSY - MOUNTING
06-07	PUMP, TANDEM - MOUNTING (420)
06-07A	PUMP, TANDEM - MOUNTING, EUROPEAN NOISE CONTROL; IF USED (420)
06-07B	HYDROSTATICS - PUMP AND SUPPLY LINES (420CT)
06-08	MOTOR - MOUNTING (420)
06-08A	MOTOR - MOUNTING (420CT)
06-09	PUMP, GEAR (WITHOUT HIGH FLOW)
06-10	PUMP, TANDEM
06-11	PUMP, TANDEM
06-12	PUMP, TANDEM
06-13	PUMP, TANDEM
06-14	PUMP, TANDEM
06-15	PUMP, TANDEM
06-16	MOTOR ASSY - REXROTH
06-16A	MOTOR ASSY - REXROTH
06-16B	MOTOR ASSY - REXROTH
06-17	MOTOR ASSY - EATON
06-17A	MOTOR ASSY, BRAKE - EATON
06-18	DRIVE LINE
06-19	AXLE ASSY
06-20	WHEELS
06-21	TRACK - STEEL (420)
06-22	FINAL DRIVE (420CT)
06-23	TRACK (420CT)
07-01	BRAKE SYSTEM - HYDRAULIC
08-01	HYDRAULICS - LIFT
08-02	HYDRAULICS - TILT
08-03	HYDRAULICS - AUXILIARY
08-04	HYDRAULICS - SELF-LEVELING
08-05	HYDRAULICS - RIDE CONTROL
08-06	HYDRAULICS - COUPLER SYSTEM
08-07	HYDRAULICS - COUPLER SYSTEM
08-08	HYDRAULICS, ATTACHMENT
08-09	VALVE ASSY, CONTROL - LOADER
08-10	VALVE ASSY, CONTROL
08-11	VALVE ASSY, CONTROL - SEAL REPLACEMENT KITS
08-12	CYLINDER - TILT (87438183)
08-12A	CYLINDER - TILT (87461812)
08-13	CYLINDER - LIFT
08-14	SECONDARY FRONT AUXILIARY
08-15	SECONDARY FRONT AUXILIARY
08-16	SECONDARY FRONT AUXILIARY - VALVE ASSY
08-17	HIGH FLOW, SUPPLY AND RETURN (420)
08-17A	HIGH FLOW, SUPPLY AND RETURN (420CT)
08-18	HIGH FLOW - AUXILIARY SYSTEM

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

08-19	HIGH FLOW, CONTROL VALVE
08-20	VALVE ASSY, CONTROL - HIGH FLOW
09-01	LOADER LIFT
09-02	LIFT CYLINDER - COVERS
09-03	COUPLER, MECHANICAL
09-03A	COUPLER, MECHANICAL (ITALIAN)
09-04	COUPLER, HYDRAULIC
09-04A	COUPLER, HYDRAULIC (ITALIAN)
09-05	BUCKETS - LOADER, DIRT / FOUNDRY
09-06	BUCKETS - LOADER, LOW PROFILE, EXTENDED LOW PROFILE
09-07	BUCKETS - LOADER, UTILITY / LIGHT MATERIAL
09-07B	BUCKETS - LOADER (HEAVY DUTY)
09-08	PALLET FORK
09-09	BUCKET, CUTTING EDGE (BOLT-ON CUTTING EDGE)
09-10	CHASSIS (420)
09-10A	CHASSIS (420CT)
09-11	CHASSIS (420)
09-11A	CHASSIS (420CT)
09-12	CONTROLS - LOADER AND GROUND DRIVE (FLAT LINKAGE LINKS, IF USED, SEE FIG 09-12A REF 5, 6)
09-12A	CONTROLS - LOADER AND GROUND DRIVE (FLAT LINKAGE LINKS, IF USED, SEE REF 5, 6)
09-13	CONTROLS - LOADER AND GROUND DRIVE (ROUND LINKAGE LINKS, IF USED, SEE FIGURE 09-13B REF 1, 2)
09-13A	CONTROLS - LOADER AND GROUND DRIVE (ROUND LINKAGE LINKS, IF USED, SEE FIGURE 09-13B REF 1, 2)
09-13B	CONTROLS - LOADER AND GROUND DRIVE (ROUND LINKAGE LINKS, IF USED, SEE FIGURE 09-13B REF 1, 2)
09-13C	CONTROLS - LOADER AND GROUND DRIVE (ROUND LINKAGE LINKS, IF USED, SEE FIGURE 09-13B REF 1, 2)
09-14	COVER - LOADER AND GROUND DRIVE
09-15	CONTROLS - AUXILIARY HYDRAULICS
09-16	HOOD
09-16A	HOOD - EUROPE, IF USED
09-17	DOOR, REAR
09-18	REAR DOOR LOCK (EUROPE)
09-19	SOUNDPROOFING
09-20	SOUNDPROOFING - SEAL
09-20A	HEAT SHIELD
09-21	NOISE KIT - EUROPE
09-21A	NOISE KIT, IF USED
09-22	NOISE KIT - EUROPE
09-22A	NOISE KIT, CAB - EUROPE, IF USED
09-22B	MAT, FLOOR
09-23	FRAME AND SEAT BAR
09-24	SEAT BAR
09-25	CAB DOOR - WITHOUT SPRING ASSIST, IF USED
09-25A	CAB DOOR - WITH SPRING ASSIST, IF USED
09-25B	CAB DOOR - WIPER
09-25C	CAB DOOR - UPPER PANEL
09-26	WINDOWS, SIDE
09-27	REAR WINDOW

Order the manual at mid-west-tech.com >

EXHAUST SYSTEM, IF USED (SEE REF 16, 17)

REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTION
1		87462107		1	MUFFLER
1A		87356837		1	GUARD Muffler And Wrap Assy; European Models, If Used: Incl. 87356487 Wrap, 87462107 Muffler; Not Illustated Separately
		87356487		1	GUARD Muffler Wrap
		87462107		1	MUFFLER Muffler
2		43127		5	BOLT Hex, M8 x 25, 8.8
3		100016		4	NUT M10, Cl 8
4		140045		11	WASHER, LOCK
5		43128		4	SCREW Hex, M8 x 30, 8.8
6		322358		13	WASHER, LOCK Belleville, M8
7		86633393		6	SPACER
8		87461995		1	CLAMP Muffler
9		87045237		1	TUBE Exhaust
10		43139		2	SCREW Hex, M10 x 25, 8.8, Full Thd
11		87046588		1	ROD Muffler Support
12		87046587		1	ROD Muffler Support
13		43138		1	SCREW Hex, M10 x 20, 8.8, Full Thd
14		120104		1	SCREW Hex, M8 x 20, 8.8
15		87042897		1	SPACER
16		87356846		1	ROD, MOUNTING Muffler Support; 393.3 mm; Center To Center of Holes; Replaces 8704658 (322.5 mm Center To Center of Holes), See Figure 02-03, Ref 8
17		87356847		1	ROD, MOUNTING Muffler Support; 452 mm; Center To Center of Holes; Replaces 87046586 (388 mm Center To Center of Holes), See Figure 02-03, Ref 5
18		120068		1	SCREW Hex, M10 x 40, 8.8, Full Thd

MidWestTech | Case 420, 420CT Skid Steer Parts Catalog | Publication 7-9712na Order the manual at mid-west-tech.com >

CONTROLS - LOADER AND GROUND DRIVE (ROUND LINKAGE LINKS, IF USED, SEE FIGURE 09-13B REF 1, 2)

REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTION
		REF			INSTRUCTION Assy With Round Linkage Links, See Figure 09-13B Ref 1, 2
1		87848		2	BOLT Hex, 1/2"-20 x 1", G5, Full Thd
2		87364		6	WASHER 1/2", SAE
3		87458514		1	ROD ASSY. Drive Control
4		367585A2		1	CRANK
5		409844A1		2	BEARING, NEEDLE 5/8 Shaft
6		87458519		1	FRAME Control Right Hand
7		87458664		2	BEARING, BALL
8		230425A1		2	BALL JOINT
9		230426A1		2	BALL JOINT
10		80855		2	NUT, LOCK 3/8"-24, GC
11		435565A1		1	ROD
12		87030547		2	NUT 3/8"-24, G5, LH
13		86509310		2	NUT 3/8"-24, G5
14		87460100		1	ROD Linkage
15		86625263		2	WASHER M8 x 20 x 1.6
16		86523954		2	PIN, SPLIT (COTTER) 3/32" x 5/8"
17		393968A1		1	ROD Control Link
18		D95097		1	SNAP RING 3/4 in
19		379344A3		1	CAM, BRAKE 5/8"-11, G8
20		393969A1		1	ROD Control Link
21		87458521		1	FRAME Control Left Hand

Order the manual at mid-west-tech.com >

DECALS - BRAZILIAN PORTUGUESE, CANADIAN FRENCH, LATIN AMERICAN SPANISH

REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTION
		REF			INSTRUCTION BRAZILIAN PORTUGUESE
1		434019A1		1	DECAL Danger, Exiting
2		297408A1		1	DECAL Danger, Crush Hazard
3		297406A1		1	DECAL Caution, Always Inspect
4		297407A1		1	DECAL Warning, Tip Hazard
5		353240A1		1	DECAL Warning, Ride Control
6		353243A1		1	DECAL Warning, Accumulator
7		298518A1		1	ADHESIVE Do Not Operate
		REF			INSTRUCTION CANADIAN FRENCH
1		434020A1		1	DECAL Danger, Exiting
2		297394A1		1	DECAL Danger, Crush Hazard
3		297410A1		1	DECAL Caution, Always Inspect
4		297380A1		1	DECAL Warning, Tip Hazard
5		353239A1		1	DECAL Warning, Ride Control
6		353242A1		1	DECAL Warning, Accumulator
7		321-5675		1	DECAL Do Not Operate
		REF			INSTRUCTION LATIN AMERICAN SPANISH
1		434018A1		1	DECAL Danger, Exiting
2		297403A2		1	DECAL Danger, Crush Hazard
3		297413A1		1	DECAL Caution, Always Inspect
4		297389A1		1	DECAL Warning, Tip Hazard
5		353238A1		1	DECAL Warning, Ride Control
6		353241A1		1	DECAL Warning, Accumulator
7		298521A1		1	TAG Do Not Operate

MidWestTech | Case 420, 420CT Skid Steer Parts Catalog | Publication 7-9712na Order the manual at mid-west-tech.com >