CASE

PROFESSIONAL PARTNER

PARTS CATALOG
SKID STEER
430

7-9722 NA

Replaces 7-9721 NA

Revised 01Dec06
Issued 01Dec04

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

02-01	RADIATOR - COOLANT RECOVERY SYSTEM
02-02	FAN MOUNTING
02-03	EXHAUST SYSTEM
02-03A	EXHAUST SYSTEM, ASPIRATOR
02-04	AIR CLEANER - ENGINE
02-05	GRID HEATER
02-06	ENGINE - MOUNTING
02-07	OIL FILL, ENGINE
02-08	ENGINE
02-08A	ENGINE - BLOCK HEATER
02-09	CYLINDER BLOCK
02-10	CYLINDER BLOCK
02-11	OIL PUMP, PAN
02-12	CYLINDER BLOCK - COVERS
02-13	CYLINDER BLOCK - COVERS
02-14	CYLINDER BLOCK - COVERS
02-15	BREATHER - ENGINE
02-16	CYLINDER HEAD
02-17	CYLINDER HEAD - COVERS
02-18	CYLINDER HEAD - VALVE MECHANISM
02-19	MANIFOLD - INTAKE
02-20	MANIFOLD - EXHAUST
02-21	CRANKSHAFT
02-22	PISTONS - CONNECTING ROD
02-23	PISTONS - CONNECTING ROD
02-24	FLYWHEEL - ENGINE
02-25	PULLEY - CRANKSHAFT
02-26	CAMSHAFT
02-27	ENGINE, OIL
02-28	OIL PUMP - ENGINE
02-29	OIL FILTERS - ENGINE
02-30	OIL FILTER AND COOLER
02-31	WATER PUMP
02-32	COOLING SYSTEM - ENGINE
02-33	THERMOSTAT - ENGINE COOLING SYSTEM
02-34	WATER PUMP - CONTROL
02-35	FAN DRIVE
02-36	POWER TAKE OFF
02-37	ENGINE - LIFT HOOK
03-01	FUEL LINES
03-01A	FUEL LINES - FUEL SHUT-OFF VALVE, IF USED
03-02	CONTROLS - THROTTLE
03-03	CONTROLS - THROTTLE, FOOT
03-04	FUEL INJECTION PUMP
03-05	FUEL INJECTION SYSTEM
03-06	FUEL INJECTION SYSTEM
03-07	FUEL INJECTION SYSTEM
03-08	FUEL FILTER
03-09	FUEL PUMP
03-10	FUEL INJECTION SYSTEM
03-11	FUEL INJECTION SYSTEM

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

04-02	ALTERNATOR MOUNTING
04-03	BATTERY - CABLES
04-04	ENGINE, ELECTRICAL
04-04A	SWITCH ASSY - OIL PRESSURE
04-05	ENGINE, ELECTRICAL
04-06	HARNESS, CHASSIS
04-07	HARNESS - CAB
04-08	FUSES AND RELAYS
04-09	OPTIONS, ELECTRICAL
04-10	OPTIONS, ELECTRICAL - MOUNTING
04-11	HARNESS, FRONT - AUXILIARY
04-12	CONTROLS, RIGHT HAND - HANDLE; IF USED, SEE ADAPTER, REF 5
04-12A	CONTROLS, RIGHT HAND - HANDLE; IF USED, SEE ADAPTER, REF 5
04-13	CONTROLS, LEFT HAND - HANDLE; IF USED, SEE ADAPTER, REF 4
04-13A	CONTROLS, LEFT HAND - HANDLE; IF USED, SEE ADAPTER, REF 5
04-14	DISCONNECT SWITCH - REMOTE JUMP START; IF USED
04-14A	DISCONNECT SWITCH - REMOTE JUMP START; IF USED
04-15	HORN - MOUNTING
04-16	BACKUP ALARM
04-17	BEACON, ROTATING
04-18	ELECTRICAL ACCESSORIES SOCKET - EUROPE
04-18A	ELECTRICAL ACCESSORIES SOCKET - NORTH AMERICA
04-19	ROAD LIGHTS AND MOUNTING - EUROPE
04-20	SPECIAL PARTS FOR ITALY - LICENSE PLATE LIGHT
04-21	LOCK, LOADER DISCONNECT - EUROPE
04-22	SPECIAL PARTS FOR ITALY - BRAKE LIGHT HARNESS
06-01	OIL COOLER - MOUNTING
06-01A	OIL COOLER ASSY - HIGH FLOW
06-01B	OIL COOLER - HIGH FLOW
06-02	HYDROSTATICS - PUMP, SUPPLY AND RETURN
06-02A	HYDROSTATICS - DRIVE MOTORS
06-02B	MOTOR - MOUNTING
06-03	PUMP, TANDEM - MOUNTING
06-03A	PUMP, TANDEM - MOUNTING, NORTH AMERICAN NOISE CONTROL; IF USED
06-04	HYDROSTATICS - TWO SPEED
06-04A	HYDROSTATICS - TWO SPEED, VALVE ASSY
06-05	JOYSTICK CONTROL PLUMBING, H PATTERN (430 WITH PILOT CONTROL)
06-06	HYDROSTATICS - PUMP TO COOLER (430 WITH PILOT CONTROL)
06-06A	HYDROSTATICS - MANIFOLD/CONTROL VALVE (430 WITH PILOT CONTROL)
06-06B	HYDROSTATICS - PUMP FITTINGS (430 WITH PILOT CONTROL)
06-07	HYDROSTATICS, HOSES (430 WITH PILOT CONTROL)
06-07A	HYDROSTATICS, MULTI VALVE (430 WITH PILOT CONTROL)
06-08	HYDROSTATICS - SINGLE SPEED, DRIVE MOTORS (430 WITH PILOT CONTROL)
06-08A	HYDROSTATICS - TWO SPEED, DRIVE MOTORS (430 WITH PILOT CONTROL)
06-08B	HYDROSTATICS - TWO SPEED, VALVE ASSY (430 WITH PILOT CONTROL)
06-09	FILTER ASSY - MOUNTING
06-10	PUMP, TANDEM
06-11	PUMP, TANDEM
06-12	PUMP, TANDEM
06-13	PUMP, TANDEM
06-14	PUMP, TANDEM

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

06-15	PUMP, TANDEM
06-16	PUMP, GEAR (WITHOUT HIGH FLOW)
06-17	PUMP, GEAR (HIGH FLOW)
06-18	MOTOR ASSY - SINGLE SPEED
06-19	MOTOR ASSY - SINGLE SPEED
06-20	MOTOR ASSY - SINGLE SPEED
06-21	MOTOR ASSY - TWO SPEED
06-22	MOTOR ASSY - TWO SPEED
06-23	MOTOR ASSY - TWO SPEED
06-24	DRIVE LINE
06-25	AXLE ASSY
06-26	WHEELS
06-27	TRACK - STEEL
07-01	BRAKE SYSTEM - HYDRAULIC
08-01	HYDRAULICS - LIFT
08-02	HYDRAULICS - TILT
08-03	HYDRAULICS - AUXILIARY
08-03A	HYDRAULICS - CASE DRAIN
08-04	HYDRAULICS - SELF-LEVELING
08-05	HYDRAULICS - RIDE CONTROL
08-06	HYDRAULICS - COUPLER SYSTEM
08-07	HYDRAULICS - COUPLER SYSTEM
08-08	HYDRAULICS, ATTACHMENT
08-08A	HYDRAULICS, ATTACHMENT (430 WITH PILOT CONTROL)
08-09	VALVE ASSY, CONTROL - LOADER
08-10	VALVE ASSY, CONTROL
08-11	VALVE ASSY, CONTROL - SEAL REPLACEMENT KITS
08-12	CYLINDER - TILT
08-13	CYLINDER - LIFT
08-14	SECONDARY FRONT AUXILIARY
08-15	SECONDARY FRONT AUXILIARY
08-16	SECONDARY FRONT AUXILIARY - VALVE ASSY
08-17	HIGH FLOW, SUPPLY AND RETURN
08-18	HIGH FLOW - AUXILIARY SYSTEM
08-19	HIGH FLOW, CONTROL VALVE
08-20	VALVE ASSY, CONTROL - HIGH FLOW
09-01	LOADER LIFT
09-02	LIFT CYLINDER - COVERS
09-03	COUPLER, MECHANICAL
09-03A	COUPLER, MECHANICAL (ITALIAN)
09-04	COUPLER, HYDRAULIC
09-04A	COUPLER, HYDRAULIC (ITALIAN)
09-05	BUCKETS - LOADER (DIRT/FOUNDRY)
09-06	BUCKETS - LOADER (LOW PROFILE/ EXTENDED LOW PROFILE)
09-07	BUCKETS - LOADER (UTILITY/LIGHT MATERIAL)
09-08	PALLET FORK
09-09	BUCKET, CUTTING EDGE (BOLT-ON CUTTING EDGE)
09-10	CHASSIS
09-11	CHASSIS
09-12	CONTROLS - LOADER AND GROUND DRIVE (FLAT LINKAGE LINKS, IF USED, SEE FIGURE 09-12A REF 5, 6)

Order the manual at mid-west-tech.com >

CONTROLS, LEFT HAND - HANDLE; IF USED, SEE ADAPTER, REF 4

REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTION
		87458322		1	HANDLE, WITHOUT SWITCHES; Incl. 1 - 4
1		86837247		2	SCREW, #4-40 x 1 1/4", w/LW, Faceplate
2		87427350		2	SCREW, Hex, #10-32 x 5/16", Grip
3		(87564724)		2	SET SCREW, #10-32 x 1/4 CONE AST PHC
4		87456565		1	ADAPTER, Mount
		87458328		1	HANDLE, WITH TURN SIGNAL SWITCH; Incl. 5 - 10
5		87427353		1	SWITCH, Turn Signal
6		86837247		2	SCREW, #4-40 x 1 1/4", w/LW, Faceplate
7		87427350		2	SCREW, Hex, #10-32 x 5/16", Grip
8		(87564724)		2	SET SCREW, #10-32 x 1/4 CONE AST PHC
9		87456565		1	ADAPTER, Mount
10		256344A1		1	CONNECTOR
		87458326			HANDLE, WITH HYDRAULIC ATTACHMENT; Incl. 11 - 18
11		87458601		1	SWITCH, Hydraulic Attachment On-Off
12		87440121		1	SWITCH, Hydraulic Attachment
13		86837247		2	SCREW, #4-40 x 1 1/4", w/LW, Faceplate
14		87427350		2	SCREW, Hex, #10-32 x 5/16", Grip
15		(87564724)		2	SET SCREW, #10-32 x 1/4 CONE AST PHC
16		87456565		1	ADAPTER, Mount
17		256342A1		1	CONNECTOR
18		256341A1		1	CONNECTOR
		87458327		1	HANDLE, WITH HYDRAULIC ATTACHMENT, TWO SPEED SWITCH; Incl. 19 - 27
19		87458601		1	SWITCH, Hydraulic Attachment On-Off
20		87440121		1	SWITCH, Hydraulic Attachment
21		86837247		2	SCREW, #4-40 x 1 1/4", w/LW, Faceplate
22		87427352		1	SWITCH, Trigger, On- Off
23		87427350		2	SCREW, Hex, #10-32 x 5/16", Grip
24		(87564724)		2	SET SCREW, #10-32 x 1/4 CONE AST PHC
25		87456565		1	ADAPTER, Mount
26		256342A1		1	CONNECTOR
27		256341A1		1	CONNECTOR

MidWestTech | Case 430 Skid Steer Parts Catalog | Publication 7-9722na Order the manual at mid-west-tech.com >

CONTROLS - LOADER AND GROUND DRIVE (FLAT LINKAGE LINKS, IF USED, SEE REF 5, 6)

REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTION
					Assy With Flat Linkage Links, See Ref 5, 6
1		80702		2	WASHER, 3/8"
2		641419		2	WASHER
3		140045		2	WASHER, SPRING, Belleville, M10
4		9628503		2	NUT, 3/8"-16, G5
5		87436612		1	LINK
6		87436613		1	LINK
7		234726		2	PIN, CLEVIS, 1/4" x .770"
8		D131983		2	PIN
9		88206		2	BOLT, Hex, 3/8"-16 x 1", G5, Full Thd
10		43117		1	SCREW, Hex, M6 x 30, 8.8
11		86500688		5	NUT, M6, Cl 10
12		832-41406		1	NUT, LOCK, M6 x 1, Cl 8
13		120952A1		1	SPRING
14		409846A3		2	BEARING, NYLON, 5/8
15		409847A3		2	BEARING, NYLON, 3/4
16		{103-11143}		2	Ring; #143
17		103-1475		1	RING, SNAP, #75, Ext
18		103-11118		2	RING, SNAP, #118, Ext
19		87848		2	BOLT, Hex, 1/2"-20 x 1", G5, Full Thd
20		87364		2	WASHER, 1/2", SAE
21		87460125		1	FRAME, Right Hand
22		367582A1		2	BEARING, NYLON
23		409856A1		1	SPACER
24		367585A2		1	CRANK
25		409844A1		2	BEARING, NEEDLE
26		100-1462		1	RING, SNAP, #62, Ext
27		367583A4		1	LEVER ASSY., 5/8
28		87452325		1	FRAME, Left Hand
29		87460100		1	ROD
30		80855		12	NUT, LOCK, 3/8"-24, GC
31		230426A1		6	BALL JOINT
32		87030547		6	NUT, 3/8"-24, G5, LH
33		86509310		6	NUT, 3/8"-24, G5
34		230425A1		6	BALL JOINT

Assy With Flat Linkage Links, See Ref 5, 6

MidWestTech | Case 430 Skid Steer Parts Catalog | Publication 7-9722na Order the manual at mid-west-tech.com >

DECALS - BRAZILIAN PORTUGUESE, CANADIAN FRENCH, LATIN AMERICAN SPANISH

REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTION
		REF			INSTRUCTION, BRAZILIAN PORTUGUESE
1		434019A1		1	DECAL, Danger, Exiting
2		297408A1		1	DECAL, Danger, Crush Hazard
3		297406A1		1	DECAL, Caution, Always Inspect
4		297407A1		1	DECAL, Warning, Tip Hazard
5		353240A1		1	DECAL, Warning, Ride Control
6		353243A1		1	DECAL, Warning, Accumulator
7		298518A1		1	ADHESIVE, Do Not Operate
		REF			INSTRUCTION, CANADIAN FRENCH
1		434020A1		1	DECAL, Danger, Exiting
2		297394A1		1	DECAL, Danger, Crush Hazard
3		297410A1		1	DECAL, Caution, Always Inspect
4		297380A1		1	DECAL, Warning, Tip Hazard
5		353239A1		1	DECAL, Warning, Ride Control
6		353242A1		1	DECAL, Warning, Accumulator
7		321-5675		1	DECAL, Do Not Operate
		REF			INSTRUCTION, LATIN AMERICAN SPANISH
1		434018A1		1	DECAL, Danger, Exiting
2		297403A2		1	DECAL, Danger, Crush Hazard
3		297413A1		1	DECAL, Caution, Always Inspect
4		297388A1		1	DECAL, Warning, Tip Hazard; Replaces 297389A1
5		353238A1		1	DECAL, Warning, Ride Control
6		353241A1		1	DECAL, Warning, Accumulator
7		298521A1		1	TAG, Do Not Operate

MidWestTech | Case 430 Skid Steer Parts Catalog | Publication 7-9722na Order the manual at mid-west-tech.com >