# PARTS CATALOG

## EH80
## MIDI CRAWLER EXCAVATOR

7-9950NA

NEW HOLLAND
CONSTRUCTION



Order the manual at mid-west-tech.com >

# TABLE OF CONTENTS


| | |
|---|---|
| 001 | FRAME ASSEMBLY, UPPER |
| 002 | BRACKET ASSEMBLY, SWING |
| 003 | COUNTERWEIGHT ASSEMBLY |
| 004 | COUNTERWEIGHT ASSEMBLY (GAIN) |
| 005 | ENGINE ASSEMBLY |
| 006 | ENGINE ASSEMBLY |
| 007 | ENGINE INSTALLATION |
| 008 | RADIATOR INSTALLATION |
| 009 | RADIATOR ASSEMBLY |
| 010 | CLEANER ASSEMBLY, AIR |
| 011 | W ELEMENT |
| 012 | MUFFLER ASSEMBLY |
| 013 | PUMP ASSEMBLY, FUEL |
| 014 | PUMP ASSEMBLY, FUEL |
| 015 | FUEL LINES |
| 016 | FUEL LINES |
| 017 | SEPARATOR ASSEMBLY, WATER |
| 018 | TANK ASSEMBLY, FUEL |
| 019 | TANK ASSEMBLY, HYDRAULIC |
| 020 | CONTROL ASSEMBLY, ENGINE |
| 021 | POWER TAKE OFF ASSEMBLY, ENGINE |
| 022 | MOTOR ASSEMBLY, SWING |
| 023 | VALVE INSTALLATION (WITHOUT NIBBLER AND BREAKER) |
| 024 | VALVE INSTALLATION (DOZER) |
| 025 | HYD LINES, UPPER (SUCTION, DELIVERY) |
| 026 | HYD LINES, UPPER (DOZER) |
| 027 | HYD LINES, UPPER (WITHOUT NIBBLER AND BREAKER, MAIN) |
| 028 | HYD LINES, UPPER (WITHOUT NIBBLER AND BREAKER, MAIN) |
| 029 | HYD LINES, RETURN (WITHOUT NIBBLER AND BREAKER, RETURN) |
| 030 | HYD LINES, RETURN (WITHOUT NIBBLER AND BREAKER, RETURN) |
| 031 | CONTROLS, OPERATORS |
| 032 | CONTROLS, OPERATORS |
| 033 | CONTROL BOX ASSEMBLY (FOR LEFT SIDE) |
| 034 | CONTROL BOX ASSEMBLY (FOR LEFT SIDE) |
| 035 | CONTROL BOX ASSEMBLY (FOR RIGHT SIDE) |
| 036 | LEVER ASSEMBLY, PROPEL |
| 037 | CONTROL LINES, REMOTE |
| 038 | CONTROL LINES, REMOTE |
| 039 | CONTROL LINES, REMOTE |
| 040 | CONTROL LINES, REMOTE |
| 041 | CONTROL LINES, REMOTE (DOZER) |
| 042 | CONTROL LINES, REMOTE |
| 043 | CONTROL LINES, REMOTE (WITHOUT NIBBLER AND BREAKER) |
| 044 | CONTROL LINES, REMOTE (WITHOUT NIBBLER AND BREAKER) |
| 045 | CONTROL LINES, REMOTE (WITHOUT NIBBLER AND BREAKER) |
| 046 | CONTROL LINES, REMOTE (WITHOUT NIBBLER AND BREAKER) |
| 047 | CONTROL LINES, REMOTE |
| 048 | CONTROL LINES, REMOTE (WITHOUT NIBBLER AND BREAKER) |
| 049 | CONTROL LINES, REMOTE (WITHOUT NIBBLER AND BREAKER) |
| 050 | CONTROL LINES, VALVE |
| 051 | CONTROL LINES. VALVE |


MidWestTech | New Holland EH80 Midi Crawler Excavator Parts Catalog | Publication 7-99... Order the manual at mid-west-tech.com >

# TABLE OF CONTENTS


| | |
|---|---|
| 052 | CONTROL LINES, VALVE (CHANGE SWING) |
| 053 | CONTROL LINES, REMOTE |
| 054 | CONTROL LINES, REMOTE |
| 055 | PLATE GROUP, FLOOR |
| 056 | PLATE GROUP, FLOOR (NIBBLER & BREAKER) |
| 057 | MIRROR INSTALLATION (STD/WITH ROOF & TRIPLE GUARD/LIGHT) |
| 058 | MIRROR INSTALLATION |
| 059 | MIRROR INSTALLATION LF02-01001 -01279 |
| 060 | MIRROR INSTALLATION (STD/WITH ROOF & TRIPLE GUARD/LIGHT) |
| 061 | CAB INSTALLATION |
| 062 | CAB ASSEMBLY |
| 063 | CAB ASSEMBLY |
| 064 | CAB ASSEMBLY |
| 065 | WINDOW ASSEMBLY FR. |
| 066 | DOOR ASSEMBLY, CAB |
| 067 | SEAT GROUP |
| 068 | SEAT ASSEMBLY |
| 069 | SEAT ASSEMBLY |
| 070 | BELT ASSEMBLY, SEAT |
| 071 | GUARD INSTALLATION |
| 072 | GUARD INSTALLATION |
| 073 | COVER ASSEMBLY |
| 074 | BOX ASSEMBLY |
| 075 | GUARD ASSEMBLY |
| 076 | BONNET ASSEMBLY |
| 077 | GUARD INSTALLATION |
| 078 | COVER ASSEMBLY, UNDER |
| 079 | PANEL ASSEMBLY, INSTRUMENT (STD) |
| 080 | PANEL ASSEMBLY, INSTRUMENT (STD) |
| 081 | PANEL ASSEMBLY, INSTRUMENT |
| 082 | PANEL ASSEMBLY INSTRUMENT |
| 083 | GAUGE, CLUSTER |
| 084 | GAUGE, CLUSTER |
| 085 | CONTROLLER ASSEMBLY |
| 086 | CONTROLLER ASSEMBLY |
| 087 | CONTROLLER ASSEMBLY |
| 088 | CONTROLLER ASSEMBLY |
| 089 | BATTERY INSTALLATION |
| 090 | CONDITIONER, AIR |
| 091 | CONDITIONER INSTALLATION |
| 092 | CONDITIONER INSTALLATION |
| 093 | CONDITIONER INSTALLATION |
| 094 | CONDITIONER ASSEMBLY, AIR |
| 095 | CONDITIONER ASSEMBLY, AIR |
| 096 | DRIER ASSEMBLY, AIR |
| 097 | FILTER ASSEMBLY, AIR |
| 098 | CONDITIONER ASSEMBLY, AIR |
| 099 | CONDITIONER ASSEMBLY, AIR |
| 100 | ELECTRIC ASSEMBLY, UPPER |
| 101 | LIGHT INSTALLATION |
| 102 | AMP INSTALLATION |


MidWestTech | New Holland EH80 Midi Crawler Excavator Parts Catalog | Publication 7-99... Order the manual at mid-west-tech.com >

# TABLE OF CONTENTS


| | |
|---|---|
| 103 | HARNESS ASSEMBLY, UPPER |
| 104 | HARNESS ASSEMBLY, UPPER |
| 105 | HARNESS ASSEMBLY, UPPER |
| 106 | HARNESS ASSEMBLY, UPPER |
| 107 | HARNESS ASSEMBLY, UPPER |
| 108 | HARNESS ASSEMBLY, CAB |
| 109 | HARNESS ASSEMBLY, CAB |
| 110 | HANESS ASSEMBLY, UPPER (WITHOUT PEDAL, 1 PEDAL) |
| 111 | HARNESS ASSEMBLY, UPPER (WITHOUT PEDAL, 1 PEDAL) |
| 112 | HARNESS ASSEMBLY, ENGINE |
| 113 | HARNESS ASSEMBLY, ENGINE |
| 114 | LOW GROUP (FOR RUBBER) |
| 115 | LOW GROUP (FOR IRON) |
| 116 | RING ASSEMBLY, SLEWING |
| 117 | IDLER ASSEMBLY CRAWLER |
| 118 | IDLER ASSEMBLY |
| 119 | IDLER ADJUST ASSEMBLY |
| 120 | ROLLER ASSEMBLY, TRACK |
| 121 | ROLLER ASSEMBLY, UPPER |
| 122 | SHOE ASSEMBLY 2 |
| 123 | RUBBER, CRAWLER BELT |
| 124 | HYD LINES, LOW |
| 125 | DOZER ASSEMBLY |
| 126 | DOZER ASSEMBLY |
| 127 | BOOM ASSEMBLY |
| 128 | HYD LINES, BOOM 3.72M (12FT 2IN) (WITHOUT NIBBLER AND BREAKER) |
| 129 | HYD LINES, BOOM 3.72M (12FT 2IN) |
| 130 | LIGHT INSTALLATION |
| 131 | ARM ASSEMBLY 1.8M (5FT 11 IN) (WITHOUT NIBBLER AND BREAKER) |
| 132 | ARM ASSEMBLY 1.8M (5FT 11 IN) |
| 133 | HYD LINES, ARM 1.8M (5FT 11 IN) |
| 134 | HYD LINES, ARM 1.8M (NIBBLER AND BREAKER) |
| 135 | BUCKET INSTALLATION |
| 136 | TOOL AND ACCESSORY |
| 137 | ELEMENT KIT |
| 138 | CONTROL LINES, REMOTE |
| 139 | CONTROL LINES, REMOTE |
| 140 | CONTROL LINES, REMOTE |
| 141 | CONTROL LINES, REMOTE |
| 142 | CONTROL LINES, REMOTE |
| 143 | CONTROL LINES, REMOTE (WITHOUT NIBBLER AND BREAKER) (MULTI) |
| 144 | CONTROL LINES, REMOTE (WITHOUT NIBBLER AND BREAKER) (MULTI) |
| 145 | CONTROL LINES, REMOTE(WITHOUT NIBBLER AND BREAKER) (MULTI) |
| 146 | CONTROL LINES, REMOTE (WITHOUT NIBBLER AND BREAKER) (MULTI) |
| 147 | CONTROL LINES, REMOTE(WITHOUT NIBBLER AND BREAKER) (MULTI) |
| 148 | CONTROL LINES, REMOTE (BOOM SAFETY) |
| 149 | CONTROL LINES, REMOTE (BOOM SAFETY) |
| 150 | CONTROL LINES, REMOTE (BOOM SAFETY) |
| 151 | CONTROL LINES, REMOTE (BOOM SAFETY) |
| 152 | CONTROL LINES, REMOTE (BOOM SAFETY) |
| 153 | CONTROL LINES, REMOTE (BOOM SAFETY) |


MidWestTech | New Holland EH80 Midi Crawler Excavator Parts Catalog | Publication 7-99... Order the manual at mid-west-tech.com >

VALVE ASSEMBLY, PILOT (PROPELLING)

| REF | FN | PART NUMBER | YR/SN | QTY | DESCRIPTION |
|---|---|---|---|---|---|
| | | {PM30V00019R100} | | 1 | REPAIR KIT CONSISTS OF ITEM 210X4, 211X4, 212X4, 213X2 |
| | | {YN30V00070R100} | | 1 | REPAIR KIT CONSISTS OF ITEM 420X2, 471X4 |



MidWestTech | New Holland EH80 Midi Crawler Excavator Parts Catalog | Publication 7-99... Order the manual at mid-west-tech.com >

## CRANKSHAFT, PISTON AND FLYWHEEL

| REF | FN | PART NUMBER | YR/SN | QTY | DESCRIPTION |
|---|---|---|---|---|---|
| 1 | | {897190-9301} | | 1 | CRANKSHAFT |
| 10 | | {897063-2580} | | 1 | METAL SET; CRANKSHAFT, STANDARD BLUE |
| | | {897063-2590} | | 1 | METAL SET; CRANKSHAFT, STANDARD BLACK |
| | | {897063-2600} | | 1 | METAL SET; CRANKSHAFT, STANDARD GREEN |
| 12A | | {897264-9300} | | 1 | FLYWHEEL |
| 21 | | {509000-2732} | | 1 | BOLT; PULLEY FIX M16X43 |
| 28 | | {894324-3350} | | 1 | GEAR; CR/SHF |
| 31 | | {894201-6410} | | 1 | KEY; FEATHER, CR/SHF |
| 38 | | {894142-1561} | | 1 | WASHER; FLYWHEEL |
| 40A | | {897065-9841} | | 8 | BOLT; FLYWHEEL M16X43 |
| 42 | | {894453-5200} | | 2 | WASHER; THRUST, CR/SHF |
| 56 | | {894140-4883} | | 1 | PULLEY; CR/SHF DAMPER |
| 59 | | {509503-1270} | | 1 | WASHER; CR/SHF PULLEY |
| 63 | | {897288-2500} | | 4 | PISTON (GRADE=AX) |
| 63 | | {897288-2510} | | 4 | PISTON (GRADE=CX) |
| 68 | | {897147-9840} | | 4 | RING SET; PISTON, STANDARD |
| 73 | | {894324-1590} | | 4 | METAL SET; CONN ROD, STANDARD |
| 83 | | {894457-0081} | | 4 | PIN; PISTON |
| 84 | | {897289-2630} | | 4 | ROD ASM; CONN |
| 85 | | {897289-2640} | | 4 | BUSHING; CONNROD |
| 86 | | {897062-0860} | | 8 | BOLT; CONNROD M11X44.5 |
| 87 | | {908160-5080} | | 8 | PIN; CONNROD BIG END |
| 126 | | {894460-6870} | | 8 | RING; SNAP, PISTON PIN |



MidWestTech | New Holland EH80 Midi Crawler Excavator Parts Catalog | Publication 7-99... Order the manual at mid-west-tech.com >

INJECTION PUMP

| REF | FN | PART NUMBER | YR/SN | QTY | DESCRIPTION |
|---|---|---|---|---|---|
| 181 | | {515619-0010} | | AR | SHIM; TAPPET, INJ PUMP T=0.60 |
| 181 | | {515619-0020} | | AR | SHIM; TAPPET, INJ PUMP T=0.70 |
| 181 | | {515619-0030} | | AR | SHIM; TAPPET, INJ PUMP T=0.80 |
| 181 | | {515619-0040} | | AR | SHIM; TAPPET, INJ PUMP T=0.90 |
| 181 | | {515619-0050} | | AR | SHIM; TAPPET, INJ PUMP T=1.00 |
| 181 | | {515619-0070} | | AR | SHIM; TAPPET, INJ PUMP T=1.10 |
| 181 | | {515619-0080} | | AR | SHIM; TAPPET, INJ PUMP T=1.20 |
| 181 | | {515619-0090} | | AR | SHIM; TAPPET, INJ PUMP T=1.30 |
| 181 | | {515619-0100} | | AR | SHIM; TAPPET, INJ PUMP T=1.40 |
| 181 | | {515619-0110} | | AR | SHIM; TAPPET, INJ PUMP T=0.55 |
| 181 | | {515619-0120} | | AR | SHIM; TAPPET, INJ PUMP T=0.65 |
| 181 | | {515619-0130} | | AR | SHIM; TAPPET, INJ PUMP T=0.75 |
| 181 | | {515619-0150} | | AR | SHIM; TAPPET, INJ PUMP T=0.85 |
| 181 | | {981235-0420} | | AR | SHIM; TAPPET, INJ PUMP T=0.95 |
| 181 | | {981235-0430} | | AR | SHIM; TAPPET, INJ PUMP T=1.05 |
| 181 | | {981235-0440} | | AR | SHIM; TAPPET, INJ PUMP T=1.15 |
| 181 | | {981235-0450} | | AR | SHIM; TAPPET, INJ PUMP T=1.25 |
| 181 | | {515619-1060} | | AR | SHIM; TAPPET, INJ PUMP T=1.50 |
| 181 | | {515619-1070} | | AR | SHIM; TAPPET, INJ PUMP T=1.60 |
| 181 | | {515619-0250} | | AR | SHIM; TAPPET, INJ PUMP T=0.20 |
| 181 | | {515619-0260} | | AR | SHIM; TAPPET, INJ PUMP T=0.25 |
| 181 | | {515619-0270} | | AR | SHIM; TAPPET, INJ PUMP T=0.35 |
| 181 | | {515619-0370} | | AR | SHIM; TAPPET, INJ PUMP T=0.45 |
| 181 | | {515619-1080} | | AR | SHIM; TAPPET, INJ PUMP T=1.35 |
| 181 | | {515619-1090} | | AR | SHIM; TAPPET, INJ PUMP T=1.45 |
| 181 | | {515619-1100} | | AR | SHIM; TAPPET, INJ PUMP T=1.55 |



MidWestTech | New Holland EH80 Midi Crawler Excavator Parts Catalog | Publication 7-99... Order the manual at mid-west-tech.com >