4890
Tractor
(Includes Rev. 1)

Parts Catalog

8-1181

CASE IH

MidWestTech | Case 4890 Tractor Parts Catalog | Publication 8-1180

Order the manual at mid-west-tech.com >

GENERAL INFORMATION

ILLUSTRATION AND TEXT

The arrangement of this parts catalog is for easy identification of Case parts. All parts are illustrated in "Exploded Views." This places each part in normal reference to each other. Reference numbers are used in the illustrations. These numbers are in reference to those on the text pages. The text pages list reference number, part number, part description and the amount required.

NSS "Not Serviced Separately" in the part number column is an indication this part is not available for repairs.

UAR "Use As Required" in the amount required column is an indication the number of parts used is controlled by service.

REF "Reference " in the parts number column is an indication this part has many applications or has special service information. The page this information can be found on is listed in the part description column.

INDEX

An alphabetical index and serial number information is on the front pages of this catalog. A numerical index which lists the part number, page number and reference number is on the last pages of this catalog.

CATALOG CHANGES

Changes to the product will make it necessary to revise or add pages to this catalog. Each new or revised page will have a new issue date. A cover sheet will be attached to each revision. The cover sheet will list all pages released for each revision. All revised and new pages must be put into the parts book as soon as they are received.

PARTS ORDER

Orders must give the complete description, correct part number, the total amount required, the product model, all the necessary serial numbers, the method of shipment and the shipping address.

TEXT DESCRIPTION

An assembly may contain many service items. The component parts of an assembly will be indented. The amount required column will list the number of components required for a complete assembly or sub-assemblies. See example.

REF.	PART NO.	DESCRIPTION	REQ'D
1	A 77303	VALVE ASSEMBLY - PTO control	1
2	REF	BODY ASSEMBLY - (See Page 99)	1
3	NSS	SPOOL - control valve (Order A77303)	1
4	A 61985	PLUG ASSEMBLY - valve spool	1
5	218- 5007	O-RING - plug 3/4 x 15/16 x 3/32" (19.05 x 23.81 x 2.38mm)	2
6	NSS	PIN - spring guide	1
7	B 51407	SPRING - detent 5/8" free length (15.87mm)	1
8	211- 11	BALL - detent 3/8" dia. steel (9.52mm)	UAR

RIGHT-HAND AND LEFT-HAND IDENTIFICATION

The reference to right-hand (RH) and left-hand (LH) as used in this publication is identified by the operator standing at the rear of the unit, looking toward the front of the machine.

MidWestTech | Case 4890 Tractor Parts Catalog | Publication 8-1180 Order the manual at mid-west-tech.com >

ALPHABETICAL INDEX

A

Acoustical Covers, Cab 9-423
Adapters, Hydraulic Coupling 8-313
Adapters, Hydraulic Hose 8-311
Air Cleaner 2-11
Air Conditioning Compressor Clutch .. 9-465
Air Conditioning, Cab 9-441,443
Air Conditioning Hoses 9-463
Air Conditioning Evaporator 9-441,443
Air Conditioning Condenser 9-461
Air Conditioning Compressor 9-465
Air Conditioning Blower Assembly . 9-433,435
Air Conditioning Receiver-Drier 9-461
Air Conditioning Expansion Valve 9-445
Air Conditioning Switches 9-447
Air Filter, Cab 9-431
Air Induction System 2-11
Air Restriction Switch 2-11
Alternator Assembly 4-125,127
Alternator Mounting 4-113
Antenna, Radio 9-453
Arm, Draft Arm Lift 9-339,341
Arm, Steering 5-135
Aspirator, Exhaust 2-11
Automatic Shutoff, Engine 4-81
Auxiliary Electric Outlet 4-85
Axle, Front 6-191
Axle, Rear 6-207
Axle, Rear (Rigid) 6-213

B

Battery 4-109
Battery Cables 4-109
Battery Holder 4-109
Bearing, Engine Main 2-39
Belt, Fan 2-9
Belt, Seat 9-467
Block, Cylinder 2-37
Blower Assembly, Cab Air 9-433,435
Brake Assembly,Transmission 7-245
Brake, Master Cylinder 7-249
Brake, Parking 7-247
Brake Pedals 7-243
Brake, PTO 6-235
Brake, Slave Cylinder 7-243

C

Cab Assembly ..... 9-409 through 457
Cab Lights 4-89
Cab Mounts and Supports 9-407
Cable, Battery 4-109

C

Cable, Cab Heat Control 9-439
Cable, Fuel Shut-Off 3-73
Cable, Tachometer Drive 4-77
Camshaft, Engine 2-35
Camshaft, Bushings 2-35
Cap, Main Bearing 2-39
Chassis 9-359
Charge System, Hydraulic 8-257
Check Valve, Rear Steering 5-163
Cigar Lighter 9-447
Circuit Breaker 4-101
Circuitry, Transmission Top Cover 8-269
Cluster, Instrument 4-97
Cluster Harness 4-77
Clutch, Air Compressor 9-465
Clutches, (C1) and (C4) 6-179
Clutches, (C2) and (C3) 6-183
Clutches, (C2) and Planetary 6-181
Clutch Housing 6-165
Clutch, PTO 6-235
Clutch, Assembly 6-179,181,183
Clutch, Foot Pedal 6-175
Cold Start Switch 4-99
Cold Start Battery Pack 4-111
Compensator, Hydraulic Pump 8-283
Compressor, Air 9-465
Compressor Mounting, Air 9-459
Condenser, Air Conditioning 9-461
Connecting Rod 2-41
Connecting Rod Bearing 2-41
Console Electrical Harness 4-77
Control Console 9-367,369
Control Valve, Rear Steering 5-159
Control Valve System, Transmission .. 8-271
Control Valve, Transmission 8-273
Coolant Indicator Module 4-77,99
Cooler, Hydraulic Oil 8-267
Core, Evaporator 9-441,443
Core, Heater 9-439
Coupler, Quick Hitch 9-357
Couplings, Hydraulic 8-313
Cover, Cylinder Head 2-29
Cover, Trans. Control Valve 8-239,273
Cowl, Instrument 9-365
Crankshaft, Engine 2-39
Cylinder Assembly, Remote Hydraulic . 8-315
Cylinder Assembly, Rear Steering 5-157
Cylinder Assembly, Front Steering . 5-153,155
Cylinder Block, Engine 2-37
Cylinder Block Gasket Kit 2-49,51,53

Rac 8-1181 Issued August, 1981 Printed in U.S.A.

MidWestTech | Case 4890 Tractor Parts Catalog | Publication 8-1180 Order the manual at mid-west-tech.com >

ALPHABETICAL INDEX

C

Cylinder Block Heater 2-13
Cylinder Head, Engine 2-31

D

Decals, Safety Kit 9-405
Decal, SMV Emblem 9-361
Decals, Tractor Kit 9-403
Differential Assembly, Front 6-201,203
Differential Assembly, Rear 6-219,221
Dipstick, Engine Oil 2-47
Door, Cab 9-411,413
Draft Arms, Hitch 9-339,343
Drawbar and Supports 9-349,351,353
Drawbar Yoke 9-355
Drive, Fuel Injection Pump 3-57
Drive Shaft, Front Axle 6-199
Drive Shaft, Rear Axle 6-217
Drive Shaft, PTO 6-241

E

Electric Controls, Rear Steering 5-139
Electric Hitch Wiring 4-129
Electrical Harness, Cab Headliner ... 4-93,95
Electrical Harness, Cab Lower 4-91
Electrical Harness, Fwd. Components .. 4-87
Electrical Harness, Engine 4-83
Electrical Harness, Console 4-77
Electrical Harness, Rear Light 4-87
Electrical Harness, Transmission 4-85
Electrical Outlet, Auxiliary 4-85
Engine Block Heater 2-13
Engine Cylinder Block 2-37
Engine Cylinder Head 2-31
Engine Crankshaft 2-39
Engine Mounts 9-359
Engine Shutoff 4-81
Ether Starting 2-13
Evaporator, Air Conditioning 9-441,443
Exhaust System 2-17,19
Extension, Hydraulic Hose 8-311

F

Fan 2-9
Fan Belt 2-9
Filter, Cab Air 9-431
Filter, Engine Fuel 3-63
Filter, Engine Oil 2-21,27
Filter, Hydraulic Oil 8-265
Flasher Switch 4-99
Flasher Warning Lamp 4-107

F

Flood Lamp, Front 4-105
Flood Lamp, Rear 4-103,105
Flood Lamp, Upper 4-89
Floor Mats, Cab 9-425
Flywheel, Engine 2-39
Frame, Cab 9-409
Front Lamp Harness 4-87
Fuel Filter System 3-63
Fuel Gauge 4-97
Fuel Injection Pump 3-59,61
Fuel Injection Pump Drive 3-57
Fuel Injection Pump Lube Tubes 3-71
Fuel Injection System 3-65,67
Fuel Injector 3-65,67
Fuel Shut Off Control 3-73
Fuel Tank 3-75
Fuel Tank Level Sender 3-75
Fuses, Cab 4-79
Fuses, Tractor 4-79
Fuse Holder 4-79

G

Gasket Kits, Engine 2-49,51,53
Gauge, Engine Water Temperature 4-97
Gauge, Fuel Level 4-97
Gauge, Pyrometer 4-97
Gear Shift Linkage 6-169
Glass, Cab 9-419,421
Grille, Front Lower 9-371,373
Grille, Front Upper 9-379,383
Guide, Engine Valve 2-33
Guard, Wheel 9-363

H

Harness, Cab Headliner 4-93,95
Harness, Cab Lower 4-91
Harness, Forward Components 4-87
Harness, Cluster Electrical 4-77
Harness, Front Lights 4-87
Harness, Rear Lights 4-87
Harness, Rear Steering Control 5-139
Harness, Transmission Electrical 4-85
Head Lamp 4-103
Headliner, Cab 9-427,429
Heater, Cab 9-439
Heater, Cylinder Block 2-13
Hitch Depth Control Circuitry 8-325,327
Hitch Control Valve, Depth 8-329,321,333
Hitch Depth Control 8-317,319
Hitch Coupler, Quick 9-357
Hitch Draft Arms 9-339,343

Rac 8-1181

Issued August, 1981 Printed in U.S.A.

MidWestTech | Case 4890 Tractor Parts Catalog | Publication 8-1180 Order the manual at mid-west-tech.com >

CAB
HEADLINER WIRING
PRIOR TO CAB SERIAL NO. 12033908

REF.	PART NO.	DESCRIPTION	REQ'D
1	F 64478	HARNESS ASSEMBLY - headliner wiring	1
2	REF	SWITCH - blower (See Page 9-447)	1
3	F 64443	WIRE - switch to blower motor, red 88" (2235.2 mm)	1
4	A 42624	WIRE - blower switch to air conditioning switch, black 6" (152.4 mm)	1
5	F 64222	HARNESS - wire, blower switch resistor (Cab serial no. 12016090 and after)	1
6	F 44900	RESISTOR - voltage (Cab serial no. 12016090 and after)	1
7	187- 579	SCREW - self-tapping, #10-16 x 1/2" washer head	2
8	REF	SWITCH - wiper (See Page 9-447)	1
9	REF	SWITCH - air conditioning (See Page 9-447)	1
10	REF	SHELL - lighter socket (See Page 9-447)	1
11	REF	SOCKET - lighter (See Page 9-447)	1
12	REF	LAMP - dome (See Page 9-427)	1
13	REF	SWITCH - dome lamp (See Page 9-427)	1
14	F 64126	WIRE - switch to lamp, black 4" (101.6 mm)	1
15	F 64127	WIRE - switch to door switch, white 70" (1778 mm)	1
16	F 64476	WIRE - switch to ground, black 15" (381 mm)	1
17	187- 1088	SCREW - self-tapping, #10-16 x 1/2" Phillips pan head	1
20	F 63895	SWITCH - lamp, door opening	1
21	REF	LAMP - console (See Page 9-427)	1
22	REF	BLOWER ASSEMBLY - (See Page 9-433)	1
23	REF	RADIO - (See Page 9-455)	1

MidWestTech | Case 4890 Tractor Parts Catalog | Publication 8-1180 Order the manual at mid-west-tech.com >

NUMERICAL INDEX

PART NO	PAGE	REF
A 45383	249	22
A 45394	125	19
A 45394	127	19
A 45440	31	23
A 45471	387	25
A 45471	391	53
A 45473	387	29
A 45473	393	3
A 45473	395	3
A 45475	59B	4
A 45475	61B	4
A 45482	387	24
A 45482	391	52
A 45487	387	6
A 45487	399	5
A 45488	387	10
A 45488	399	12
A 45489	387	10
A 45489	391	8
A 45489	399	12
A 45497	389	20
A 45497	393	28
A 45497	395	28
A 45497	401	11
A 45498	393	41
A 45498	401	26
A 45501	389	41
A 45501	397	31
A 45501	401	33
A 45503	389	40
A 45503	397	30
A 45503	401	32
A 45504	389	19
A 45504	393	27
A 45504	395	27
A 45504	401	9
A 45505	389	18
A 45505	393	24
A 45505	395	24
A 45505	401	8
A 45508	401	1
A 45511	401	4
A 45512	389	29
A 45512	393	35
A 45512	395	35
A 45512	401	20
A 45513	389	9
A 45513	393	19
A 45513	395	19
A 45513	401	2
A 45514	397	15
A 45515	389	31
A 45515	393	37
A 45515	395	37
A 45515	401	22
A 45516	389	30
A 45516	393	36
A 45516	395	36
A 45516	401	21
A 45517	389	32
A 45517	393	38
A 45517	395	38
A 45517	401	23
A 45519	393	40
A 45519	397	7
A 45519	399	11
A 45520	397	4
A 45521	397	6
A 45522	389	47
A 45522	397	18
A 45522	401	40
A 45523	389	46
A 45523	397	17
A 45523	401	41
A 45524	397	28
A 45524	401	43
A 45525	397	1
A 45526	397	16
A 45527	387	7
A 45527	399	6
A 45528	387	9
A 45529	387	9
A 45530	389	21
A 45530	393	29
A 45530	395	29
A 45530	401	12
A 45531	389	12
A 45531	393	21
A 45531	395	21
A 45531	401	5
A 45532	393	31
A 45532	401	16
A 45533	393	30
A 45533	401	15
A 45550	401	30
A 45557	41	28
A 45570	399	8
A 45571	399	
A 45572	387	13
A 45572	391	10
A 45572	391	44
A 45576	399	23
A 45577	399	20
A 45579	399	9
A 45580	399	9
A 45583	387	14
A 45583	399	13
A 45584	387	14
A 45584	391	11
A 45584	399	13
A 45604	201	22
A 45604	219	22
A 45605	201	22
A 45605	219	22
A 45606	201	22
A 45606	219	22
A 45607	201	22
A 45607	219	22
A 45609	217	5
A 45612	125	27
A 45613	125	36
A 45613	127	36
A 45614	125	34
A 45614	127	34
A 45615	125	40
A 45615	127	40
A 45616	125	30
A 45616	127	30
A 45627	125	28
A 45627	127	28
A 45629	199	8
A 45629	217	8
A 45630	199	7
A 45630	217	7
A 45633	217	10
A 45666	201	8
A 45666	219	8
A 45668	201	12
A 45668	219	12
A 45669	201	23
A 45669	219	23
A 45670	201	32
A 45670	219	32
A 45671	203	

Rac 8-1181 Issued August, 1981 Printed in U.S.A.

MidWestTech | Case 4890 Tractor Parts Catalog | Publication 8-1180 Order the manual at mid-west-tech.com >

NUMERICAL INDEX

PART NO	PAGE	REF
G 34299	335	7
G 34299	337	7
G 34872	153	11
G 34977	315	4
G 34979	315	5
G 34980	315	3
G 35009	153	17
G 35372	153	6
G 35381	153	
G 35382	153	
G 35510	153	16
G 35514	137	15
G 35514	153	1
G 35515	153	19
G 37418	261	35
G 46081	173	23
G 46143	255	30
G 46146	117	59
G 46146	117	84
G 46146	121	59
G 46146	121	84
G 46176	273	32
G 49020	109	18
G 49080	63	11
G 49402	173	35
G 49622	259	36
G 49623	135	36
G 100448	315	20
G 100448	335	18
G 100449	157	15
G 100714	153	12
G 102020	145	25
G 102020	157	1
G 102021	157	9
G 102025	157	2
G 102029	157	12
G 102094	235	31
G 102424	315	12
G 102424	335	9
G 102424	337	6
G 102569	155	9
G 102569	315	16
G 102569	335	5
G 102569	337	5
G 102728	157	
G 104114	335	16
G 104114	337	16
G 104195	155	13
G 104224	315	17
G 104224	335	6
G 104224	337	9
G 104607	155	7
G 104623	155	1
G 104624	155	20
G 104628	155	2
G 104633	155	
G 104634	155	6
G 104670	155	12
G 104933	315	
G 104933	335	
G 104933	337	
G 104992	155	
G 105435	337	
G 105436	337	15
G 105500	315	
G 105509	337	
H 138248	331	9
H 158592	7	13
H 162974	161	7
H 205070	331	11
H 229203	161	10
H 229203	331	16
H 364497	137	8
H 746172	161	7
H 748218	239	8
H 749218	239	33
H 753525	239	18
H 756627	331	17
H 756783	281	50
H 756783	283	30
H 756783	331	36
H 757492	331	30
L 10007	339	12
L 10088	357	2
L 10120	329	25
L 10175	357	4
L 10177	357	3
L 10261	357	12
L 10262	357	10
L 10263	357	6
L 10264	357	7
L 10264	373	4
L 10462	345	22
L 10463	339	15
L 13452	11	30
L 13765	105	24
L 16415	323	19
L 16415	327	17
L 18331	87	4
L 18331	367	20
L 18331	369	30
L 18331	439	20
L 18331	463	28
L 19294	321	5
L 30032	203	41
L 30032	221	41
L 30674	197	18
L 30674	215	18
L 30674	223	22
L 30674	345	7
L 30674	347	7
L 31204	199	9
L 31204	217	9
L 33062	203	40
L 33062	221	40
L 35261	449	28
L 35261	451	28
L 35305	307	18
L 41213	261	16
L 47157	379	23
L 47157	383	35
L 47158	379	27
L 47158	385	14
L 47158	385	17
L 47159	379	19
L 47159	383	31
L 50541	243	19
L 60332	257	25
L 73646	447	7
L 78623	343	35
N 6856	389	53
R 13911	257	6
R 14668	251	51
R 14668	253	37
R 15023	115	4
R 15023	117	53
R 15023	117	73
R 15115	115	32
R 15115	119	32
R 15145	117	55
R 15145	121	55
R 15159	117	86
R 15159	121	86
R 15161	123	5

Rac 8-1181 Issued August, 1981 Printed in U.S.A.

MidWestTech | Case 4890 Tractor Parts Catalog | Publication 8-1180 Order the manual at mid-west-tech.com >