

Parts Manual

LP3010/3020 Series

MidWestTech | Crown LP3010, LP3020 Series Electric Pallet Jack Parts Manual | Publicati... Order the manual at mid-west-tech.com >

Table of Content

ITD – INTRODUCTION	PAGE	SERIAL NR. CUT	REV.
General	7		
SECTION 1 – COVERS	**PAGE**	**SERIAL NR. CUT**	**REV.**
Covers	12		
Guide Wheels	14		
SECTION 2 – HYDRAULIC PART	**PAGE**	**SERIAL NR. CUT**	**REV.**
Tube-/Hose Layout	18,20,22		
Valve Bloc	24,26		
Pump Motor and Pump	28		
SECTION 3 – DRIVE UNIT	**PAGE**	**SERIAL NR. CUT**	**REV.**
Gearbox	32		
Drive Motor	34		
SECTION 4 – ELECTRICAL	**PAGE**	**SERIAL NR. CUT**	**REV.**
Electrical Parts	38,40,42,44,46,48,50		
Instrument	52,54		
SECTION6 – STEERING	**PAGE**	**SERIAL NR. CUT**	**REV.**
Steering Motor	58		
Steering	60,62		
SECTION 7 – MAST-/LIFT STRUCTURE	**PAGE**	**SERIAL NR. CUT**	**REV.**
Fork Carriage	66		
Yoke	68		
SECTION 8 – CYLINDER	**PAGE**	**SERIAL NR. CUT**	**REV.**
Lift Cylinder	72,74		
SECTION 9 – CABIN/PLATFORM	**PAGE**	**SERIAL NR. CUT**	**REV.**
Platform	78,80,82		

MidWestTech | Crown LP3010, LP3020 Series Electric Pallet Jack Parts Manual | Publ... Order the manual at mid-west-tech.com >