ESR 5000 SERIES
PARTS MANUAL



Order Number: 812746-006
Revision: A • Printed in Germany

MidWestTech | Crown ESR 5000 Series Forklift Parts Manual | Publication 812746-006 Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

INTRODUCTION 1
- **Important Customer Information** 3
  - Ordering Spare Parts 3
  - Truck Modifications 3
  - Maintenance, Repairs and Training 3
  - Manual Structure 3
  - Description of Abbreviations Used 3

COVERS 5
- **Frame** 6
- **Covers Part 1 - 3** 8
- **Covers Part 2 - 3** 10
- **Covers Part 3 - 3** 12
- **Side Door ESR 5000S** 14
- **Skid and Slide Rail** 16
- **Reach Carriage** 18
- **Load Wheel** 20
- **Battery Latch** 22
- **Battery - Eject** 24
- **Battery - Eject** 26
- **Seat Deck ESR 5000** 28
- **Seat Deck ESR 5000S Part 1 - 2** 30
- **Seat Deck ESR 5000S Part 2 - 2** 32
- **Seat Part 1 - 2** 34
- **Seat Part 2 - 2** 36
- **Headrest** 38
- **Rear View Mirror** 40
- **Aisle Guide Wheels ESR 5000** 42
- **Overhead Guard** 44

HYDRAULIC SYSTEM 47
- **ESR 5000 Pipe / Hose Diagram** 48
- **ESR 5000 Pipe / Hose Diagrams** 50
- **Reservoir ESR 5000** 52
- **Reservoir ESR 5000S** 54
- **Mast Part 1 - 2** 56
- **Mast Part 1 - 2** 58
- **Mast Part 2 - 2** 60
- **Mast Part 2 - 2** 62
- **Mast Part 2 - 2** 64
- **Sideshifter** 66
- **Sideshifter For Fifth Valve Function** 68
- **Valve Block** 70
- **Pump Motor and Pump** 72
- **Pump Motor ESR 5000** 74
- **Pump Motor ESR 5000 Australia** 76
- **Pump Motor ESR 5000S** 78

DRIVE UNIT 81
- **Drive Unit** 82

MidWestTech | Crown ESR 5000 Series Forklift Parts Manual | Publication 812746-006 Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

Gear Unit 84
Drive Motor ESR 5000 86
Drive Motor ESR 5000 Australia 88
Drive Motor ESR 5000S 90

ELECTRICAL SYSTEM 93
Electrical Components Part 1 - 3 94
Electrical Components Part 1 - 3 96
Electrical Components Part 2 - 3 98
Electrical Components Part 3 - 3 100
Contactor 102
Cushion / Mast Reach Sensor 104
Cushion / Mast Reach Sensor 106
Height Encoder 108
Mast Wiring 110
Mast Wiring 112
Mast Wiring and Height Encoder 114
Mast Wiring and Height Encoder 116
Fingertip Control Levers 118
Fingertip Control Levers 120
Dual-Axis Hydraulic Control Levers 122
Multi-Task Control Handle 124
Multi-Task Control Handle 126
Floorboard Part 1 - 2 128
Floorboard Part 2 - 2 130
Accelerator Pedal 132
Battery Connector 134
DC /DC Converter 136
Display Panel 138
Beacon 140
Work Lights 142
Travel Alarm 144
Horn 146
Cooling System 148

BRAKE SYSTEM 151
Brake System 152
Brake System 154
Brake Pedal 156
Motor Brake ESR 5000 158
Motor Brake ESR 5000 Australia 160
Motor Brake ESR 5000S 162
Load Wheel Brake 164

STEERING 167
Steer Motor 168
Steering Column 170

LIFTING MECHANISM 173
Mast Part 1 - 2 174
Mast 1.4 t & 1.6 t Part 1 - 2 176
Mast 2.0 t Part 1 - 2 178
Mast Part 2 - 2 180

MidWestTech | Crown ESR 5000 Series Forklift Parts Manual | Publication 812746-006 Order the manual at mid-west-tech.com >

Mast Part 2 - 2 182
Sideshifter 1.4 t / 1.6 t 184
Sideshifter 2.0 t 186
Sideshifter 2.0 t 188
Fork Tines 190
Load Backrest 192
Pulley 194

CYLINDERS 197
Lift Cylinder 1.4 t & 1.6 t 198
Lift Cylinder 2.0 t 200
Lift Cylinder 1.4 t & 1.6 t 202
Lift Cylinder 2.0 t 204
Free Lift Cylinder 1.4 t & 1.6 t 206
Free Lift Cylinder 2.0 t 208
Reach Cylinder 210
Reach Cylinder 212

MISCELLANEOUS 215
InfoLink™ 216
Work Assist™ 218
Clip Pad 220
Trash Bin for Wrapping 222
Miscellaneous 224
Decals and Labels 226
Decals and Labels 228

MidWestTech | Crown ESR 5000 Series Forklift Parts Manual | Publication 812746-006 Order the manual at mid-west-tech.com >