# Model M13K
# Articulated Forklift

# Parts Catalog

8-1400

CASE CONSTRUCTION



Order the manual at mid-west-tech.com >

# ALPHABETICAL INDEX

## A


Accelerator and Linkage ..... 47
Air Cleaner ..... 43
Alternator ..... 63
  Mounting and Adjusting Strap ..... 83
Axle Assemblies ..... 133
  Axle Housing ..... 137
  Differential ..... 139
  Disc Brakes ..... 141
  Planetaries ..... 137
Axle Mounting ..... 133


## B


Battery ..... 81
  Cables ..... 81
Belts
  Alternator and Fan ..... 41
  Compressor ..... 41
  Seat ..... 203
Block, engine cylinder ..... 25
Brake Assemblies and Circuits
  Air Compressor and Related Parts ..... 145, 147
  Air Pressure Protection Valve ..... 157, 169
  Alcohol Evaporator ..... 151
  Brake Actuator ..... 153, 163
  Disc Brakes ..... 141, 155
  Emergency Brake to Safety Chamber ..... 159
  Governor, air compressor ..... 149
  Master Cylinder ..... 163
  Master Cylinder To Wheel Cylinders ..... 155
  Parking Brake, transmission ..... 121
  Safety Chamber ..... 159, 165
  Treadle Assembly ..... 157, 161
  Treadle To Master Cylinder and Reservoir ..... 153
  Treadle To Hydraulic Tank and Horn ..... 157


## C


Cab, operators ..... 213-221
Calipers, brake ..... 140, 155
Camshaft, engine ..... 23
Carriage Assy. ..... 225
Clutch, transmission ..... 115-117
Cold Start System (Ether injection) ..... 87
Compressor - air ..... 145-147
Connecting Rods, engine ..... 31


## C


Control Levers
  Clutch Cutout ..... 153
  Lift Tilt and Fork Spacing ..... 193
  Pedal, accelerator ..... 47
  Pedal, brake (Treadle) ..... 153-161
  Transmission ..... 101-103, 133
Counterweight ..... 197
Conveyor Assy. ..... 229
Crankshaft, engine ..... 27
Cushions, seat ..... 203
Cylinders, brake
  Master ..... 153, 155, 163
  Slave ..... 141
Cylinders, hydraulic
  Tilt, Mast Forks ..... 187
  Lift, Mast Forks ..... 185
  Steering ..... 97
  Fork Spacing, Mast ..... 227


## D


Decals
  Engine Data ..... 19
  Machine ..... 229
Dipsticks
  Brake Reservoirs ..... 171
  Engine Oil ..... 25
  Hydraulic Tank ..... 173
  Transmission Oil ..... 105
Disc Brakes ..... 141-155
Drive Shaft
  Center Bearing ..... 129
  Front, axle end ..... 129
  Front, transmission end ..... 131
  Rear ..... 131, 161


## E


Electrical Systems
  Cold Starting Systems ..... 87
  Instrument Panels ..... 71, 73
  Operators Compartment ..... 219
  Winterization ..... 233
Engine Mount ..... 39



Order the manual at mid-west-tech.com >

# ALPHABETICAL INDEX

## E


Engine Subassemblies
- Alternator ..... 63, 83
- Camshaft ..... 23
- Crankshaft ..... 27
- Cylinder Block ..... 25
- Cylinder Head and Cover ..... 19
- Flywheel and Housing ..... 27, 29, 31
- Fuel Filter System ..... 55
- Fuel Injection System ..... 55
- Gasket Kits ..... 35
- Injection Nozzles ..... 61
- Injection Pump ..... 59
- Injection Pump Drive ..... 57
- Oil Filter and Cooler ..... 15
- Oil Pump and Pan ..... 33
- Manifolds, intake and exhaust ..... 17
- Piston and Connecting Rods ..... 31
- Starter ..... 65, 67, 69, 71-75
- Timing Gear Cover ..... 37
- Valve Mechanism ..... 21
- Water Manifold and Thermostat ..... 11
- Water Pump ..... 13

Evaporator, alcohol ..... 151
Exhaust, pipe and mufflers ..... 45


## F


Fan, radiator ..... 41
- Mounting ..... 13, 41

Filters
- Air Cleaner ..... 43
- Air, governor ..... 149
- Engine Oil ..... 15
- Fuel ..... 49, 55
- Hydraulic Tank ..... 173
- Transmission Oil ..... 107

Flywheel, engine ..... 27
Frames
- Articulated, front ..... 201
- Articulated, rear ..... 197
- Lift, Forks ..... 195

Fuel Injector Nozzles ..... 61
Fuel Lines ..... 49
Fuel Tank ..... 49


## G


Gaskets, engine (Service Kits) ..... 35
Gauges - See Electrical Systems
Gears
- Engine - See Engine Subassemblies
- Transmission - See Transmission Subassemblies

Governor, air compressor ..... 149
Grille ..... 199


## H


Head, engine ..... 19
Heater
- Block, engine ..... 25
- Cab ..... 215

Hood ..... 199
Horn, air ..... 157, 169, 171
Hose, radiator ..... 41
Hoses - See Fuel Lines, Brakes Assemblies and Hydraulic Circuits
Hydraulic Circuit
- Basic Hydraulics ..... 175, 177
- Tilt, Mast ..... 181
- Lift, Mast Fork ..... 179
- Pump To Valve ..... 177
- Steering, pump to cylinders ..... 95
- Steering, valve to reservoir ..... 93
- Transmission ..... 107

Hydraulic Tank Assembly ..... 173


## I


Index, numerical ..... 234
Instrument Panel ..... 71, 73
Instruments - See Gauges


## L


Lights ..... 85
Lift Arm, mechanical parts ..... 195


## M


Manifold
- Exhaust ..... 17
- Intake ..... 17
- Water ..... 11

Mounts
- Axle ..... 133
- Engine ..... 39
- Radiator ..... 41
- Transmission ..... 105

Mufflers ..... 45


## N


Nozzle, fuel injector ..... 61


Printed in U.S.A.

MidWestTech | Case M13K Articulated Forklift Parts Catalog | Publication 8-1400 Order the manual at mid-west-tech.com >

# ALPHABETICAL INDEX


## O

Oil Cooler, engine ..... 15
Oil Pan, engine ..... 35

## P

Parking Brake ..... 121, 159
Pedal, accelerator ..... 47
Pedal, brake (Treadle) ..... 153, 157, 161
Piston Assemblies, engine ..... 31
Pulleys
Air Compressor ..... 143
Alternator ..... 63
Alternator and Fan Drive ..... 83
Fan Mounting ..... 41
Pump Drive, water ..... 13
Pumps
Engine, oil ..... 33
Fuel Injection ..... 59
Fuel, electric ..... 51
Hydraulic Oil ..... 99
Steering ..... 93, 99
Torque Converter ..... 109
Transmission Charging ..... 123
Water, engine ..... 13

## R

Radiator, cooling ..... 41
Regulator, voltage ..... 63
Reservoirs
Air ..... 143-153
Fuel ..... 49
Hydraulic Oil ..... 173, 175
Rims, wheel ..... 135
Rings, engine piston ..... 31
Rocker Arms, engine ..... 21
Rods, connecting ..... 31
Rods, push ..... 21

## S

Safety Chamber ..... 159, 165
Seat Assemblies ..... 203
Shafts
Axle (See Axle Assemblies)
Drive ..... 159, 161
Engine (See Engine Subassemblies)
Transmission (See Transmission Subassemblies) ..... 251
Shroud, radiator ..... 199
Sleeve, piston ..... 31
Solenoid
Starter ..... 69, 77
Starter, engine ..... 65, 67, 69, 71, 73
Starting Aid (Ether Injection) ..... 87

## T

Temperature Sending Unit ..... 11
Thermostat, water temperature ..... 11
Timing Gear Cover, engine ..... 37
Tire Inflation Kit ..... 143
Torque Converter ..... 107
Transmission Mounts ..... 105
Transmission Subassemblies
Axle Output Shaft and Parking Brakes ..... 121
Charging Pump ..... 123
Control Valve ..... 123, 125
Converter Housing, Gears and Transmission Housing ..... 111
Forward Clutch and Planetary ..... 117
Front Cover, Input Shaft and Torque Converter ..... 109
High Range Clutch and Transfer Gear ..... 119
Hydraulic System ..... 107
Overhaul Kit ..... 127
Reverse Clutch and Planetary ..... 115
Turbine Driven Gears and Freewheel Unit ..... 113
Trunnion, rear frame ..... 197

## V

Valve Mechanism, engine ..... 21
Valve Parts, hydraulic control ..... 189
Valves
Air Shutoff ..... 157
Air Pressure Protection ..... 157-159
Air Pressure Regulator ..... 159, 167, 187, 197
Brake Control ..... 159, 161, 187, 191
Breather, axle ..... 137
Breather, transmission ..... 111
Clutch Cutout ..... 153
Emergency Brake ..... 159
Drain, air reservoir ..... 153
Drain, engine oil cooler ..... 15
Drain, radiator ..... 41
Flow Control, steering ..... 93
Horn ..... 169
Valve Control, 3 spool ..... 189, 193
Tire, valve stem ..... 135
Torque Converter ..... 111
Transmission Control ..... 123, 125
Check, double ..... 153, 167

## W

Wheel, steering ..... 89
Wheel, tire ..... 135
Windows - cab ..... 217
Winterization type "A" ..... 233
Wiper, windshield ..... 209, 211
Wire - See Electrical Circuits


MidWestTech | Case M13K Articulated Forklift Parts Catalog | Publication 8-1400 Order the manual at mid-west-tech.com >