580 Super E Construction King Loader Backhoe

Parts Catalog

8-1833

CASE CONSTRUCTION

MidWestTech | Case 580 Super E Construction King Loader Backhoe Parts Catalog | Publication 8-1833

Order the manual at mid-west-tech.com >

580 SUPER E CONSTRUCTION KING LOADER BACKHOE
PICTORIAL INDEX



	CODE	PAG.
	1	1-11
ENGINES	2	12-73
FUEL SYSTEM	3	74-81
ELECTRICAL	4	82-151
STEERING SYSTEM	5	152
POWER TRAIN	6	172-273
BRAKES	7	274-305
HYDRAULIC SYSTEM	8	306-487
CHASSIS/ MOUNTED EQUIPMENT	9	
Loader Controls	9	488-495

MidWestTech | Case 580 Super E Construction King Loader Backhoe Parts Catalog | Publi... Order the manual at mid-west-tech.com >



















	CODE	PAGES
Loader Frames	9	496-505
Backhoe Controls	9	506-521
Backhoe Frames	9	522-555
Hitch Controls	9	556-557
Hitch Frames	9	558-573
Chassis/ Sheet Metal	9	574-595
Seat	9	596-613
Cab	9	614-661
Canopy/ Miscellaneous	9	662-675
NUMERICAL INDEX	10	676-

Printed in U.S.A. 861570 Issued December, 1986

MidWestTech | Case 580 Super E Construction King Loader Backhoe Parts Catalog | Publi... Order the manual at mid-west-tech.com >

ALPHABETICAL INDEX

A

Air Cleaner 17-23
Air Conditioner
  Blower 651
  Compressor 93
  Compressor Mounting 97,99
  Condenser 661
  Controls 633,657
  Evaporator 657
  Filter 649
  Receiver-Drier 659
Alarm - backup 141
Alarm - parking brake 143
Alternator - electrical 87-91
Alternator Mounting 95
Antirollback-loader 493
Axle
  Front - four wheel drive 207-237
  Front - two wheel drive 167
  Rear 263

B

Backhoe
  Boom 531
  Buckets 545-555
  Controls (See Controls)
  Control Tower 507
  Coupler - bucket 539
  Dipper 537
  Extendable Dipper 541
  Frame and Mounting Parts 523,525
  Frost Tooth 539
  Hydraulics (See Hydraulic Circuits)
  Stabilizers 523
  Swing Tower 527,529
Backup Alarm 141
Battery 101,105
Beacon - rotating 145,147
Bearings - front wheel 169
Belts - fan, alternator, and
  compressor 15,35,95,97
Belts - seat 597,599
Blade - loader 505
Boom Latch 535
Boom Lock 381,517
Box - operators tool 667
Brake Alarm - parking 143
Brake Master Cylinder 297,299
Brake System 275-305
Buckets - backhoe 545-555

B

Buckets - loader 501,503

C

Cab 615-661
  Air Conditioner, Heater, and
    Defroster 651-661
  Air Filter 649
  Blower 651
  Doors and Windows 621-631
  Electrical and Lighting 129-137,633,659
  Frame 617
  Glass and Moldings 629,631
  Headliner 647
  Mounting Parts 615
  Panel - cab control 633
  Panels - closure, cab to tractor 591,593
  Windshield Wipers 635-645
Canopy - ROPS 663
Chassis - tractor 575
Clutch Cutout - power shuttle 121
Cold Start System 25,27,105
Column - steering 153,161,163
Compressor - air conditioner 93
Compressor Mounting 97,99
Controls
  Backhoe 509-521
  Brake 289,301,305
  Boom Latch 535
  Boom Lock 517
  Clutch Cutout 121
  Engine Speed - throttle 71,73
  Extendable Dipper 519,521
  Front Axle Drive - 4WD 207,209
  Hitch - three-point 557
  Loader 489-495
  Loader Bucket Positioning 493,495
  Power Shuttle 195
  Steering 153
  Transmission Shift 245
Control Tower - backhoe 507
Converter - torque 175
Cooling Systems
  Engine 13,15
  Engine Oil 41
  Hydraulic Oil 325-333
  Power Shuttle 177-181
Counterweights 571,573
Coupler - backhoe bucket 539
Couplings - hydraulic line disconnect 459

8-1833

Issued December, 1986 Printed in U.S.A.

MidWestTech | Case 580 Super E Construction King Loader Backhoe Parts Catalog | Publi... Order the manual at mid-west-tech.com >