2294 Tractor

Parts Catalog

8-1952

CASE

MidWestTech | Case 2294 Tractor Parts Catalog | Publication 8-1952

Order the manual at mid-west-tech.com >

ALPHABETICAL INDEX

A

Accumulator, Emergency Brake ... 7-301,303
Acoustical Covers, Cab 9-513
Adapters, Hydraulic Coupling 8-387
Air Cleaner 2-11
Air Conditioning Compressor Clutch .. 9-543
Air Conditioning, Cab 9-535
Air Conditioning Hoses 9-545
Air Conditioning Evaporator 9-531,533
Air Conditioning Condenser 9-545
Air Conditioning Compressor 9-547
Air Conditioning Blower Assembly 9-521
Air Conditioning Receiver-Drier 9-545
Air Conditioning Expansion Valve 9-535
Air Conditioning Switches 9-517
Air Filter, Cab 9-519
Air Restriction Switch 2-11
Alternator Assembly 4-97,99
Alternator Mounting 4-95
Antenna Kit, Radio 4-115
Arm, Draft 9-411,413
Arm, Draft (Telescoping) 9-415
Arm, Steering 5-137,139
Aspirator Tube, Engine 2-11
Auxiliary Electric Outlet 4-67,83
Auxiliary Outlet Harness 4-67,83
Axle, Front 5-137,139
Axle, Front (MFD) ..... 5-147 through 5-161
Axle, Rear, 120 Inch 6-243,245
Axle, Rear, 96 Inch 6-241,245

B

Battery 4-87
Battery Cables 4-87
Battery Holder Box 4-87
Bearing, Engine Main 2-35
Belt, Fan 2-9
Belt, Seat 9-467
Block, Cylinder 2-33
Blower Assembly, Cab Air 9-521
Brake, Differential 6-237
Brake Pedals 7-285
Brake, PTO 6-279
Brake Valve Assembly 7-289,291,295
Brake Valve, Master 7-293
Breaker, Circuit 4-85
Bushings, Camshaft 2-31

C

Cab Assembly 9-499
Cab Lights 4-75

C

Cab Mounts and Supports 9-487
Cable, Battery 4-87
Cable, Cab Heat Control 9-519
Caliper Disc Brake 7-311
Camshaft, Engine 2-31
Camshaft Bushings 2-31
Cap, Main Bearing 2-33
Center Wheel, Transmission 6-235
Cigar Lighter 4-61
Circuit Breaker 4-85
Cluster, Instrument 4-81
Clutch, Air Compressor 9-543
Clutch, PTO 6-279
Clutch Housing 6-181
Clutches, (C1) and (C4) 6-205
Clutches, (C2) and (C3) 6-211,213
Cold Start Switch 2-13
Compensator, Hydraulic Pump 8-337
Compressor, Air 9-547
Condenser, Air Conditioning 9-545
Connecting Rod 2-37
Connecting Rod Bearing 2-37
Control Console 9-439
Coolant Indicator Module 4-73
Cooler, Engine Oil 2-25
Cooler, Hydraulic Oil 5-127
Core, Evaporator 9-531,533
Core, Heater 9-427,529
Countershaft, Transmission 6-233
Coupler, Quick Hitch 9-417,419
Couplings, Hydraulic 8-387
Cover, Cylinder Head 2-27
Covers, Trans. Without Hitch 6-191
Crankshaft, Engine 2-35
Cylinder Assembly, Remote _ 8-389
Remote Hydraulic 8-359,361
Cylinder Block, Engine 2-33
Cylinder Block Gasket Kit 2-43
Cylinder Block Heater 2-13
Cylinder Head, Engine 2-27
Cylinder Assembly, Steering 5-133

D

Decals, French Language 9-477,479,481
Decals, Safety 9-481
Decals, Tractor 9-477,479
Defroster, Cab Windshield 9-515
Differential Assembly 6-235,237
Differential Assembly (MFD) .. 5-147,149,151
Differential Brake 6-237

Rac 8-1952

Issued October, 1985 Printed in U.S.A.

MidWestTech | Case 2294 Tractor Parts Catalog | Publication 8-1952 Order the manual at mid-west-tech.com >

ALPHABETICAL INDEX

D

Differential Clutch 6-235
Differential Lock Harness 4-61
Differential Lock Mechanism 6-239
Dipstick, Engine Oil 2-33
Dipstick, Transmission Oil 6-189
Door, Cab 9-501
Draft Arms, Hitch 9-411,413
Draft Arms, Hitch (Telescoping) 9-415
Draft Sensing Linkage 8-393
Drawbar 9-421
Drawbar, Special Wide Swing 9-423
Drive, Fuel Injection Pump 3-45

E

Electric Outlet, Auxiliary 4-67,83
Electric Shift Harness 4-79
Electrical Harness, Auxiliary Outlet .. 4-67,83
Electrical Harness, Cab Headliner 4-75
Electrical Harness, Cab Lower 4-61
Electrical Harness, Fwd. Components .. 4-73
Electrical Harness, Engine 4-65
Electrical Harness, Rear Component ... 4-69
Electrical Harness, Transmission 4-67
Electric Power Attachment
(Implement Monitor) 4-117
Emergency Hand Brake .. 7-301 through 7-307
Engaging Control (MFD) 6-219
Engine Cylinder Block 2-33
Engine Block Heater 2-13
Engine Cylinder Head 2-27
Engine Crankshaft 2-35
Engine Shut Off, Automatic 4-113
Ether Starting Kit 2-13
Evaporator, Air Conditioning 9-531,533
Exchanger, Engine Oil Heat 2-25
Exhaust System 2-15,17

F

Fan, Engine 2-9
Fan Belt 2-9
Filter, Cab Air 9-519
Filter, Engine Fuel 3-49
Filter, Engine Oil 2-25
Filter, Hydraulic Oil 8-321
Filter, Water 2-7
Flasher Switch 4-61
Flasher Warning Lamp 4-101
Flood Lamp, Front 4-105
Flood Lamp, Rear 4-105
Flood Lamp, Upper 4-107

F

Flow Control Kit (Remote Hydraulic) .. 8-431
Flywheel, Engine 2-35
Foot Inching Pedal 6-201
Forward Component Harness 4-73
Four Post ROPS Wiring 4-77
Frame, Cab 9-499
Frame, Protective 9-495
Frame, Weight 9-427
Front Axle Support (MFD) 5-141,143
Front Fenders (For MFD Tractor) 9-551
Front Lamp Harness 4-73
Front Wheel 5-175
Front Wheel, MFD 5-177,179
Fuel Filter System 3-49
Fuel Injection Pump 3-47
Fuel Injection Pump Drive 3-45
Fuel Injection System 3-51
Fuel Injector 3-53,55
Fuel Shut Off Control 3-57
Fuel Tank 3-59
Fuel Tank Level Sender 3-59
Fuel Tank Repair Kit 3-59
Fuses, Cab 4-63
Fuses, Tractor 4-63
Fuse Block, Cab 4-63
Fuse Holder, Tractor 4-63

G

Gasket Kits, Engine 2-41,43
Gasket Kits, Engine Oil Pan 2-43
Gear, Bevel, Transmission 6-235
Gear, Park Lock 6-233,239
Gear, Pinion, Transmission 6-235
Gear Shift Linkage 6-195
Glass, Cab 9-509
Grille Kit, Radio Speaker 9-515
Grille, Front Lower 9-433
Grille, Front Upper 9-435
Ground Speed Attachment 4-113
Guide, Engine Valve 2-29

H

Hand Brake, Emergency . 7-301 through 7-307
Hand Brake, Parking 7-309
Harness, Auxiliary Outlet 4-67,83
Harness, Cab Headliner 4-75
Harness, Cab Lower 4-61
Harness, Forward Components 4-73
Harness, Engine Electrical 4-65
Harness, Rear Component 4-69

Rac 8-1952 Issued October, 1985 Printed in U.S.A.

MidWestTech | Case 2294 Tractor Parts Catalog | Publication 8-1952 Order the manual at mid-west-tech.com >

ALPHABETICAL INDEX

H

Harness, Transmission Electrical 4-67
Head Lamp 4-103
Headliner, Cab 9-515
Heat Exchanger, Engine Oil 2-25
Heater, Cab 9-527,529
Heater, Cylinder Block 2-13
Hitch Control Valve 8-403
Hitch Depth Control Linkage 8-391
Hitch Depth Sensing Linkage 8-393
Hitch Draft Arms 9-411,413
Hitch Draft Arms (Telescoping) 9-415
Hitch Hydraulic Circuit 8-401
Hitch Rockshaft 8-395
Holder, Fuse (Tractor) 4-63
Hood, Upper 9-435
Hood Latch 9-431
Hood Supports 9-429
Hoses, Cab Air Conditioning 9-535
Hoses and Adapters, Remote 8-385
Housing, Rear Axle, 120 Inch 6-243,245
Housing, Rear Axle, 96 Inch 6-241,245
Hub, Front Wheel 5-175
Hydraulic Charging Pump 8-317
Hydraulic Circuit, Hitch Control 8-401
Hydraulic Circuit, PTO 8-313
Hydraulic Manifold, Elec. Shift 6-183,185
Hydraulic Oil Filter and Screen 8-321
Hydraulic Oil Cooler 5-127
Hydraulic Pump Assembly 8-329
Hydraulic Pump Circuit 8-319
Hydraulics, Power Shift 8-315

I

Inching Pedal 6-201
Injection System, Engine Fuel 3-51
Insert, Connecting Rod 2-37
Insert, Main Bearing 2-35
Insert, Exhaust Valve 2-29
Instrument Cluster 4-81
Instrument Panel 9-437
Intermediate Shaft 6-217

K

Key, Starting and Door 4-61,4-501

L

Lamp, Cab Mounted 4-75
Lamp, Flasher Warning 4-101
Lamp, Head 4-101
Lamp, Instrument Cluster 4-81

L

Lamp Assembly, Cab Courtesy 9-515
Lamp Assembly, Cab Dome 9-515
Latch, Hood Lock 9-429
Lifter, Push Rod 2-29
Light Switch 4-61
Lighter, Cigar 4-61
Linkage, Draft Control 8-391
Linkage, Draft Sensing 8-393
Linkage, Power Shift 6-193
Linkage, Range Shift 6-199
Lock, Differential 7-297
Louvers, Cab Air 9-515

M

Manifold, Electric Shift 6-185
Manifold, Exhaust 2-15
Manifold, Intake 2-15
Manifold, Water 2-5
Master Brake Valve 7-293
Mats, Floor 9-511
Mirrors, Cab 9-549
Muffler, Vertical 2-21
Muffler, Vertical Attachment 2-23

N

Nozzle, Ether Injector 2-13
Nozzle, Fuel Injector 3-53,55

O

Oil Cooler, Engine 2-25
Oil Cooler, Hydraulic 5-127
Oil Filter, Engine 2-25
Oil Filter, Hydraulic 8-321
Oil Pan, Engine 2-41
Oil Pan Gasket 2-43
Oil Pressure Switch, Hydraulic 8-313
Oil Pump, Engine 2-39
Operators Manual Box 9-437

P

Pan, Engine Oil 2-41
Pan, Evaporator 9-531,533
Panel, Cab Controls 9-517
Panel, Instrument 9-437
Panels, Side Front 9-433
Panels, Side Rear 9-435
Park Lock Control 6-197
Parking Hand Brake 7-309
Pedals, Brake 7-285
Piston, Engine 2-37

Rac 8-1952 Issued October, 1985 Printed in U.S.A.

MidWestTech | Case 2294 Tractor Parts Catalog | Publication 8-1952 Order the manual at mid-west-tech.com >

STEERING SYSTEM
MFD TRACTORS
CARRARO AXLE

REF.		PART NO.	DESCRIPTION	REQ'D
1		REF	CYLINDER ASSEMBLY - steering (See Page 5-135)	2
2	K	260225	ELBOW - hose to cylinder (Carraro No. 101522)	4
3	A	164626	HOSE - steering hydraulic	2
4	218-	845	TEE - steering connector	2
5	218-	5173	ELBOW ASSEMBLY - 45 degrees swivel, 1/2 tube 3/4-16 inch thread	1
7	A	163194	TUBE - steering, left (Carraro No. 110896)	1
8	A	163195	TUBE - steering, right (Carraro No. 110895)(Prior to P.I.N. 9931825) (Order A180091 and A180092)	1
8	A	180092	TUBE - steering, right (P.I.N. 9931825 and after)	1
9	K	956973	GUARD - hose protective (Carraro No. 107739)	2
10	214-	263	CLAMP - hose retaining	2
11	A	163199	BRACKET - hose to axle retaining (Carraro No. 110645) (Prior to P.I.N 9931825)(Order A180091 and A180092)	1
11	A	180091	BRACKET - hose to axle retaining (P.I.N. 9931825 and after)	1
12	A	67290	BRACKET - steering hose support	1
13	A	67289	SPACER - hose support bracket	1
14	R	12102	CLAMP - hose (Order D20302)	2
15	113-	4	BOLT - hex, 1/4 NC x 1 inch	2
16	131-	461	NUT - hex lock, 1/4 inch NC	2
17		REF	HOSE - left, cylinder to steering pump (See Page 5-123)	1
18		REF	HOSE - right, cylinder to steering pump (See Page 5-123)	1
19	R	38237	STRAP - hose retaining (Order L18337)	1

MidWestTech | Case 2294 Tractor Parts Catalog | Publication 8-1952 Order the manual at mid-west-tech.com >

REMOTE HYDRAULICS
REMOTE ATTACHMENT - NO. 4 CIRCUIT

REF.		PART NO.		DESCRIPTION	REQ'D
	A	180263	†	ATTACHMENT - remote hydraulics, No. 4 circuit (Continued from Page 8-355)(Replaces A67589)	1
	A	67536		ATTACHMENT - remote hydraulics, No. 4 circuit (Continued from Page 8-355)	1
35		REF		BODY - remote valve (See Inset A)(See Page 8-367)	1
35		REF		BODY - remote valve (See Inset B)(See Page 8-369)	1
36	A	47576		KIT - seal, with shims (See Page 8-359)(Order components)	UAR
37		REF		COUPLING - remote hydraulic, female (See Page 8-387)	2
38	A	149221	†	RETAINER - coupling	2
39	A	137976		RING - snap, coupling to cab	4
40	A	145468		PLUG - remote coupling dust (In A67536 attachment)	1
41	A	162364		FASTENER - dust plug (In A67536 attachment)	1
47	218-	5062		CONNECTOR ASSEMBLY - straight, 5/8 tube 7/8-14 inch thread	2
48	218-	5007		O-RING - 3/4 x 5/8 x 3/32 inch (19 x 16 x 2 mm)	1
49	A	145907		HOSE - No. 7 remote coupling	1
50	A	145908		HOSE - No. 8 remote coupling	1
51	A	63323		CLAMP - tube to tube	2
52	113-	103		BOLT - hex, 5/16 NC x 1 inch	1
53	192-	20		WASHER - lock, 5/16 inch	1
54	129-	102		NUT - hex, 5/16 inch NC	1
55	A	147508		STUD - valve mounting, 11-3/4 inch	3
56	A	177479	†	CAP - dust (In A180263 attachment)	2
57	A	180178	†	HOSE - drain (In A180263 attachment)	2
58	A	180159	†	CLAMP - hose retaining (In A180263 attachment)	2
59	A	180154	†	CLAMP - hose retaining (In A180263 attachment)	1

MidWestTech | Case 2294 Tractor Parts Catalog | Publication 8-1952 Order the manual at mid-west-tech.com >

NUMERICAL INDEX

PART NO	PAGE	REF
A 153323	37	2
A 153336	211	1
A 153400	279	28
A 153571	233	
A 153638	37	8
A 153805	39	1
A 153811	215	6
A 153816	51	24
A 153835	33	31
A 153891	233	19
A 153892	233	12
A 153946	35	35
A 153951	199	12
A 153952	199	13
A 153988	235	7
A 154013	235	15
A 154014	7	21
A 154051	7	15
A 154053	7	19
A 154065	7	26
A 154283	67	13
A 154283	277	10
A 154305	35	1
A 154389	33	9
A 154390	33	7
A 154391	33	6
A 154392	33	8
A 154424	17	35
A 154446	15	1
A 154463	239	13
A 154464	239	12
A 154527	239	18
A 154541	25	1
A 154607	237	26
A 154647	317	14
A 154648	207	10
A 154648	209	10
A 154658	37	12
A 154667	217	7
A 154684	35	32
A 154691	189	41
A 154742	233	30
A 154767	33	30
A 154770	7	16
A 154782	11	9
A 154782	65	2
A 154890	235	8
A 154891	235	9
A 154932	279	49
A 154957	243	22
A 155047	9	28
A 155160	237	42
A 155225	243	4
A 155226	241	22
A 155436	13	20
A 155461	211	3
A 155461	213	3
A 155489	49	1
A 155612	281	11
A 155613	281	10
A 155636	233	7
A 155636	239	24
A 155684	317	15
A 155804	211	19
A 155859	203	4
A 155861	199	6
A 155861	239	5
A 155861	239	20
A 155862	239	21
A 155865	203	6
A 155962	279	38
A 155963	279	34
A 155964	279	35
A 155980	39	3
A 156020	177	2
A 156097	27	10
A 156185	391	30
A 156185	393	21
A 156284	279	46
A 156294	279	25
A 156323	53	
A 156323	55	
A 156355	225	2
A 156355	227	1
A 156428	35	13
A 156555	79	22
A 156555	185	9
A 156561	233	1
A 156562	233	33
A 156564	221	29
A 156564	223	29
A 156565	221	32
A 156565	223	32
A 156567	221	27
A 156567	223	27
A 156567	225	6
A 156567	227	6
A 156567	229	6
A 156567	231	6
A 156571	225	36
A 156571	227	36
A 156571	229	36
A 156571	231	36
A 156572	225	37
A 156572	227	37
A 156572	229	37
A 156572	231	37
A 156573	225	26
A 156573	227	26
A 156576	225	28
A 156576	227	28
A 156577	225	43
A 156577	227	43
A 156577	229	43
A 156577	231	43
A 156578	225	40
A 156578	227	40
A 156578	229	40
A 156578	231	40
A 156579	225	39
A 156579	227	39
A 156579	229	39
A 156579	231	39
A 156580	225	10
A 156580	229	10
A 156581	225	11
A 156581	229	11
A 156582	225	9
A 156582	229	9
A 156583	225	15
A 156583	229	49
A 156584	225	20
A 156584	227	20
A 156585	225	42
A 156585	227	42
A 156585	229	42
A 156585	231	42
A 156586	225	23
A 156586	227	23
A 156586	229	23
A 156586	231	23
A 156587	225	22
A 156587	227	22
A 156587	229	22

Rac 8-1952 Issued October, 1985 Printed in U.S.A.

MidWestTech | Case 2294 Tractor Parts Catalog | Publication 8-1952 Order the manual at mid-west-tech.com >