1280 Crawler Excavator

Parts Catalog

8-2090

CASE CONSTRUCTION

Order the manual at mid-west-tech.com >

GENERAL INFORMATION

Indexes

This parts catalog is arranged for easy identification on parts The Alphabetical Index at the front of the catalog gives location of major groups and assemblies The Numerical Index at the rear of the catalog gives part numbers and the page on which they are listed

Abbreviations and Terms

PIN - Product Identification Number
SN - Serial Number
NSS - Not sold separately
REF - Reference Used to clarify drawing
RESERVED - No item listed
UAR - Use as required

Changes

When changes are made to the machine, revised pages for this catalog will be issued These pages must be inserted into your catalog as soon as they are received Failure to keep your catalog up to date will result in confusion and may cause you to order wrong parts

Orders

Orders should specify correct part number, full description, quantity required, machine and engine model, machine and engine serial numbers, method of shipment and shipping address

Right-Hand and Left-Hand Sides

The terms right-hand and left-hand (abbreviated to RH and LH) as used in this catalog indicate the right and left sides of the machine as viewed by the operator in the normal operating position for proper operation of the machine or attachment

U S and Metric Units

Sizes, lengths, and dimensions are given in U S units followed by its equivalent in metric units See item 8 below Sizes of hardware (bolts, nuts, etc) are given according to hardware type — in inches for U S hardware, in millimeter for metric hardware See items 9 and 10

Description, Quantity and Machinery Items

All parts are briefly described under DESCRIPTION The quanitity used is listed under REQ'D Notice in the example below that the description of some items is moved in (indented) from the left-hand margin An indented item is part of the item under which it is indented The example shows that one hydraulic oil filter is used on the machine Each filter contains one head assembly, one element kit, and one housing (indented items with no reference numbers and item 6) The head assembly and kit are further divided to show individual part (items 2, 3, 4 & 5)

Machinery items must be ordered from the Machinery Price List See item 7 in the example

REF	PART NO		DESCRIPTION	REQ'D
1	D	43567	FILTER ASSEMBLY - hydraulic oil	1
	D	61903	HEAD ASSEMBLY - filter	1
2		NSS	HEAD - filter	1
3	D	58199	VALVE - bypass	1
	D	43800	KIT - filter element	1
4		NSS	ELEMENT - filter	1
5	A	27994	O-RING - filter	1
6	D	42439	HOUSING - filter	1
7		REF	CANOPY - ROPS, machinery item, see page 2 for ordering	2
8	R	42849	HOSE - from upper valve port, 38" (965 mm) long	1
9	13-	728	BOLT - hex head, 7/16" - 14 NC x 1-3/4"	2
10	814-	8030	BOLT - hex head, 8 mm - 1 25 x 30 mm (8 8)	2

8007328

Order the manual at mid-west-tech.com >