680K Construction King Loader Backhoe

Parts Catalog

8-2261

CASE CONSTRUCTION

MidWestTech | Case 680K Construction King Loader Backhoe Parts Catalog | Publication 8-2261

Order the manual at mid-west-tech.com >

PICTORIAL SECTION INDEX









GENERAL 1

ENGINE 2



FUEL 3

ELECTRICAL 4



STEERING 5

POWER TRAIN 6



BRAKES 7

HYDRAULICS 8



CHASSIS/ MOUNTED EQUIPMENT 9

NUMERICAL INDEX 10

B1685A88J

Bur 8-2261 Issued September, 1988 Printed in U.S.A.

MidWestTech | Case 680K Construction King Loader Backhoe Parts Catalog | Publication 8... Order the manual at mid-west-tech.com >

GENERAL INFORMATION

Indexes

Section 1 of this catalog contains a SN and P.I.N. location guide, alphabetical index, pictorial index of the sections included, and pictorial index(es) for quick location of hoses and tubes (and other system components in some catalogs). An alphabetical index also appears at the beginning of each section. Section 10 is the Numerical Index which lists all part numbers in alpha/numeric order with their page location and reference number.

Illustration and Text

The arrangement of this parts catalog is for easy identification of parts. All parts are illustrated in "exploded views" in proper relation to each other. Reference numbers used in the illustrations refer to those on the text pages. The text pages list reference number, part number, part description and the quantity required.

Abbreviations

P.I.N. "Product Identification Number"
SN "Serial Number"
NSS "Not Serviced Separately" in the part number column indicates this part is not available for service.
REF "Reference" in the part number column indicates this part has special service information. The page where this information can be found is given in the part description column.
UAR "Use As Required" in the quantity required column indicates the number of parts used is determined by service needs.

Right-Hand and Left-Hand Identification

The reference to right-hand and left-hand in this catalog is identified by the operator standing at the rear of the basic unit (without rear attachment), looking toward the front of the machine (in normal forward travel). For pages covering any machine attachments, right-hand and left-hand are defined by the operator sitting in the position for proper operation of the attachment.

Catalog Revisions and Supplements

Changes to the product may make it necessary to revise or add pages to this catalog. A cover sheet will list all pages released in a revision or supplement. Each new or revised page will have a new issue date. All revised and new pages must be put into the parts catalog as soon as they are received.

Parts Orders

Orders must specify product model, all necessary serial numbers, correct part number, complete description, quantity required, method of shipment, and shipping address.

Text Format Explanation

An assembly may contain many service items. The component parts of an assembly or subassembly are indented. The quantity required column lists the number of assemblies required for a complete machine, and the number of components required in a complete assembly or subassembly.

The example below illustrates the use of indents and other text page elements explained on this page.

REF.	PART NO.	DESCRIPTION	REQ'D.
1	D43567	FILTER ASSEMBLY - hydraulic oil, PIN 7534840 and after	1
	D61903	HEAD ASSEMBLY - filter	1
2	NSS	HEAD - filter, order D61903 head assembly	1
3	D58199	VALVE - bypass	1
	D43800	KIT - filter element, replaces D35700 kit	1
4	NSS	ELEMENT - filter, order D43800 element kit	1
5	A27994	O-RING - filter	1
6	D61948	HOUSING - filter	1
7	REF	CANOPY - ROPS, machinery item, order from Machinery Price List	1
8	843065C1	HOSE - 132 inch (3353 mm) long, reservoir to pump	1
9	113-323	BOLT - hex head, 7/16 - 14 NC x 1-3/4 inch, plated	2
10	814-8030	BOLT - hex head, 8 mm - 1.25 x 30 mm (8.8), plated	4

MidWestTech | Case 680K Construction King Loader Backhoe Parts Catalog | Publication 8... Order the manual at mid-west-tech.com >

ALPHABETICAL INDEX

A

Actuator - brake 7-241,7-243
Air Cleaner 2-19
Air Conditioner
  Blower 9-499
  Compressor and Clutch 9-509
  Compressor Mounting 9-507
  Condenser 9-505
  Controls 9-483,9-485
  Evaporator 9-503
  Filter 9-497
  Receiver-Drier 9-505
Alarm - backup 4-127
Alarm - warning buzzer 4-99,4-101
Alcohol Evaporator 7-245
Alternator - electrical ..... 4-75 - 4-79
Alternator Mounting 4-85
Antirollback - loader 9-367
Axle
  Front 5-159,5-161
  Rear ..... 6-205 - 7-217
  Rear Axle Mounting 6-203
  Rear Brakes 7-215,7-217

B

Backhoe
  Boom 9-397
  Buckets ..... 9-409 - 9-421
  Controls (See Controls)
  Control Tower 9-381
  Dipper 9-401,9-403
  Extendable Dipper 9-405,9-407
  Frame and Mounting Parts 9-395
  Hydraulics (See Hydraulic Circuits)
  Stabilizers 9-395
  Swing Tower 9-397
Backup Alarm 4-127
Battery 4-87
Beacon - rotating 4-133,4-135
Bearings - engine
  Camshaft 2-41
  Main 2-47
  Rod 2-51
Belts
  Air Conditioner Compressor 9-507
  Brake Air Compressor 7-219
  Fan and Alternator 2-13
  Seat 9-447,9-449
  Water Pump Tensioner 2-27
Boom Latch 9-399

B

Boom Lock 8-283,8-285
Box - operators manual and tool 9-431
Brake System
  Air Pressure Protection Valve 7-239
  Alcohol Evaporator 7-245
  Brake Actuator 7-241,7-243
  Clutch Cutout Valve 7-239
  Compressor - air brake system 7-233
  Compressor Mounting 7-219
  Compressor to Reservoir 7-221
  Parking Brake Valve 7-231
  Pressure Reducing Valve 7-231
  Reservoir - air 7-221,7-223
  Treadle Assembly 7-237
  Treadle to Clutch Cutout Valve 7-229
  Treadle to Parking Brake Valve 7-229
  Treadle to Reservoir 7-223,7-225
  Unloading Valve - air compressor 7-235
Breaker Fork - concrete 9-423
Buckets - backhoe ..... 9-409 - 9-421
Buckets - loader ..... 9-375 - 9-379

C

Cab
  Air Conditioner, Heater, and
    Defroster ..... 9-497 - 9-507
  Air Filter 9-497
  Blower 9-499
  Doors and Windows ..... 9-471 - 9-477
  Electrical and Lighting
    4-99,4-101,4-113-4-121,9-467
  Frame 9-465,9-467
  Glass and Moldings 9-479,9-481
  Headliner 9-495
  Line Covers - heating and air
    conditioning 9-469
  Mounting Parts 9-465
  Panel - cab control 9-483,9-485
  Panel - closure 9-465
  Windshield Wipers ..... 9-487 - 9-493
Canopy - ROPS 9-511
Chassis - tractor 9-427,9-429
Clutch - air conditioner 9-509
Clutch Cutout - brake system 7-239
Cold Start System 2-21
Column - steering 5-155
Compressor - air conditioner 9-509
Compressor - brake air 7-233
Concrete Breaker Fork 9-423

Bur 8-2261

Issued September, 1988 Printed in U.S.A.

MidWestTech | Case 680K Construction King Loader Backhoe Parts Catalog | Publication 8... Order the manual at mid-west-tech.com >