780C
Construction King Loader Backhoe

Parts Catalog

8-2271

CASE CONSTRUCTION

Order the manual at mid-west-tech.com >

PICTORIAL SECTION INDEX









GENERAL 1

ENGINE 2



FUEL 3

ELECTRICAL 4



STEERING 5

POWER TRAIN 6



BRAKES 7

HYDRAULICS 8



CHASSIS/ MOUNTED EQUIPMENT 9

NUMERICAL INDEX 10

851734A

Bur 8-2271 Issued September, 1988 Printed in U.S.A.

MidWestTech | Case 780C Construction King Loader Backhoe Parts Catalog | Publication... Order the manual at mid-west-tech.com >

GENERAL INFORMATION

Indexes

Section 1 of this catalog contains a SN and P.I.N. location guide, alphabetical index, pictorial index of the sections included, and pictorial index(es) for quick location of hoses and tubes (and other system components in some catalogs). An alphabetical index also appears at the beginning of each section. Section 10 is the Numerical Index which lists all part numbers in alpha/numeric order with their page location and reference number.

Illustration and Text

The arrangement of this parts catalog is for easy identification of parts. All parts are illustrated in "exploded views" in proper relation to each other. Reference numbers used in the illustrations refer to those on the text pages. The text pages list reference number, part number, part description and the quantity required.

Abbreviations

P.I.N. "Product Identification Number"
SN "Serial Number"
NSS "Not Serviced Separately" in the part number column indicates this part is not available for service.
REF "Reference" in the part number column indicates this part has special service information. The page where this information can be found is given in the part description column.
UAR "Use As Required" in the quantity required column indicates the number of parts used is determined by service needs.

Right-Hand and Left-Hand Identification

The reference to right-hand and left-hand in this catalog is identified by the operator standing at the rear of the basic unit (without rear attachment), looking toward the front of the machine (in normal forward travel). For pages covering any machine attachments, right-hand and left-hand are defined by the operator sitting in the position for proper operation of the attachment.

Catalog Revisions and Supplements

Changes to the product may make it necessary to revise or add pages to this catalog. A cover sheet will list all pages released in a revision or supplement. Each new or revised page will have a new issue date. All revised and new pages must be put into the parts catalog as soon as they are received.

Parts Orders

Orders must specify product model, all necessary serial numbers, correct part number, complete description, quantity required, method of shipment, and shipping address.

Text Format Explanation

An assembly may contain many service items. The component parts of an assembly or subassembly are indented. The quantity required column lists the number of assemblies required for a complete machine, and the number of components required in a complete assembly or subassembly.

The example below illustrates the use of indents and other text page elements explained on this page.

REF.	PART NO.	DESCRIPTION	REQ'D.
1	D43567	FILTER ASSEMBLY - hydraulic oil, PIN 7534840 and after	1
	D61903	HEAD ASSEMBLY - filter	1
2	NSS	HEAD - filter, order D61903 head assembly	1
3	D58199	VALVE - bypass	1
	D43800	KIT - filter element, replaces D35700 kit	1
4	NSS	ELEMENT - filter, order D43800 element kit	1
5	A27994	O-RING - filter	1
6	D61948	HOUSING - filter	1
7	REF	CANOPY - ROPS, machinery item, order from Machinery Price List	1
8	843065C1	HOSE - 132 inch (3353 mm) long, reservoir to pump	1
9	113-323	BOLT - hex head, 7/16 - 14 NC x 1-3/4 inch, plated	2
10	814-8030	BOLT - hex head, 8 mm - 1.25 x 30 mm (8.8), plated	4

MidWestTech | Case 780C Construction King Loader Backhoe Parts Catalog | Publication... Order the manual at mid-west-tech.com >

ALPHABETICAL INDEX

A

Actuator - brake 7-225,7-239,7-241
Air Cleaner 2-17,2-19
Air Conditioner
  Blower 9-483
  Compressor and Clutch 9-493
  Compressor Mounting 9-491
  Condenser 9-489
  Controls 9-467,9-469
  Evaporator 9-487
  Filter 9-481
  Receiver - Drier 9-489
Alarm - backup 4-131
Alarm - warning buzzer 4-103,4-105
Alcohol Evaporator 7-243
Alternator - electrical ..... 4-79 - 4-83
Alternator Mounting 4-89
Antirollback - loader 9-353
Axle
  Front 5-161
  Rear ..... 6-201 - 7-215
  Rear Brakes 7-213,7-215
  Rear Mounting 6-201

B

Backhoe
  Boom 9-383,9-385
  Buckets ..... 9-395 - 9-405
  Controls (See Controls)
  Control Tower 9-367
  Dipper 9-389
  Extendable Dipper 9-391
  Frame and Mounting Parts 9-381
  Hydraulics (See Hydraulic Circuits)
  Stabilizers 9-381
  Swing Tower 9-383
Backup Alarm 4-131
Battery 4-91
Beacon - rotating ..... 4-133 - 4-139
Bearings - engine
  Camshaft 2-45
  Main 2-51
  Rod 2-55
Belts
  Air Conditioner Compressor 9-491
  Brake Air Compressor 7-217
  Fan and Alternator 2-13
  Seat 9-431,9-433
  Water Pump Tensioner 2-27
Boom Latch 9-387

B

Boom Lock 8-279,8-281
Box - operators manual and tool 9-417
Brake System
  Air Pressure Protection Valve 7-221,7-237
  Alcohol Evaporator 7-243
  Brake Actuator 7-225,7-239,7-241
  Clutch Cutout Valve 7-227,7-237
  Compressor-air brake system 7-231
  Compressor Mounting 7-217
  Compressor to Reservoir 7-219
  Parking Brake Valve 7-227,7-229
  Pressure Reducing Valve 7-229
  Reservoir-air 7-219
  Treadle Assembly 7-235
  Treadle to Clutch Cutout Valve 7-227
  Treadle to Parking Brake Valve 7-227
  Treadle to Reservoir 7-221,7-223
  Unloading Valve-air compressor 7-233
Breaker Fork - concrete 9-407
Buckets - backhoe ..... 9-395 - 9-405
Buckets - loader ..... 9-361 - 9-365

C

Cab
  Air Conditioner, Heater, and
    Defroster ..... 9-481 - 9-491
  Air Filter and Roof Insulation 9-481
  Blower 9-483
  Doors and Windows ..... 9-455 - 9-461
  Electrical and Lighting ..... 4-103 - 4-125
  Frame 9-449,9-451
  Glass and Moldings 9-463,9-465
  Headliner 9-479
  Mounting Parts 9-449
  Panel - cab control 9-467
  Panel - closure 9-423,9-449
  Windshield Wipers ..... 9-471 - 9-477
Canopy - ROPS 9-495
Chassis - tractor 9-411
Clutch - air conditioner 9-493
Clutch Cutout- brake system 7-237
Cold Start System 2-21
Column - steering 5-151,5-157
Compressor - air conditioner 9-493
Compressor - brake air 7-231
Concrete Breaker Fork 9-407
Controls
  Backhoe ..... 9-369 - 9-379
  Brake ..... 7-221 - 7-227

Bur 8-2271

Issued September, 1988 Printed in U.S.A.

MidWestTech | Case 780C Construction King Loader Backhoe Parts Catalog | Publication... Order the manual at mid-west-tech.com >