584E, 585E, and 586E Forklifts

Parts Catalog


Bur 8-2873

(This Book Includes Revision 1)

MidWestTech | Case 584E, 585E, 586E Forklift Parts Catalog | Publication 8-2873

Order the manual at mid-west-tech.com >

PICTORIAL SECTION INDEX



GENERAL 1

ENGINE 2

FUEL 3

ELECTRICAL 4

TRACKS/ STEERING 5

POWER TRAIN 6

BRAKES 7

HYDRAULICS 8

CHASSS/MTD. EQUIPMENT 9

NUMERICAL INDEX 10

MidWestTech | Case 584E, 585E, 586E Forklift Parts Catalog | Publication 8-2873 Order the manual at mid-west-tech.com >

GENERAL INFORMATION

Indexes

Section 1 of this catalog contains a SN and P.I.N. location guide, alphabetical index, pictorial index of the sections included, and pictorial index(es) for quick location of hoses and tubes (and other system components in some catalogs). An alphabetical index also appears at the beginning of each section. Section 10 is the Numerical Index which lists all part numbers in alpha/numeric order with their page location and reference number.

Illustrations

The arrangement of this parts catalog is for easy identification of parts. All parts are illustrated in "exploded views" in proper relation to each other. Reference numbers used in the illustrations refer to those on the text pages. The text pages list reference number, part number, part description and the quantity required.

Abbreviations

P.I.N. "Product Identification Number"

SN "Serial Number"

NSS "Not Serviced Separately" in the part number column indicates this part is not available for service.

REF "Reference" in the part number column indicates this part has special service information. The page where this information can be found is given in the part description column.

UAR "Use As Required" in the quantity required column indicates the number of parts used is determined by service needs.

Right-Hand and Left-Hand Identification

The reference to right-hand and left-hand in this catalog is identified by the operator standing at the rear of the basic unit (without rear attachment), looking toward the front of the machine (in normal forward travel). For pages covering any machine attachments, right-hand and left-hand are defined by the operator sitting in the position for proper operation of the attachment.

Catalog Revisions and Supplements

Changes to the product may make it necessary to revise or add pages to this catalog. A cover sheet will list all pages released in a revision or supplement. Each new or revised page will have a new issue date. All revised and new pages must be put into the parts catalog as soon as they are received.

Parts Orders

Orders must specify product model, all necessary serial numbers, correct part number, complete description, quantity required, method of shipment, and shipping address.

Text Format Explanation

An assembly may contain service items. The component parts of an assembly or subassembly are indented. The quantity required column lists the number of assemblies required for a completed machine, and the number of components required in a complete assembly or subassembly.

The example below illustrates the use of indents and other text page elements explained on this page.

HYDRAULIC FILTER

REF.	PART NO.	DESCRIPTION	REQ'D.
1	D4356734	FILTER ASSEMBLY - hydraulic oil, P.I.N. 7534840 and after	1
	D61903	HEAD ASSEMBLY - filter	1
2	NSS	HEAD - filter, order D61903 head assembly	1
3	D58199	VALVE - bypass	1
	D43800	KIT - filter element, replaces D35700 element kit	1
4	NSS	ELEMENT - filter, order D43800 element kit	1
5	A27994	O-RING - filter	1
6	D61948	HOUSING -filter	1
7	REF	CANOPY - ROPS, order from Machinery Price List	1
8	843065C1	HOSE - 3353 mm (132 inch) long, reservoir to pump	1
9	113-323	BOLT - hex, 7/16 NC x 1-3/4 inch	2
10	814-8030	BOLT - hex, 8 - 1.25 x 30 mm	4

MidWestTech | Case 584E, 585E, 586E Forklift Parts Catalog | Publication 8-2873 Order the manual at mid-west-tech.com >

ALPHABETICAL INDEX

A

Actuator - differential brake 7-5
Air Cleaner 2-9,2-9B
Air Cleaner and Intake Parts 2-7,2-7B
Alarm - back-up 4-37
Alternator 4-3, 4-3B
Alternator Mounting 4-9
Axle - rear drive
  Axle Shaft 6-45,6-45B,6-51,6-51B
  Control 6-31
  Differential 6-41,6-43,6-55
  Drive Shaft 6-33,6-35
  Housing 6-37,6-47
  Mounting 6-33
  Planetary 6-45,6-45B,6-53,6-53B
  Ring and Pinion Gear Set 6-43,6-57
  Swivel Housing 6-39,6-49
  Tie Rod 6-37,6-49

B

Backup Alarm 4-37
Battery Box 9-127
Belt
  Fan 2-5,2-5B
  Seat 9-131,9-137
Block - cylinder ..... 2-33 - 2-35B
Box - operators manual 9-127B
Brake - parking 7-19

C

Camshaft 2-31,2-31B
Canopy - ROPS 9-145
Chassis 9-117,9-119
Cleaner - air 2-9,2-9B
Cluster - instrument 4-23,4-25
Cold Start System 2-11
Cold Start System - dual batteries 4-39
Column - steering 5-3
Concrete Block Forks 9-113
Connecting Rods 2-41,2-41B
Control Levers and Linkage 9-3
Control Valve
  Flow 8-27
  Forklift 8-29,8-31
  Steering ..... 5-11 - 5-11D
Converter - torque 6-3
Cooler - oil 2-23,2-23B
Counterweights - rear 9-115
Cover - front gear 2-19,2-19B
Crankshaft ..... 2-37 - 2-37D
Cylinder
  Block ..... 2-33 - 2-35B
  Block Heater 2-35,2-35B

C

Cylinder, continued
  Head and Covers 2-27,2-27B
Cylinders
  Master - brake 7-17
  Mast Lift ..... 8-35 - 8-41B
  Sideshift 8-47
  Steering ..... 5-13 - 5-15
  Tilt 8-43,8-45

D

Decals ..... 9-149 - 9-155
Deluxe Seat 9-143
Differential Lock
  Four Wheel Drive 6-29
  Two Wheel Drive 6-25
Drive Shaft
  Power Shuttle to Transaxle 6-23
  Rear Drive Axle - four wheel drive 6-35

E

Electrical Circuit
  Battery and Cables to Starter 4-11
  Engine Harness and Connections 4-13,4-15
  Flasher Harness and Controls 4-21
  Instrument Panel ..... 4-17 - 4-19B
  Main Harness ..... 4-17 - 4-19B
  Power Shuttle 4-27
Emblem - slow moving vehicle 9-147
Engine Mounting 2-15
Engine Side Panels 9-125
Exhaust Manifold 2-21

F

Fan
  Engine 2-5,2-5B
  Radiator ..... 2-3 - 2-5D
Fan Belt - engine 2-5,2-5B
Fenders 9-127,9-127B
Filter
  Fuel 3-9,3-9B
  Hydraulic Oil 8-33
  Oil - engine 2-23,2-23B
Floor Plates 9-127
Flow Control Valve 8-27
Flywheel and Housing 2-39
Forklift Control Valve 8-29,8-31
Forklift Hydraulic Circuit ..... 8-3 - 8-9
Forks 9-113
Front Gear Cover 2-19,2-19B
Front Wheels and Tires 5-23
Fuel
  Filter 3-9,3-9B

MidWestTech | Case 584E, 585E, 586E Forklift Parts Catalog | Publication 8-2873 Order the manual at mid-west-tech.com >