1620
COMBINE

Parts Catalog

8-3141

CASE IH AGRICULTURE

MidWestTech | Case 1620 Combine Parts Catalog | Publication 8-3141

Order the manual at mid-west-tech.com >

ALPHABETICAL INDEX

A

Accumulator Attachment 8-71
Acoustical Covers, Cab 9-233
Air Cleaner and System 2-51
Air Conditioning Compressor Pulleys 9-249
Air Conditioning System 9-243,247
Alfalfa Shoe Sieve 9-103
Alternator Assembly 4-59
Alternator Bracket 2-15
Alternator Mounting 4-57
Automatic Feeder Cut-off 4-39
Automatic Head Height Control 4-41
Automatic Reel Speed 4-39
Auger Alarm and Supports 9-99
Auger Bed 9-93
Auger Drive 9-95
Auger, Grain Delivery 9-127
Auger, Tailings Delivery 9-147
Augers, Bottom 9-165
Axle, Adjustable Steering 5-19
Axle, Drive 6-47
Axle Extension 6-49
Axle, Nonadjustable Steering 5-15
Axle Shield, Steering 5-27

B

Battery 4-55
Battery Cables 4-55
Battery Tray 4-53
Bearings, Crankshaft 2-35
Beater, Discharge 9-111
Belt Drive, Reel 9-3,5,7
Belts, Engine 2-5
Block Engine Cylinder 2-25
Blower Assembly 9-241
Blower Mounting 9-239
Bottom Augers 9-165
Brake Cylinder 7-11
Brake Cylinder Reservoir 7-9
Brake, Parking 7-7
Brake Pedal 7-3
Brakes, Master 7-5
Breather, Engine 2-25

C

Cab Door 9-239
Cab Filter 9-235
Cab Glass 9-229,231
Cab Headliner 9-235
Cab, Operator 9-229,231
Cab Roof 9-237
Cab Roof Harness 4-13

C

Cab Sound Insulation 9-233
Cab Spotlight 4-70
Cage, Rotor 9-81
Camshaft 2-29
Center Harness 4-15
Chaffer and Shoe Sieve 9-105
Chaffer Drive Hange Lever 9-97
Chaffer Sieve 9-107
Charge Pump, Hydrostatic 6-27
Cleaning Fan and Shields 9-117,125
Cleaning Fan Drive 9-119,121
Cleaning Fan Drive Control 9-123
Cleaning Fan Inlet Shield 9-125
Compressor Assembly 9-253
Compressor Clutch 9-251
Concaves 9-89
Condenser Coil 9-245
Cone, Rotor Transition 9-79
Connecting Rods 2-37
Console 9-207,209,211
Console Back Lighting Harness 4-11
Console Harness 4-7,9
Control Valve and Mounting 8-27,29
Control Valve, Hydrostatic Pump 6-25
Conveyor, Feeder 9-41,43
Coolant Filter and Conditioner 2-13
Couplings, Self Sealing 8-77
Crankshaft 2-35
Cylinder Block 2-25,27
Cylinder, Brake 7-11
Cylinder, Feed Clutch 8-67
Cylinder Head and Cover 2-23
Cylinder, Header Lift 8-25
Cylinder, Separator Clutch 8-69
Cylinder Sleeves 2-37
Cylinder, Steering 5-11
Cylinder, Unloader Swing 8-75

D

Decals ..... 9-285 through 297
Differential, Transmission 6-43,45
Dipstick, Oil 2-39
Discharge Beater 9-111
Discharge Beater Bottom 9-113
Dome Light 4-65
Double Piloted Valve 8-37
Drive Axle 6-47
Drive, Cleaning Fan 9-119,121
Drive, Feeder ..... 9-23 through 29
Drive, Feeder Jackshaft 9-31
Drive, Grain Elevator 9-143,145

Rac 8-3141 Issued March, 1988 Printed in U.S.A.

MidWestTech | Case 1620 Combine Parts Catalog | Publication 8-3141 Order the manual at mid-west-tech.com >

ALPHABETICAL INDEX

D

Drive, Rotor 9-59,61
Drive, Separator Jackshaft 9-9,11
Drive, Shaker Shaft 9-95
Drive, Straw Chopper 9-187
Drive, Tank Unloader Belt 9-169,171
Drive, Tank Unloader Chain 9-173,175
Drive, Tailings Elevator 9-155,157
Drive Wheels 6-55

E

Electrical Harness, Back Lighting 4-11
Electrical Harness, Cab Roof 4-13
Electrical Harness, Center 4-15
Electrical Harness, Console 4-7,9
Electrical Harness, Engine 4-3
Electrical Harness, Feeder Reservoir 4-45
Electrical Harness, Fuel Sender 4-31
Electrical Harness, Grain Tank 4-25
Electrical Harness, Header Lift 4-23
Electrical Harness, Monitor 4-17
Electrical Harness, Steering Column 4-5
Elevator Drive Jackshaft 9-159,161
Elevator, Grain 9-135,137
Elevator, Tailings 9-151,153
Engine Assembly, Complete 2-45
Engine Breather 2-25
Engine Front Cover 2-47
Engine Harness 4-3
Engine Rails and Supports 2-41
Engine Shield 9-261
Ether Starting 2-17
Evaporator 9-239
Exhaust Manifold 2-21
Exhaust System 2-19
Expansion Valve 9-247
Extensions, Steering Axle 5-19
Extinguisher, Fire 9-257

F

Fan and Rotor Speed Harness 4-37
Fan, Cleaning 9-117
Fan, Engine 2-5
Fan Shields 9-115
Feeder Adapter and Deflector 9-39
Feeder Clutch Circuit 8-63,65
Feeder Clutch Cylinder 8-67
Feeder Control Concepts 8-53
Feeder Conveyor 9-41,43
Feeder Drive 9-27,29
Feeder Gear Case 9-21
Feeder Housing and Top Cover 9-35

F

Feeder Jackshaft Drive 9-31
Feeder Lift and Lower Doors 9-37
Feeder Modual Control 8-55
Feeder Pivot Stripper 9-45
Feeder Reverser 9-51,53
Feeder Reverser Harness 4-45
Feeder Reverser Motor 4-47
Feeder Valve 8-63,65
Filler Tube, Engine Oil 2-39
Filter, Coolant 2-13
Filter, Engine Oil 2-31
Filter, Fuel 3-9
Final Drive 6-51,53
Fire Extinguisher 9-257
Fixed Ladder and Extension 9-275
Floor Mat 9-233
Flywheel, Engine 2-35
Flywheel Housing 2-39
Foot-N-Inch Pedal 6-13
Foot-N-Inch Valve 6-15
Foot-N-Inch Valve Circuit 6-11
Front Cover, Engine 2-47
Fuel Filter 3-9
Fuel Injection Pump 3-5
Fuel Injection System 3-3,9
Fuel Lines 3-9
Fuel Sender Harness 4-31
Fuel Tank 3-13
Fuse Block 4-51
Fuses 4-51

G

Gasket Kits, Engine 2-43,45
Gear Case, Feeder and Cleaner 9-21
Grain Auger Shield 9-133
Grain Auger Trough 9-129,131
Grain Delivery Auger 9-127
Grain Elevator Conveyor 9-139
Grain Elevator Drive 9-143,145
Grain Elevator Head Shield 9-141
Grain Pan Dividers 9-109
Grain Scan Monitor 4-43
Grain Tank 9-163
Grain Tank Harness 4-25
Grain Tank Light 4-25
Grain Tank Unloader 9-177,179
Grain Tank Unloader Drive 9-169,171,173,175

H

Hand Held Spotlight 4-70
Hand Rails 9-271

Rac 8-3141 Issued March, 1988 Printed in U.S.A.

MidWestTech | Case 1620 Combine Parts Catalog | Publication 8-3141 Order the manual at mid-west-tech.com >

ALPHABETICAL INDEX

H

Harness, Cab Roof 4-13
Harness, Center 4-15
Harness, Console 4-7,9
Harness, Console Back Lighting 4-11
Harness, Engine 4-3
Hanress, Feeder Reverser 4-45
Harness, Fuel Sender 4-31
Harness, Grain Tank 4-25
Harness, Header Lift 4-23
Harness, Monitor 4-17
Harness, Steering Column 4-5
Head, Cylinder 2-23
Header Lift Cylinder 8-25
Header Lift Cylinder Circuit 8-23
Header Lift Handle Harness 4-23
Header Lift Pump 8-21
Header Lift Pump Mounting 8-19
Header Lift Return Circuit 8-15
Header Lift Supply Circuit 8-13
Header, Valve 8-31,33
Headliner Cab 9-235
Heater, Cab 9-239
Heater Control Valve 9-247
Heater System 9-243,247
Hydraulic Reservoir 8-3
Hydraulic Reservoir Drain Circuit 8-5
Hydraulic Pump 6-19,21,23
Hydrostatic Motor 6-29,31
Hydrostatic Pump Circuit 8-7

I

Injection Nozzle 3-7
Inlet Shields, Fan 9-125
Instrument Cluster 4-49
Intake Manifold 2-21

J

Jackshaft Bearing Block 9-19
Jackshaft, Elevator Drive 9-159,161

K

Knuckle, Steering 5-23,25

L

Ladder Extension 9-275
Ladder, Fixed 9-275
Ladder, Pivoting 9-273
Ladder, Service 9-269
Light, Dome 4-65
Light, Grain Tank 4-29
Light, Tail 4-33
Light, Unloader 4-29

L

Light, Warning 4-33
Lights, Rear 4-31

M

Main Rear Harness 4-31
Manifold, Exhaust 2-21
Manifold, Intake 2-21
Master Brake Cylinder 7-11
Master Brake Pedal 7-3
Master Brakes 7-5
Mirror, Rear View 9-255,257
Monitor Harness 4-17
Motor, Hydrostatic 6-29,31
Muffler, Exhaust 2-19

N

Nozzle, Fuel Injection 3-7

O

Oil Breather, Engine 2-25
Oil Cooler, Circuit 8-9
Oil Cooler, Engine 2-31
Oil Cooler, Hydraulic 8-11
Oil Filler Tube 2-39
Oil Filter 2-31
Oil Level Gauge 2-39
Oil Pan, Engine 2-39
Oil Pump, Engine 2-33
Operator Seat ..... 9-271 through 227
Operator Seat and Mounting 9-215
Operators Cab 9-229,231
Operators Platform and Supports 9-281,283
Operators Platform Extension 9-279

P

Pan, Oil 2-39
Parking Brake 7-7
Piston Rings 2-37
Pistons, Engine 2-37
Pivot Pedal, Steering Wheel 5-3
Pivoting Ladder 9-273
Platform, Operators 9-281,283
Power Steering Circuit 5-5,7
Power Takeoff Drive 6-3,5,7
Precleaner 2-19
Propulsion Control 6-17
Pump, Fuel Injection 3-5
Pump, Header Lift 8-21
Pump, Hydrostatic 6-19,21,23
Pump, Oil 2-33
Pump, Steering Hand 5-9P
Pump, Water 5-9

Rac 8-3141 Issued March, 1988 Printed in U.S.A.

MidWestTech | Case 1620 Combine Parts Catalog | Publication 8-3141 Order the manual at mid-west-tech.com >