1816 Uni-Loader

Service Manual

9-72555

MidWestTech | Case 1816 Uni Loader Service Manual | Publication 8-41040

Order the manual at mid-west-tech.com >

1816, 1816B, AND 1816C UNI-LOADERS

TABLE OF CONTENTS

DIVISION/SECTION	SECTION NO.	FORM NO.
1 GENERAL		
Safety Rules, Service Manual Introduction, and Torque Specifications	1001	8-41040
Maintenance and Lubrication	1002	8-41040
Engine Specifications - 1816C	1003	8-41040
2 ENGINES		
Troubleshooting a Hard Starting Engine and D61880 Starter (Square Housing) - 1816 and 1816B	2001	8-41040
Engine Troubleshooting	2002	8-41040
Engine Removal and Installation - 1816 and 1816B and Drive Belts - 1816	2003	8-41040
Engine Removal Installation, 1816C	2004	8-41040
Tecumseh Engines Mechanic's Handbook - 1816 and 1816B		691462A
Onan Engine - 1816C	2006	8-41040
Engine Accessories	2007	8-41040
3 FUEL SYSTEM		
Engine Controls, Fuel Lines, Fuel Filter, Electric Fuel Pump	3001	8-41040
Carburetor - 1816C	3002	8-41040
4 ELECTRICAL		
Electrical System Troubleshooting	4002	8-41040
Wiring Diagrams	4003	8-41040
Gauges	4004	8-41040
Battery	4005	8-41040
Starter	4006	8-41040
NOTE: *Also see the following sections:*		
Starter - 1816 and 1816B	Sections 2001 and 2005	
Alternator - 1816, 1816B	Sections 2001 and 2005	
Alternator - 1816C	Sections 2006 and 4002	
Spark Ignition System - 1816, 1816B	Sections 2001 and 2005	
Spark Ignition System - 1816C	Sections 2006 and 4002	
6 POWER TRAIN		
Hydrostatic Troubleshooting, Testing, and Adjustment for Machines with Vickers Piston Pumps	6001	8-41040
Hydrostatic Troubleshooting, Testing, and Adjustment for Machines with Sundstrand Piston Pumps	6002	8-41040
Hydrostatic System Diagrams and Operation for Machines with Vickers Piston Pumps	6003	8-41040
Hydrostatic System Diagrams and Operation for Machines with Sundstrand Piston Pumps	6004	8-41040
Vickers Piston Pump	6005	8-41040
Sundstrand Piston Pump	6006	8-41040
Hydrostatic Motor	6007	8-41040

Reprinted

CASE CORPORATION

8-41040
March 1982

PRINTED IN U.S.A.

MidWestTech | Case 1816 Uni Loader Service Manual | Publication 8-41040 Order the manual at mid-west-tech.com >

OTHER FULLY ILLUSTRATED DO-IT-YOURSELF TECUMSEH BOOKS THAT ARE AVAILABLE

TECUMSEH MECHANICS MANUAL (Complete) ..... No. 691630
covers all engine models & Peerless drives

MOTION DRIVE SYSTEMS REPAIR MANUAL ..... No. 691218
covers all Peerless-Tecumseh transmissions, transaxles, differentials and right angle gear drives.

2 CYCLE ENGINE MANUAL ..... No. 692508

4 CYCLE ENGINE MANUAL, 3 to 10 h.p. ..... No. 692509


4 CYCLE ENGINE MANUAL, 8 to 18 h.p.
(CAST IRON ENGINES) ..... No. 691462A

ELECTRICAL TROUBLE SHOOTING BOOKLET ..... No. 693505

Litho in U.S.A.

Form No. 691462A

MidWestTech | Case 1816 Uni Loader Service Manual | Publication 8-41040 Order the manual at mid-west-tech.com >



1. Suction Oil
2. Return Oil
3. Pump Flow
4. Oil To and From A Ports and Cylinders
5. Oil To and From B Ports and Cylinders
6. Bucket Cylinder
7. Lift Cylinder
8. Loader Control Valve
9. A Port
10. B Port
11. Equipment Pump
12. To Piston Pumps
13. Filter Condition Gauge
14. Hydraulic Filter
15. Hydraulic Reservoir
16. Oil Cooler

Figure 4 - Loader Hydraulic Diagram (Late Models)

Order the manual at mid-west-tech.com >