170C Crawler Excavator

Parts Catalog

8-4114

CASE CONSTRUCTION

MidWestTech | Case 170C Crawler Excavator Parts Catalog | Publication 8-4114

Order the manual at mid-west-tech.com >

PICTORIAL SECTION INDEX



GENERAL 1

ENGINE 2



FUEL SYSTEM 3



ELECTRICAL 4



STEERING 5



POWER TRAIN 6



BRAKES 7



HYDRAULIC 8



CHASSIS 9

NUMERICAL INDEX 10

MidWestTech | Case 170C Crawler Excavator Parts Catalog | Publication 8-4114 Order the manual at mid-west-tech.com >

GENERAL INFORMATION

Indexes

Section 1 of this catalog contains a SN and P.I.N. location guide, alphabetical index, pictorial index of the sections included, and pictorial index(es) for quick location of hoses and tubes (and other system components in some catalogs). An alphabetical index also appears at the beginning of each section. Section 10 is the Numerical Index which lists all part numbers in alpha/numeric order with their page location and reference number.

Illustrations

The arrangement of this parts catalog is for easy identification of parts. All parts are illustrated in "exploded views" in proper relation to each other. Reference numbers used in the illustrations refer to those on the text pages. The text pages list reference number, part number, part description and the quantity required.

Abbreviations

P.I.N. "Product Identification Number"

SN "Serial Number"

NSS "Not Serviced Separately" in the part number column indicates this part is not available for service.

REF "Reference" in the part number column indicates this part has special service information. The page where this information can be found is given in the part description column.

UAR "Use As Required" in the quantity required column indicates the number of parts used is determined by service needs.

Right-Hand and Left-Hand Identification

The reference to right-hand and left-hand in this catalog is identified by the operator standing at the rear of the basic unit (without rear attachment), looking toward the front of the machine (in normal forward travel). For pages covering any machine attachments, right-hand and left-hand are defined by the operator sitting in the position for proper operation of the attachment.

Catalog Revisions and Supplements

Changes to the product may make it necessary to revise or add pages to this catalog. A cover sheet will list all pages released in a revision or supplement. Each new or revised page will have a new issue date. All revised and new pages must be put into the parts catalog as soon as they are received.

Parts Orders

Orders must specify product model, all necessary serial numbers, correct part number, complete description, quantity required, method of shipment, and shipping address.

Text Format Explanation

An assembly may contain service items. The component parts of an assembly or subassembly are indented. The quantity required column lists the number of assemblies required for a completed machine, and the number of components required in a complete assembly or subassembly.

The example below illustrates the use of indents and other text page elements explained on this page.

HYDRAULIC FILTER

REF.	PART NO.	DESCRIPTION	REQ'D.
1	D43567S4	FILTER ASSEMBLY - hydraulic oil, P.I.N. 7534840 and after	1
	D61903	HEAD ASSEMBLY - filter	1
2	NSS	HEAD - filter, order D61903 head assembly	1
3	D58199	VALVE - bypass	1
	D43800	KIT - filter element, replaces D35700 element kit	1
4	NSS	ELEMENT - filter, order D43800 element kit	1
5	A27994	O-RING - filter	1
6	D61948	HOUSING -filter	1
7	REF	CANOPY - ROPS, order from Machinery Price List	1
8	843065C1	HOSE - 3353 mm (132 inch) long, reservoir to pump	1
9	113-323	BOLT - hex, 7/16 NC x 1-3/4 inch	2
10	814-8030	BOLT - hex, 8 - 1.25 x 30 mm	4

MidWestTech | Case 170C Crawler Excavator Parts Catalog | Publication 8-4114 Order the manual at mid-west-tech.com >

ALPHABETICAL INDEX

A

Adjustable Relief Valve....8-141,8-145
Adjustment Cylinder - track .... 5-11 - 5-15
Adjustment Cylinder Mounting - track....5-7,5-9
Air
  Cleaner 2-3
  Cooling Adapting Parts - engine 2-5
  Intake Parts....2-3
Alarm - low engine oil pressure 4-11
Alternator
  Assembly 4-9
  Fan....2-9
  Pulley 2-9
Anti-Vandalism Guards - cab....9-107,9-109
Arm Cylinder....8-173,8-175
Arm Cylinder Circuit....8-83,8-85
Arm, Links and Mounting Pins.... 9-53 - 9-59
Arm Lubrication Lines.... 9-61
Attachment Control Valve.... 8-101 - 8-111

B

Backhoe Bucket....9-63,9-65
Backhoe Bucket Cutter Options .... 9-69 - 9-73
Battery 4-41
Block
  Junction....8-17
  Manifold 8-149,8-151
Boom and Related Parts .... 9-43 - 9-49
Boom and Tool Cylinder....8-169,8-171
Boom, Arm and Tool Cylinder Circuits 8-77
Boom Cylinder Circuit....8-79,8-81
Boom Lubrication Lines....9-51
Box
  Electrical .... 4-45 - 4-53
  Manual 9-115,9-119
Brake - transmission....6-5,6-9
Brake Hydraulic Lines....7-3,7-5
Bucket Teeth 9-67

C

Cab
  Anti-Vandalism Guards 9-107,9-109
  Door .... 9-95 - 9-99
  Electrical Components 4-25,4-27
  Electrical Harness 4-19,4-21
  Fan.... 4-29
  Frame 9-75,9-77,9-83,9-85,9-89
  Glass and Insulation 9-79,9-81
  Glass, Insulation and Seals 9-93
  Insulation.... 9-87
  Lamp.... 4-27
  Rear Lamp 4-31
  Sliding Window 9-91

C

Cab, continued
  Windshield.... 9-101,9-103
  Windshield Opening Parts.... 9-105
  Wiring Harness.... 4-25
Carrier.... 6-3,6-7
Chain, Links and Pins - track 5-19
Check Valve.... 8-155
Cigarette Lighter 4-19,4-21
Circuit
  Arm Cylinder.... 8-83,8-85
  Boom and Tool Cylinder.... 8-169,8-171
  Boom, Arm and Tool Cylinder 8-77
  Hydraulic
    Control .... 8-39 - 8-55
    Control - for swing brake.... 8-71
    Craning Valve 8-67,8-69
    Craning Valve Control.... 8-57
    For Options 8-73,8-75,8-89,8-91
    From Main Control Valves .... 8-59 - 8-65
    Return Lines .... 8-21 - 8-37
  Relief Valve 8-107,8-109
  Tool Cylinder 8-87
Cleaner - air 2-3
Consoles - hand control valve.... 9-31 - 9-37
Control - throttle and fuel shutoff.... 3-9
Control Circuits Manifold.... 8-47
Control Panel - electrical.... 4-13
Control Valve
  Attachment .... 8-101 - 8-111
  Foot 8-129,8-131
  For Options.... 8-121
  Hand.... 8-125,8-127
  Parallel Supply 8-137
  Swing and Drive ....8-113 - 8-119D
Cooler - hydraulic oil 8-5,8-7
Cooler Hydraulic Pump 8-97
Counterweight.... 9-5 - 9-11
Cover
  Rear Engine 9-17,9-19
  Side Access.... 9-21,9-23
  Turntable Lower Access.... 9-13,9-15
Craning
  Valve .... 8-141 - 8-147
  Valve Hydraulic Circuit 8-67,8-69
  Valve Hydraulic Control Circuit.... 8-57
Cylinder
  Arm.... 8-173,8-175
  Boom and Tool.... 8-169,8-171
  Circuit
    Arm 8-83,8-85
    Boom 8-79,8-81
    Boom, Arm and Tool.... 8-77

MidWestTech | Case 170C Crawler Excavator Parts Catalog | Publication 8-4114 Order the manual at mid-west-tech.com >