
NEW HOLLAND
TT60A
TT75A
Tractors



REPAIR MANUAL

SERVICE

84154801

MidWestTech | New Holland TT60A, TT75A Tractor Service Manual | Publication 84154801

Order the manual at mid-west-tech.com >

TT60A, TT75A
REPAIR MANUAL
COMPLETE CONTENTS

SECTION 00 - GENERAL 2

SECTION 10 - ENGINE 3

SECTION 18 - CLUTCHES 8

SECTION 21 - TRANSMISSION SYSTEM 10

SECTION 25 - FRONT DRIVE AXLE 12

SECTION 27 - MECHANICAL REAR WHEEL DRIVE 14

SECTION 31 - POWER TAKE-OFF 16

SECTION 33 - BRAKING SYSTEM 17

SECTION 35 - HYDRAULIC SYSTEMS 18

SECTION 41 - STEERING SYSTEMS 22

SECTION 44 - FRONT AXLE 24

SECTION 55 - ELECTRICAL SYSTEM 25

SECTION 90 - BODYWORK 31

The following pages are the collation of the contents pages from each section and chapter of the TT60A, TT75A Repair manual. Complete Repair part # 84154801.

The sections used through out all New Holland product Repair manuals may not be used for each product. Each Repair manual will be made up of one or several books. Each book will be labeled as to which sections are in the overall Repair manual and which sections are in each book.

The sections listed above are the sections utilized for the TT60A, TT75A Tractors.

© 2008 CNH America LLC

Printed in U.S.A.

84154805 7/08
Replaces 87583295

MidWestTech | New Holland TT60A, TT75A Tractor Service Manual | Publication 84154801 Order the manual at mid-west-tech.com >

SECTION 00 - GENERAL

BOOK 1 - 84154802

Chapter 1 - General

CONTENTS

Section	Description	Page
	General Instructions	2
	Important Notice	2
	Shimming	2
	Rotating Shaft Seals	2
	O-Rings	3
	Sealers	3
	Bearings	3
	Spring Pins	3
	Precautionary Notice	4
	Equipment Notice	4
	Spare Parts Notice	4
	General Notices	4
	Health and Safety	5
	Health and Safety Precautions	6
	General Workshop Tools and Equipment	11
	Legal Aspects	11
	Lubricants and Greases	11
	Precautionary Statements	15
	Safety	16
	The Tractor	16
	Driving the Tractor	17
	Operating the Tractor	18
	Operating the PTO	19
	Servicing the Tractor	19
	Diesel Fuel	20
	Ecology and the Environment	21
	Minimum Hardware Tightening Torques	22
	General Dimensions	24
	Federal Emissions Warranty	30
	California Emission Control Warranty Statement	31
	Universal Symbols	33
	Safety Decals	34
	Safety Decals	35
	Instructional Decals	38

MidWestTech | New Holland TT60A, TT75A Tractor Service Manual | Publication 84154801 Order the manual at mid-west-tech.com >

SECTION 10 - ENGINE

BOOK 1 - 84154802


Chapter 1 - Engine System

CONTENTS

Section	Description	Page
	Specifications	5
	Engine Bolt Torque Specifications	13
	Metric Bolt Torque Specifications	14
	Special Tools	15
	Troubleshooting	16
	Description and Operation - Engine Components	20
	Cylinder Head Assembly	20
	Camshaft Assembly	20
	Cylinder Block Assembly	20
	Crankshaft Assembly	20
	Connecting Rods	20
	Pistons	20
	Manifolds	20
	Timing Gears	21
	Lubrication System	22
	Cooling System	23
	Fuel System	24
	Fuel Shut Off (Injection Pump)	24
	Lift Pump	24
	Fuel Filters	24
	Engine Preparation	25
	Engine Removal - Installation	26
	Separating Engine from Transmission Housing	26
	Separating Front Axle from Engine	36
	Engine Installation	38
	Engine Compression Test	39
	Test Procedure	39
	Test Readings	39
	Test Conclusion	39
	Rebuild Instructions	39
	Overhaul	40

MidWestTech | New Holland TT60A, TT75A Tractor Service Manual | Publication 84154801 Order the manual at mid-west-tech.com >

CLUTCH PLATE




5

1. Clutch facing
2. Facing rivet
3. Segment rivet
4. Hub
5. Segment
6. Idle damper spring
7. Main damper spring

MidWestTech | New Holland TT60A, TT75A Tractor Service Manual | Publication 84154801 Order the manual at mid-west-tech.com >

Rear Remote Valve Neutral Operation With Detent (Non-adjustable), Float, and Flow Control



10

Detent Kick Out

1. Spool centering and non-adjustable, pressure detent mechanism (Kick Out @ 191 Bar [2770 psi])
2. Radial drillings
3. Main control spool
4. Ball
5. Detent piston
6. Spring loaded plunger
7. Detent balls

MidWestTech | New Holland TT60A, TT75A Tractor Service Manual | Publication 84154801 Order the manual at mid-west-tech.com >