NEW HOLLAND

SKID STEER

L180

PIN N8M464425 & Prior

PARTS CATALOG

84278457
Replaces 87659706

Issued 10-2009

NEW HOLLAND CONSTRUCTION

www.newhollandconstruction.com

MidWestTech | New Holland L180 Skid Steer Parts Catalog | Publication 84278457

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

02-01	RADIATOR - COOLANT RECOVERY SYSTEM
09-63	DECALS - DB
02-02	FAN, FAN BELT - STANDARD OIL COOLER
02-03	EXHAUST SYSTEM
02-03A	MUFFLER - ASPIRATED
02-04	AIR CLEANER - ENGINE
02-05	ENGINE - MOUNTING
02-06	OIL FILL, ENGINE
02-07	ENGINE - BLOCK HEATER
02-07B	GRID HEATER; L180
02-08	ENGINE
02-08A	ENGINE - TIMER
02-09	CYLINDER BLOCK
02-10	CYLINDER BLOCK
02-11	OIL PUMP, PAN
02-12	CYLINDER BLOCK - COVERS
02-13	BREATHER - ENGINE
02-14	CYLINDER HEAD
02-15	CYLINDER HEAD - COVERS
02-16	CYLINDER HEAD - VALVE MECHANISM
02-17	INTAKE MANIFOLD
02-18	EXHAUST MANIFOLD
02-19	CRANKSHAFT
02-20	CONNECTING ROD
02-21	PISTON - ENGINE
02-22	FLYWHEEL - ENGINE
02-23	PULLEY - CRANKSHAFT
02-24	CAMSHAFT - TIMING CONTROL
02-26	ENGINE, OIL
02-27	OIL PUMP - ENGINE
02-28	OIL FILTERS - ENGINE
02-30	OIL FILTER AND COOLER
02-31	WATER PUMP
02-32	COOLING SYSTEM - ENGINE
02-33	THERMOSTAT - ENGINE COOLING SYSTEM
02-34	WATER PUMP - CONTROL
02-35	FAN DRIVE
02-36	POWER TAKE OFF
02-37	ENGINE - LIFT HOOK
03-01	FUEL TANK
03-01A	FUEL TANK - FUEL SHUT-OFF VALVE, IF USED
03-02	CONTROLS - THROTTLE, LEFT SIDE
03-02A	CONTROLS - THROTTLE, RIGHT SIDE
03-02B	CONTROLS - THROTTLE, DELUXE CAB; IF USED, SEE REF 18
03-02C	CONTROLS - THROTTLE, DELUXE CAB; IF USED, SEE REF 18
03-03	FUEL INJECTION PUMP
03-04	FUEL INJECTION SYSTEM - INJECTOR
03-05	INJECTION PUMP - CONTROL
03-06	KIT, FUEL SYSTEM - INLINE FUEL FILTER
03-07	FUEL INJECTION SYSTEM
03-08	FUEL FILTER

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

03-09	FUEL PUMP
03-10	FUEL INJECTION SYSTEM
03-11	FUEL INJECTION SYSTEM
04-01	STARTER MOUNTING - ALTERNATOR MOUNTING; L180
04-01A	ALTERNATOR; L180
04-02	BATTERY - CABLES
04-02A	BATTERY - CABLES, DELUXE CAB
04-03	ELECTRIC, CAB
04-03A	OPTIONAL ADVANCED INSTRUMENT CLUSTER
04-03B	DIAGNOSTIC PLUG
04-03C	ELECTRIC CAB - RIGHT HAND CONSOLE, DELUXE CAB
04-03D	ELECTRIC CAB - LEFT HAND CONSOLE, DELUXE CAB
04-03F	ELECTRIC CAB - MAIN HARNESS AND FUSE BLOCK, DELUXE CAB
04-03G	ELECTRIC CAB, HARNESS AND FUSE BLOCK (EUROPE) - DELUXE CAB
04-03H	ELECTRIC CAB, DELUXE CAB
04-03I	ELECTRIC CAB - LIGHTS, DELUXE CAB
04-03J	ELECTRIC CAB, TURN SIGNALS - DELUXE CAB
04-04	ELECTRIC, CAB - 4-WAY FLASHERS
04-04A	CAB ELECTRICAL, EUROPE - DELUXE CAB
04-04B	HARNESS ASSY - EU ADAPTER
04-05	ELECTRIC, ENGINE
04-05B	SWITCH ASSY - OIL PRESSURE
04-06	ELECTRIC, MAIN
04-07	ELECTRIC, MAIN
04-08	ELECTRIC, CHASSIS
04-08A	ELECTRIC, CHASSIS - DELUXE CAB
04-08B	ELECTRIC, CHASSIS
04-08B1	MAIN HARNESS ASSY - CHASSIS
04-09	ELECTRIC, MOUNTING PLATE
04-09A	ELECTRIC, MOUNTING PLATE - DELUXE CAB
04-09B	ELECTRIC, MOUNTING PLATE - DELUXE CAB - IF USED
04-10	BACKUP ALARM
04-10A	BACK-UP ALARM - MODELS WITH PILOT CONTROL; IF USED
04-10B	BACK UP ALARM - MODELS WITH PILOT CONTROL; IF USED
04-10C	BACK UP ALARM - DELUXE CAB
04-11	HORN AND TURN SIGNAL
04-11A	HORN - DELUXE CAB
04-11B	ELECTRIC CAB, TURN SIGNALS - DELUXE CAB
04-12	REMOTE JUMP START (IF USED)
04-12A	REMOTE JUMP START (IF USED)
04-12B	REMOTE JUMP START
04-13	ELECTRIC POWER KIT
04-14	WARNING BEACON LIGHT
04-14A	BEACON KIT, DELUXE CAB
04-15	REAR LIGHT BAR, ON-ROAD
04-15A	REAR LIGHT BAR, ON ROAD; IF USED - WITHOUT COVER
04-15B	REAR LIGHT BAR, ON ROAD; IF USED - WITH COVER
04-15C	REAR LIGHT ASSEMBLY - DELUXE CAB
04-16	BOOM, ON ROAD
04-16A	BOOM, ON ROAD - DELUXE CAB
04-17	FRONT HEADLAMP, ON-ROAD

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

04-17A	FRONT HEADLAMP WITH TURN SIGNALS, ON ROAD
04-17B	FRONT AND REAR WORK LIGHTS - DELUXE CAB
04-17C	FRONT HEADLAMP - DELUXE CAB
04-18	HARNESS, TWO SPEED
04-19	PILOT CONTROL HARNESS
04-20	LOADER LOCKOUT, PILOT CONTROLS (EUROPE)
04-25	KIT, VOLTAGE SUPPRESSION
04-26	HARNESS, VOLTAGE SUPPRESSION
04-27	HARNESS ASSY - DOOR AND FRAME
04-27A	HARNESS ASSY - DOOR AND FRAME
06-01	PUMP, TANDEM - MOUNTING
06-01A	HYDROSTATICS - TANDEM PUMP
06-01B	HYDROSTATICS - PUMP TO MANIFOLD
06-01C	HYDROSTATICS AND RESONATOR - TANDEM PUMP
06-02	PUMP, TANDEM - MOUNTING, MODELS WITH PILOT CONTROL
06-02A	HYDROSTATICS - PUMP TO MANIFOLD, MODELS WITH PILOT CONTROLS
06-02B	HYDROSTATICS - PUMP TO MANIFOLD, MODELS WITH PILOT CONTROLS
06-02C	HYDROSTATICS - DRIVE MOTORS TO MANIFOLD, MODELS WITH PILOT CONTROL
06-03D	HYDROSTATICS - PILOT CONTROL TO PUMP
06-03E	HYDROSTATICS - JOYSTICK VALVE KITS, ISO PATTERN, LEFT HAND
06-03F	HYDROSTATICS - JOYSTICK VALVE KITS, ISO PATTERN, LEFT HAND
06-04	HYDROSTATICS - TWO SPEED
06-05	HYDROSTATICS - TWO SPEED, VALVE ASSY
06-06	PUMP, GEAR
06-07	PUMP, GEAR (HIGH FLOW)
06-08	MOTOR ASSY - SINGLE SPEED
06-09	MOTOR ASSY - SINGLE SPEED
06-10	MOTOR ASSY - SINGLE SPEED
06-11	MOTOR ASSY - TWO SPEED
06-12	MOTOR ASSY - TWO SPEED
06-13	MOTOR ASSY - TWO SPEED
06-14	PUMP, TANDEM
06-15	PUMP, TANDEM
06-16	PUMP, TANDEM
06-17	PUMP, TANDEM
06-18	PUMP, TANDEM
06-19	PUMP, TANDEM
06-20	FINAL DRIVE
06-21	TRANSMISSION CENTERING
06-22	WHEELS
06-22A	WHEELS - SOLID FLEX
06-23	REXROTH PUMP AA22
06-24	PRESSURE RELIEF VALVE
06-25	PRESSURE RELIEF VALVE
06-26	INTERNAL GEAR PUMP
06-27	ROTARY GROUP, RIGHT HAND ROTATION
06-28	ROTARY GROUP, LEFT HAND ROTATION
06-29	CONTROL, HYDRAULIC
06-30	CONTROL CARTRIDGE WITH ORIFICE
06-31	VALVE SECTION - LOCKING ELEMENTS
07-01	BRAKE SYSTEM - HYDRAULIC

Order the manual at mid-west-tech.com >