CASE

PROFESSIONAL PARTNER

PARTS CATALOG
ARTICLUATED DUMP TRUCK

330B
TIER 3

84282128
Replaces 87659351

Issued November 2009

MidWestTech | Case 330B Tier 3 Articulated Dump Truck Parts Catalog | Publication 84282128

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

00A00000000	001	DEALER INSTALLED ACCESSORIES
00A00000001	001	PICTORIAL INDEX
01A00000093	001	ENGINE ASSY (UNTIL P.I.N. HHD0330BN7PG56999) (504221449)
01A00000094	001	ENGINE ASSY (P.I.N. HHD0330BN7PG57000 AND AFTER) (504350997)
01A00000247	001	FILTER INSTAL, OIL (87319242)
01A00000259	001	GUARD, DRIVE BELT (87578906)
01A00000260	001	OIL PAN INSTAL (87520765)
01A00000261	001	WIRE HARNESS - ENGINE CLAMPING (87520786)
01A00000262	001	MANIFOLD INSTAL, EXHAUST (87520829)
01A00000263	001	COVER INSTAL, CRANKCASE (87593671)
01A00000265	001	COVER INSTAL, HEAD (87520847)
01A00000270	001	TUBING INSTAL (87521003)
01A00000273	001	ENGINE INTAKE PARTS (87521024)
01A00000274	001	DIPSTICK SUPPORT PARTS (87521044)
01A00000277	001	STARTER MOTOR INSTAL (87521060)
01A00000278	001	AIR COMPRESSOR (87511798)
01A00000282	001	ENGINE BLOCK PARTS (87599682)
01A00000283	001	HOUSING, REAR (87522001)
01A00000284	001	CRANKCASE PARTS - NOZZLE (87522002)
01A00000286	001	ROCKER ARM INSTAL (87522006)
01A00000288	001	FLYWHEEL AND DAMPER INSTAL (87600023)
01A00000289	001	PISTONS INSTAL (87522844)
01A00000290	001	INJECTOR, FUEL SYSTEM (87522845)
01A00000291	001	ELECTRONIC CONTROL (87522846)
01A00000292	001	ENGINE SENSOR / SENDER UNITS (87522847)
01A00000294	001	TURBOCHARGER INSTAL (87522849)
01A00000295	001	COOLING SYSTEM, TURBOCHARGER (87522851)
01A00000298	001	CYLINDER HEAD PARTS (87593676)
01A00000299	001	BREATHER ASSY (87599677)
01A00000300	001	CRANKSHAFT INSTAL (87593675)
01A00000301	001	WIRE HARNESS INSTAL, ENGINE (87600033)
01A00000302	001	HEAT EXCHANGER INSTAL (87600069)
01A00000303	001	BELT TENSIONER INSTAL (87593674)
01A00000336	001	LINES, COMPRESSOR COOLING (P.I.N. HHD0330BN7PG57000 AND AFTER) (84163256)
01A00000337	001	INJECTOR, FUEL SYSTEM (P.I.N. HHD0330BN7PG57000 AND AFTER) (84163277)
01A00000338	001	SENSORS, ENGINE (P.I.N. HHD0330BN7PG57000 AND AFTER) (84163537)
01A00000339	001	LINES, FUEL (P.I.N. HHD0330BN7PG57000 AND AFTER) (84163588)
01A00000340	001	TURBOCHARGER (P.I.N. HHD0330BN7PG57000 AND AFTER) (84163644)
01A00000341	001	STARTER (P.I.N. HHD0330BN7PG57000 AND AFTER) (84163662)
01A00000342	001	HEAT EXCHANGER (P.I.N. HHD0330BN7PG57000 AND AFTER) (84163845)
01A00000343	001	AIR COMPRESSOR (P.I.N. HHD0330BN7PG57000 AND AFTER) (84163908)
01A00010259	001	COVER, ENGINE (87319249)
01A00010303	001	TENSIONER, FAN BELT (87742489)
01A01000274	001	DIPSTICK ASSY (504145799)
01A01000294	001	FILTER INSTAL, TURBOCHARGER (87319233)
01A01000295	001	WATER PUMP INSTAL (87600124)
01A02000166	001	ALTERNATOR INSTAL (87578505)
01A02000167	001	ALTERNATOR ASSY (504028095)
01A02000269	001	TIMING SYSTEM - IDLER SM (87600159)
01A02000291	001	TIMING SYSTEM - IDLER GEAR LG (87600162)

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

01A02000294	001	TURBOCHARGER PARTS (87522850)
01A02000295	001	ENGINE COOLING SYSTEM - THERMOSTAT (87522852)
01A02010274	001	LUBRICATION SYSTEM (87521049)
01A03000274	001	LUBRICATION LINES, TURBOCHARGER (87521056)
01A03000291	001	TIMING SYSTEM - CAMSHAFT GEAR (87600168)
01A03000295	001	ENGINE COOLING SYSTEM (87522859)
01A04000295	001	LINES, AIR COMPRESSOR COOLING (87522860)
01A11000160	001	FUEL PUMP (87318990)
01A12010160	001	FUEL FILTER ASSY (87318991)
01A13020160	001	FUEL SYSTEM (87520611)
01A19010161	001	OIL PUMP INSTAL (87578871)
01D00000001	001	STARTER ASSY (504042667)
02A00000619	001	ENGINE FAN ASSY (87535978)
02A00000647	001	ENGINE ADAPTER PLATE / TEAR GUARD (P.I.N HHD0330BN7PG5700 AND AFTER) (84214517)
02A00010619	001	ENGINE ADAPTER PLATE / TEAR GUARD (87742492)
03A00000600	001	ENGINE MOUNTING (84232371)
04A00000672	001	RADIATOR (87556607)
04A00000673	001	RADIATOR PIPING (87556610)
04A01000673	001	ENGINE COOLING SYSTEM (87556612)
04A02000673	001	ENGINE COOLING (87556614)
04B00000037	001	RADIATOR ASSY (89500421536)
04B00000043	001	RADIATOR ASSEMBLY (8998340822)
05A00000570	001	GEARBOX COOLER CIRCUIT / FILTER (87557132)
05A00000571	001	GEARBOX COOLER CIRCUIT / FILTER W/RETARDER (87557133)
05A00000593	001	GEARBOX COOLER CIRCUIT / FILTER (P.I.N. HHD0330BN7PG57000 AND AFTER) (84146600)
05A00010593	001	TRANSMISSION COOLING CIRCUIT (P.I.N. HHD0330BN7PG57000 AND AFTER) (84214584)
05B00000012	001	COOLER ASSY (89500411763)
06A00000620	001	ENGINE AIR INTAKE / FILTRATION (87544160)
06A00010658	001	ENGINE AIR INTAKE / FILTRATION (P.I.N. HHD0330BN7PG57000 AND AFTER) (84165298)
06B00000018	001	AIR CLEANER ASSY (8900183778)
08A00000661	001	ENGINE EXHAUST (87398741)
08A00000705	001	ENGINE EXHAUST INSTAL (P.I.N. HHD0330BN7PG57000 AND AFTER) (84165308)
10A00000692	001	FUEL SYSTEM (UNTIL P.I.N. HHD0330BN7PG56999) (87557295)
10A00000725	001	FUEL TANK INSTAL (P.I.N. HHD0330BN7PG57000 AND AFTER) (84146945)
10A00000727	001	LINES, FUEL (P.I.N. HHD0330BN7PG5700 AND AFTER) (84160199)
10A00030688	001	TANK, FUEL (87557293)
10B00000002	001	REPAIR KITS, AIR COMPRESSOR ASSY (P.I.N. HHD0330BN7PG5700 AND AFTER) (41211340)
12A00000570	001	PEDAL, THROTTLE CONTROL (87451596)
16A00000546	001	DIPSTICK, GEARBOX (87517032)
16A00000547	001	DIPSTICK, GEARBOX - W/RETARDER (87567052)
16A00000567	001	DIPSTICK, GEARBOX (P.I.N. HHD0330BN7PG57000 AND AFTER) (84152669)
16A00000569	001	DIPSTICK, GEARBOX W/RETARDER (P.I.N. HHD0330BN7PG57000 AND AFTER) (84186753)
18A00000061	001	SECTION INDEX, AUTOMATIC GEARBOX 6WG-260 ZF W/O RETARDER (89500415371)
18A00000062	001	SECTION INDEX, AUTOMATIC GEARBOX 6WG-260 ZF W/RETARDER (89500415372)

Order the manual at mid-west-tech.com >

SECTION INDEX, AUTOMATIC GEARBOX 6WG-260 ZF W/RETARDER (89500415372)

REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTION
18		NSS		1	NOT SERVICED SEPARATELY, Piping - 87450719
		REF			INSTRUCTION, See Figure(s) 18A00000983 (001) For Service Breakdown
19		NSS		1	NOT SERVICED SEPARATELY, Piping - 87450720
		REF			INSTRUCTION, See Figure(s) 18A00000984 (001) For Service Breakdown
20		NSS		1	NOT SERVICED SEPARATELY, Intermediaite Shaft - 87515159
		REF			INSTRUCTION, See Figure(s) 18A00000985 (001) For Service Breakdown
21		NSS		1	NOT SERVICED SEPARATELY, Steering Pump Control - 87450722
		REF			INSTRUCTION, See Figure(s) 18A00000986 (001) For Service Breakdown
22		NSS		1	NOT SERVICED SEPARATELY, Filter / Control Unit - 87515165
		REF			INSTRUCTION, See Figure(s) 18A00010987 (001) For Service Breakdown
23		NSS		1	NOT SERVICED SEPARATELY, Differential Between The Wheels - 87515415
		REF			INSTRUCTION, See Figure(s) 18A00000988 (001) For Service Breakdown
24		NSS		1	NOT SERVICED SEPARATELY, Differential - 87454951
		REF			INSTRUCTION, See Figure(s) 18A00000989 (001) For Service Breakdown
25		NSS		1	NOT SERVICED SEPARATELY, No Figure To Reference
		REF			INSTRUCTION, See Figure(s) For Service Breakdown
26		NSS		1	NOT SERVICED SEPARATELY, Retarder - 87569657
		REF			INSTRUCTION, See Figure(s) 18A00000992 (001) For Service Breakdown

MidWestTech | Case 330B Tier 3 Articulated Dump Truck Parts Catalog | Publication 8428... Order the manual at mid-west-tech.com >

HYDRAULIC DUMP CIRCUIT / BRACKETS (87520032)

REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTION
1		89500410772		1	CONNECTOR, HYD.
2		89500417422		2	HOSE ASSY.
3		89500406108		1	CONNECTION
4		8916627634		16	BOLT, M10 x 30; Replaces 8900103291 Bolt Used On Some Models
5		8900001049		16	WASHER, LOCK
6		8900191136		4	FLANGE
7		8917289180		3	O-RING
8		8900005720		2	SEALRING
9		8900191133		4	FLANGE
10		89500424128		1	BRACKET, BRACKET, Replaces 89500421907 Bracket Ref Item 17
12		89500421880		2	HOSE ASSY.
14		8916587024		4	SCREW, M10 x 20
15		89500406222		2	CONNECTOR, HYD.
16		8900150511		15	COLLAR
17		89500421907		2	BRACKET, If Used, No Longer Required With Ref Item 10 And 17A
17A		89500421495		1	BRACKET, BRACKET, Replaces 89500421907 Bracket Ref Item 17
18		8900125009		2	NUT, If Used, No Longer Required With Ref Item 10 and 17A
19		8916597224		2	SCREW, M6 x 18; If Used, No Longer Required With Ref Item 10 And 17A
20		8900110039		4	COLLAR
21		8900110408		8	SCREW, M14 x 45
22		8900102292		8	WASHER, LOCK
23		89500421861		2	HOSE ASSY.
24		8900191137		4	FLANGE
25		8917289480		2	SEALRING
26		8900191433		2	FLANGE
27		8900115529		4	WASHER, LOCK
28		8999489024		1	GASKET
29		8900155641		1	CAP
31		89500414401		1	CONNECTOR, HYD.

MidWestTech | Case 330B Tier 3 Articulated Dump Truck Parts Catalog | Publication 8428... Order the manual at mid-west-tech.com >

CONTROL COMPONENTS, ELECTRICAL (P.I.N. HHD0330BN7PG57000 AND AFTER) (84152722)

REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTION
		REF			INSTRUCTION, Electrical Control Components (84152722)
1		8900117361		1	SUPPORT
2		8900127538		1	CONTROL UNIT
3		8900116885		18	SWITCH, REMOTE CONTROL
4		8900127567		4	DIODE, Plattes
5		8900125023		2	FUSE, 3A
6		8916688224		4	BOLT, M5 x 30
7		8917128534		4	WASHER, Lock
8		8900109848		4	SCREW, M6 x 30
9		8900120058		12	WASHER
10		8900125013		4	SCREW, M3 x 16
11		8900010953		4	WASHER
12		8900009278		4	NUT
13		8900102609		5	RELAY
14		8900140111		1	SWITCH, REMOTE CONTROL
15		8900124167		1	FLASHER UNIT
17		8900124067		3	FUSE, 20A
19		8900115506		1	FUSE BOX
20		8900115162		1	FUSE BOX
21		8900115163		1	FUSE BOX
22		8900115164		1	PLATE
23		8916787104		8	SCREW, Self Tapping
24		8900114204		2	RELAY
25		8900124067		3	FUSE, 20A
26		8900112439		3	FUSE, 15A
27		8900169021		8	FUSE, 10A
30		8900112438		1	FUSE, 7.5A
31		8900140610		4	BOLT, M6 x 20
33		8900117362		2	BRACKET, Hinge
34		8900125009		4	NUT
35		89500401352		1	PLUG, Cap
36		8917032477		2	BOLT, Spl
37		8900105639		1	RELAY
38		8900112438		8	FUSE, 7.5A

MidWestTech | Case 330B Tier 3 Articulated Dump Truck Parts Catalog | Publication 8428... Order the manual at mid-west-tech.com >