KOBELCO®

PARTS CATALOG

SK170-8
Hydraulic Excavator
Tier III ROPS

84370367
Issued 12/2010

MidWestTech | Kobelco SK170-8 Tier III ROPS Hydraulic Excavator Parts Catalog | Publication 84370367

Order the manual at mid-west-tech.com >

ALPHABETICAL INDEX

	FIGURE	SEQ.
ELECTRICAL ASSY, UPPER	01-079	00
AIR CLEANER - COMPONENTS	01-009	00
AIR CLEANER ASSEMBLY	01-008	00
AIR CONDITIONING (PULLEY ASSEMBLY) (YX20M01029F2)	08-047	00
ALTERNATOR - COMPONENTS (4892318)	08-046	00
ALTERNATOR (101660590002 & 101660590101)	08-045	00
ARM INSTALLATION	03-014	02
ARMREST	01-061	00
BATTERY INSTALLATION	01-087	00
BOOM ASSEMBLY	03-001	00
BOOM GROUP	03-003	00
BOOM INSTAL	03-002	00
BREATHER - ENGINE (101580150001)	08-009	00
BUCKET INSTALLATION	03-019	00
CAB - DOOR ASSY	01-055	08
CAB - DOOR WINDOW	01-055	09
CAB - HARNESS ASSY	01-055	12
CAB - HARNESS ASSY	01-055	05
CAB - LIGHT INSTAL	01-055	13
CAB - RADIO	01-055	11
CAB - SEAL ASSY	01-055	06
CAB - WINDOW ASSY, FR	01-055	14
CAB - WINDOW ASSY, FR	01-055	15
CAB - WINDOW, ROOF	01-055	07
CAB - WIPER INSTAL	01-055	10
CAB ASSY	01-055	02
CAB ASSY	01-055	03
CAB ASSY	01-055	01
CAB ASSY, GLASS	01-055	04
CAB GUARD ASSY	01-057	03
CAB GUARD ASSY	01-057	01
CAB GUARD ASSY	01-057	02
CAB INSTAL	01-053	00
CAMSHAFT - TIMING CONTROL (101580510010)	08-022	00
CASE ASSY, GEAR	07-001	07
CLAMP ASSY	01-062	00
COMPRESSOR ASSY	01-089	00
CONDITIONER, AIR	01-088	05
CONDITIONER, AIR	01-088	06
CONDITIONING, AIR INSTAL	01-088	04
CONDITIONING, AIR INSTAL	01-088	03
CONDITIONING, AIR INSTAL	01-088	01
CONDITIONING, AIR INSTAL	01-088	02
CONNECTING ROD (101580510010)	08-018	00
CONTROL ASSEMBLY, ENGINE	01-004	00
CONTROL BOX ASSY	01-066	00
CONTROL LINES, BLOCK (2 WAY)	01-037	00
CONTROL LINES, BLOCK (STD)	01-036	00
CONTROL LINES, MAIN	01-027	01
CONTROL LINES, MAIN	01-027	02
CONTROL LINES, MULTI (PATTERN CHANGE)	01-034	00
CONTROL LINES, PROPEL	01-033	01
CONTROL LINES, PUMP	01-035	00
CONTROL LINES, REMOTE	01-032	00
CONTROL LINES, REMOTE (N&B - FOOT)	01-038	00
CONTROL LINES, REMOTE (N&B - HAND)	01-039	00

Order the manual at mid-west-tech.com >

CONTROL LINES, REMOTE (SINGLE PEDAL TRAVEL)	01-033	02
CONTROL LINES, VALVE (N&B W/ROTATION)	01-031	00
CONTROL LINES, VALVE (SAFETY)	01-030	00
CONTROL LINES, VALVE (STD)	01-028	02
CONTROL LINES, VALVE (STD)	01-028	01
CONTROL LINES, VAVLE (N&B)	01-029	00
CONTROLLER INSTAL	01-071	00
CONTROLS, OPERATORS	01-067	01
CONTROLS, OPERATORS	01-067	02
CONVERTER	01-073	00
COUNTERWEIGHT INSTALLATION	01-002	00
COVER ASSEMBLY, UNDER	02-002	00
COVER ASSEMBLY, UNDER (YM24C00006F1)	01-049	00
COVER, FRONT GEAR - SENDER (101650480001)	08-006	00
COVER, FRONT GEAR (101660650001)	08-005	00
COVER, REAR GEAR (101660720001)	08-004	00
CRANKCASE (101580210001)	08-007	00
CRANKCASE (101660250001)	08-013	00
CRANKSHAFT (101580210001)	08-017	00
CYLINDER ASSY, ARM	03-013	00
CYLINDER ASSY, BOOM	03-012	00
CYLINDER ASSY, BUCKET	03-018	00
CYLINDER BLOCK (101580210001)	08-002	00
CYLINDER HEAD (101580110002 & 101560480001)	08-010	00
CYLINDER HEAD COVERS (101570140003)	08-012	00
CYLINDER INSTALLATION, ARM	03-008	00
CYLINDER INSTALLATION, BOOM	03-007	00
ENGINE ASSEMBLY (87563564)	08-001	00
ENGINE INSTALLATION	01-003	02
ENGINE INSTALLATION	01-003	01
ENGINE OIL DIPSTICK (10167080001 & 101230810001)	08-024	00
ENGINE OIL SUMP (101230830002)	08-003	00
EXHAUST MANIFOLD (101570910003)	08-016	00
FAN DRIVE (101580640003)	08-033	00
FILTERS	00-001	00
FLYWHEEL - ENGINE (101230730001)	08-020	00
FLYWHEEL HOUSING (101460740001)	08-008	00
FRAME, LOWER	02-001	00
FUEL FILTER (101230470001)	08-040	00
FUEL INJECTION PUMP (101910420003)	08-036	00
FUEL INJECTION SYSTEM - FUEL SYSTEM (101580470104)	08-042	00
FUEL LINES	01-011	02
FUEL LINES	01-011	01
FUEL PUMP (101660420101)	08-038	00
FUEL PUMP (101940450002)	08-041	00
GAUGE CLUSTER	01-076	00
GRIP ASSY	01-070	00
GUARD ASSY, CAB	01-054	00
GUARD INSTALLATION (BONNET)	01-040	02
GUARD INSTALLATION (COMMON)	01-040	01
GUARD INSTALLATION (COMMON)	01-041	00
GUARD INSTALLATION (COVERS)	01-045	00
GUARD INSTALLATION (INSIDE)	01-044	00
GUARD INSTALLATION (PATTERN CHANGER)	01-043	00
GUARD INSTALLATION (PLATES)	01-042	00
GUARD INSTALLATION (SIDE PANEL)	01-046	00
GUARD INSTALLATION (TOOL BOX)	01-047	00
HARNESS ASSY, CAB	01-084	00

Order the manual at mid-west-tech.com >

HARNESS ASSY, FLASHER AND ALARM	01-082	01
HARNESS ASSY, FLASHER AND ALARM	01-082	02
HARNESS ASSY, UPPER	01-080	04
HARNESS ASSY, UPPER	01-080	03
HARNESS ASSY, UPPER	01-080	02
HARNESS ASSY, UPPER	01-080	01
HARNESS ASSY, UPPER (FLOOR PLATE)	01-083	01
HARNESS ASSY, UPPER (FLOOR PLATE)	01-083	02
HARNESS ASSY, UPPER (PATTERN CHANGER)	01-081	00
HEAT EXCHANGER - ENGINE (101570840002)	08-028	00
HOOKS - ENGINE (101570350001)	08-035	00
HYD LINES, ARM CYLINDER (SAFETY)	03-011	00
HYD LINES, BOOM (BASE + STD)	03-009	00
HYD LINES, BOOM (ROTATION)	03-006	00
HYD LINES, BOOM (SAFETY)	03-010	01
HYD LINES, BOOM (SAFETY)	03-010	02
HYD LINES, LOWER	02-009	00
HYD LINES, PROPEL	02-010	00
HYD LINES, SWIVEL	02-011	00
HYDRAULIC LINES - ARM (STD) 3.1M, 2.6M	03-015	00
HYDRAULIC LINES, ARM (NIBBLER & BREAKER) 3.1M, 2.6M	03-016	00
HYDRAULIC LINES, ARM (ROTATION) 3.1M, 2.6M	03-017	00
HYDRAULIC LINES, BOOM (BASE + STD)	03-004	00
HYDRAULIC LINES, BOOM (NIBBLER & BREAKER)	03-005	00
HYDRAULIC LINES, PUMP	01-023	00
HYDRAULIC LINES, PUMP (ROTATION)	01-024	00
HYDRAULIC LINES, RETURN	01-026	00
HYDRAULIC LINES, SWIVEL	01-025	00
HYDRAULIC LINES, UPPER (2 WAY)	01-020	00
HYDRAULIC LINES, UPPER (ROTATION)	01-022	00
HYDRAULIC LINES, UPPER (STD & 2 WAY)	01-021	00
HYDRAULIC LINES, UPPER (STD)	01-019	00
HYDRAULIC PUMP - COMPONENTS	07-001	06
HYDRAULIC PUMP ASSEMBLY	07-001	02
IDLER ADJUSTMENT ASSEMBLY	02-008	00
IDLER ASSY	02-007	00
IDLER ASSY	02-006	00
INJECTION EQUIPMENT - INJECTOR (101580510010)	08-037	00
INJECTION EQUIPMENT - PIPING (101580460001)	08-039	00
INJECTION EQUIPMENT - PIPING (101580490001)	08-043	00
INJECTION PUMP - CONTROL (101580430001)	08-011	00
INSULATION INSTAL	01-056	00
INTAKE MANIFOLD (101570310001)	08-015	00
LEVER ASSY, PROPEL	01-064	00
LIGHT INSTAL, BOOM	01-086	00
LIGHT INSTAL, UPPER	01-085	00
MIRROR INSTALLATION	01-051	00
MIRROR INSTALLATION	01-050	00
MIRROR INSTALLATION, CAB	01-052	00
MOTOR ASSY (SWING)	07-002	00
MUFFLER ASSEMBLY	01-010	00
NAME PLATE INSTALLATION (ANTI-SLIP)	06-006	00
NAME PLATE INSTALLATION (BOOM)	06-010	00
NAME PLATE INSTALLATION (CAB WARNING W/PATTERN CHANGE)	06-008	01
NAME PLATE INSTALLATION (CAB WARNING W/PATTERN CHANGE)	06-008	02
NAME PLATE INSTALLATION (CAB WARNING)	06-007	01
NAME PLATE INSTALLATION (CAB WARNING)	06-007	02
NAME PLATE INSTALLATION (EXTERIOR WARNING)	06-002	02

Order the manual at mid-west-tech.com >

REDUCTION ASSY (SWING)

REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTION
		YM32W00008F2			MOTOR, Includes Ref. 1-32, See Fig. 01-015[00]
1		YM32W01002P1		1	GEAR, Shaft
2		YN32W01052P1		1	GEAR
3		YN32W01117P1		3	GEAR
4		YN32W01054P1		1	GEAR
5		YN32W01055P1		4	GEAR
6		YN32W01056P1		1	RING GEAR
7		YN32W01123F1		1	SPIDER, Assy, Incls. Refs. 7-1 & 7-2
7-1		NSS		1	NOT SERVICED SEPARATELY, Spider
7-2		NSS		3	NOT SERVICED SEPARATELY, Shaft
8		YN32W01058P1		1	CARRIER
9		YN32W01067P1		4	SHAFT
10		YN32W01030P1		1	BEARING
11		YN32W01029P1		1	BEARING
12		YN32W01060P1		1	GASKET
13		YN32W01104P1		1	BOX
14		YN32W01026P1		3	THRUST WASHER
15		YN32W01028P1		3	THRUST WASHER
16		YN32W01022P1		102	ROLLER
17		YN32W01072P1		4	BEARING ASSY
18		YN32W01063P1		8	WASHER
19		ZR16X03500		1	RING, Retaining -- ID 32.20 x OD 35 x Th 1.6mm
20		ZR16X09000		1	RING, Retaining -- ID 84.50 x OD 108 x 3.0mm
21		YN32W01082P1		1	SLEEVE
22		ZP26D08025		4	PIN, Roll -- OD 08 x 25mm Long
23		HS23C14135G1		11	SCREW, M14x2.0x135mm
24		PV02B01073DB		2	CAP, 18.4mm Plastic
25		YN32W01080D1		1	RIGID TUBE, 1/2" PT x 112mm Long
26		ZG31U08000		1	HYD CONNECTOR, Elbow, 90° -- 1/2" PT
27		ZE82T08000		1	PLUG, 1/2" PT
28		ZR16X04000		3	RING, Retaining -- ID 37 x OD 40 x Th 1.8mm
30		YN32W01081P1		1	GASKET
31		ZG91V02000		1	LUBE NIPPLE, 67°x1/8" PT
32		2444Z3305		1	BREATHER, 1/8"PT

MidWestTech | Kobelco SK170-8 Tier III ROPS Hydraulic Excavator Parts Catalog | Public... Order the manual at mid-west-tech.com >

VALVE ASSY, PILOT (H&W)

REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTION
		YN30V00080F1			VALVE, Includes Ref. 1-33, Also See Fig.01-038[00]
1		2436U1142S13		2	SHIM
2		2436U1487S7		2	SHIM
3		2436U2755S4		1	SEAT
5		2436U1354S5		2	SLEEVE
6		2436U1354S6		1	COVER
7		NA		2	NOT SERVICED, PISTON
8		NSS		2	NOT SERVICED SEPARATELY
9		YR30V00013S009		2	SPRING
10		NA		1	NOT SERVICED, NAME PLATE
11		2436U1354S25		2	SHIM
12		YR30V00013S012		1	SHIM
13		YN30V00022S015		1	CAM
14		YN30V00022S016		1	BOOT
15		YN30V00022S017		1	PIN
16		NA		2	NOT SERVICED, BODY
18		2436U2412S26		1	PLUG, 1/4"PF
19		ZS23C12025		1	SCREW, M12x1.75x25mm
20		2436U1354S15		2	BOLT
21		ZS83C08008		2	SCREW, Set -- M08x1.25x08mm
22		2436U1354S16		2	WASHER
23		YN30V00080S023		2	SCREW, #2x4.8mm
24		2436U2888S24		2	PIN
25		NA		1	NOT SERVICED, BALL
26		2436U1487S37		3	BALL
27		ZD12P01000		2	O-RING, ID 09.80 ± 0.17 x OD 13mm
28		ZD12P01100		1	O-RING, ID 10.80 ± 0.18 x OD 15mm
29		YN30V00080S029		2	O-RING
31		2436U1354S26		2	REPAIR KIT
32		NA		2	NOT SERVICED, SPOOL
33		2436U1354S4		2	SPRING
		YN30V00080R200			REPAIR KIT, 16, 25, 32x2

MidWestTech | Kobelco SK170-8 Tier III ROPS Hydraulic Excavator Parts Catalog | Public... Order the manual at mid-west-tech.com >

ROCKER SHAFT (101570130002)

REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTION
1		4895195		4	ROCKER, Incl. Ref 5 - 12
2		4895361		8	PUSH ROD
3		2852866		4	SCREW, M08x1.25x60mm
4		4892860		4	SCREW, M12x1.25x183mm
5		4895363		2	SNAP RING
6		4895364		2	WASHER
7		4895196		1	ROCKER ARM, Incl. Ref. 8 - 10
8		4895365		2	INSERT
9		4895198		2	NUT, 3/8"-24 UNF
10		4895199		2	ADJUSTMENT SCREW, 3/8"-24 UNF x 25.85mm
11		4895200		1	ROCKER ARM, Incl. Ref. 8 - 10
12		4895204		1	SHAFT

MidWestTech | Kobelco SK170-8 Tier III ROPS Hydraulic Excavator Parts Catalog | Public... Order the manual at mid-west-tech.com >