KOBELCO®

PARTS CATALOG

SK210-8
Hydraulic Excavator
Tier III ROPS

84370368
Issued 12/2010

Order the manual at mid-west-tech.com >

ALPHABETICAL INDEX

	FIGURE	SEQ.
AIR CLEANER ASSY	01-010	02
AIR CLEANER ASSY	01-010	01
ALTERNATOR	08-035	01
ALTERNATOR - COMPONENTS	08-035	02
ARM 2.4M, 2.94M, 3.5M	03-023	02
ARM (LONG REACH)	03-024	02
ARM (LONG REACH)	03-024	01
ARM 2.4M, 2.94M, 3.5M	03-023	01
ARM CYLINDER HYDRAULIC LINES STD (SAFETY)	03-013	00
ARM CYLINDER INSTALL	03-015	00
ARM CYLINDER INSTALL (LONG REACH)	03-016	00
ARM INSTAL (LONG REACH)	03-022	02
ARM INSTALL 2.4M, 2.94M, 3.5M	03-022	01
ARMREST	01-044	00
BATTERY ASSY	01-079	00
BOOM (LONG REACH)	03-003	00
BOOM CYLINDER ASSEMBLY STD & LONG REACH	03-019	00
BOOM CYLINDER HYD LINES STD & LONG REACH	03-012	00
BOOM CYLINDER INSTALL	03-011	00
BOOM GROUP	03-004	00
BOOM GROUP (LONG REACH)	03-005	00
BOOM HYD LINES (50 FT LONG REACH ROT)	03-010	00
BOOM HYD LINES (50 FT LONG REACH)	03-009	00
BOOM HYD LINES STD	03-006	00
BOOM INSTALL	03-001	00
BOOM STD	03-002	00
BREATHER - ENGINE	08-005	00
BUCKET INSTAL (LONG REACH)	03-025	02
BUCKET INSTALLATION	03-025	01
CAB - DOOR ASSY	01-064	08
CAB - DOOR WINDOW	01-064	09
CAB - HARNESS ASSY	01-064	05
CAB - HARNESS ASSY	01-064	12
CAB - LIGHT INSTAL	01-064	13
CAB - RADIO	01-064	11
CAB - SEAL ASSY	01-064	06
CAB - WINDOW ASSY, FR	01-064	15
CAB - WINDOW ASSY, FR	01-064	14
CAB - WINDOW, ROOF	01-064	07
CAB - WIPER INSTAL	01-064	10
CAB ASSY	01-064	03
CAB ASSY	01-064	02
CAB ASSY	01-064	01
CAB ASSY, GLASS	01-064	04
CAB GUARD ASSY	01-066	03
CAB GUARD ASSY	01-066	02
CAB GUARD ASSY	01-066	01
CAB INSTAL	01-062	00
CAMSHAFT - TIMING CONTROL	08-016	00
CASE ASSY, GEAR (ROTATION)	07-015	00
CLAMP ASSY	01-045	00
COMPRESSOR ASSY	01-080	08
CONDITIONER, AIR	01-080	07
CONDITIONER, AIR	01-080	06
CONDITIONING, AIR	01-080	01
CONDITIONING, AIR INSTAL	01-080	02

Order the manual at mid-west-tech.com >

CONDITIONING, AIR INSTAL	01-080	05
CONDITIONING, AIR INSTAL	01-080	03
CONDITIONING, AIR INSTAL	01-080	04
CONNECTING ROD	08-012	00
CONTROL ASSY, ENGINE	01-006	00
CONTROL BOX ASSY	01-049	00
CONTROL LINES, BLOCK (2 WAY)	01-042	00
CONTROL LINES, BLOCK (PT)	01-040	00
CONTROL LINES, BLOCK (PT-N&B)	01-041	00
CONTROL LINES, BLOCK (STD)	01-043	00
CONTROL LINES, MAIN	01-026	00
CONTROL LINES, MAIN (EXTREAM REACH)	01-028	02
CONTROL LINES, MAIN (EXTREAM REACH)	01-028	01
CONTROL LINES, MAIN (EXTREAM REACH)	01-028	03
CONTROL LINES, MULTI	01-039	00
CONTROL LINES, PROPEL	01-038	01
CONTROL LINES, PUMP	01-037	00
CONTROL LINES, REMOTE	01-034	00
CONTROL LINES, REMOTE (NIBBLER & BREAKER - FOOT)	01-035	00
CONTROL LINES, REMOTE (NIBBLER & BREAKER - HAND)	01-036	00
CONTROL LINES, REMOTE (SINGLE PEDAL TRAVEL)	01-038	02
CONTROL LINES, VALVE	01-029	01
CONTROL LINES, VALVE	01-029	02
CONTROL LINES, VALVE (NIBBLER & BREAKER)	01-030	00
CONTROL LINES, VALVE (NIBBLER & BREAKER W/ROTATION)	01-031	00
CONTROL LINES, VALVE (ROTATION)	01-032	00
CONTROL LINES, VALVE (SAFETY)	01-033	00
CONTROLLER INSTAL	01-054	00
CONTROLS, OPERATORS	01-050	01
CONTROLS, OPERATORS	01-050	02
CONVERTER	01-056	00
COUNTERWEIGHT INSTAL	01-003	00
COUNTERWEIGHT INSTAL (EXTREAM REACH)	01-004	00
COVER ASSEMBLY, UNDER	02-011	00
COVER ASSY, UNDER	01-073	00
CRANKCASE	08-002	03
CRANKCASE	08-002	02
CRANKCASE	08-002	01
CRANKCASE COVERS	08-004	03
CRANKCASE COVERS	08-004	02
CRANKCASE COVERS	08-004	01
CRANKSHAFT	08-011	00
CYLINDER ASSY, ARM	03-020	00
CYLINDER ASSY, ARM (LONG REACH)	03-021	00
CYLINDER ASSY, BUCKET	03-034	00
CYLINDER ASSY, BUCKET (LONG REACH)	03-035	00
CYLINDER HEAD	08-006	00
CYLINDER HEAD COVERS	08-007	00
CYLINDER INSTAL, BUCKET	03-031	00
CYLINDER INSTALL, BUCKET (LONG REACH)	03-032	00
ELECTRICAL ASSY, UPPER	01-078	00
ENGINE	08-001	00
ENGINE INSTALLATION	01-005	01
ENGINE INSTALLATION	01-005	02
ENGINE OIL DIPSTICK	08-023	00
ENGINE OIL SUMP	08-003	00
EXHAUST MANIFOLD	08-010	00
FAN DRIVE	08-032	00

Order the manual at mid-west-tech.com >

FILTERS	00-001	00
FLYWHEEL - ENGINE	08-014	00
FRAME ASSY, LOW (H & W)	02-002	00
FRAME GROUP, UPPER	01-001	00
FRAME GROUP, UPPER (H&W) (BOLT SPACER)	01-002	00
FRAME, LOWER	02-001	00
FRAME, LOWER H & W FULL TRACK GUARD	02-010	00
FUEL FILTER	08-019	00
FUEL LINES	01-012	01
FUEL LINES	01-012	02
FUEL PUMP	08-020	00
FUEL TANK INSTALLATION	01-013	00
GAUGE CLUSTER	01-075	00
GRIP ASSY	01-053	00
GUARD ASSY, CAB	01-063	00
GUARD INSTAL (BONNET)	01-072	00
GUARD INSTAL (COMMON)	01-069	01
GUARD INSTAL (COMMON)	01-069	02
GUARD INSTAL (COMMON) TOOL BOX ASSY	01-069	03
GUARD INSTAL (PARTITION)	01-070	00
GUARD INSTAL (SIDE PANEL)	01-071	00
HARNESS ASSY, CAB	01-087	00
HARNESS ASSY, FLASHER AND ALARM	01-085	01
HARNESS ASSY, FLASHER AND ALARM	01-085	02
HARNESS ASSY, UPPER	01-083	01
HARNESS ASSY, UPPER	01-083	04
HARNESS ASSY, UPPER	01-083	03
HARNESS ASSY, UPPER	01-083	02
HARNESS ASSY, UPPER (FLOOR PLATE)	01-086	02
HARNESS ASSY, UPPER (FLOOR PLATE)	01-086	01
HARNESS ASSY, UPPER (PATTERN CHANGER)	01-084	00
HEAT EXCHANGER - ENGINE	08-027	00
HOOKS - ENGINE	08-036	00
HYD LINES, ARM (ROTATION) 2.4M, 2.94M, 3.5M	03-028	00
HYD LINES, BOOM CYLINDER (BOOM & ARM SAFETY)	03-014	00
HYD LINES, LOWER	02-012	00
HYD LINES, LOWER H&W	02-013	00
HYD LINES, PROPEL STD, H&W	02-015	00
HYD LINES, PUMP	01-020	02
HYD LINES, PUMP	01-020	01
HYD LINES, PUMP (ROTATION)	01-020	03
HYD LINES, RETURN	01-025	01
HYD LINES, RETURN	01-025	02
HYD LINES, SWIVEL	02-014	00
HYD LINES, SWIVEL	01-024	00
HYD LINES, UPPER (NIBBLER & BREAKER)	01-022	00
HYD LINES, UPPER (ROTATION)	01-023	00
HYD LINES, UPPER (STD)	01-021	02
HYD LINES, UPPER (STD)	01-021	01
HYDRAULIC LINES - ARM 2.4M, 2.94M, 3.4M	03-026	00
HYDRAULIC LINES, ARM (LONG REACH W/ ROTATION)	03-030	00
HYDRAULIC LINES, ARM (LONG REACH)	03-029	00
HYDRAULIC LINES, ARM (NIBBLER & BREAKER) 2.4M, 2.94M, 3.5M	03-027	00
HYDRAULIC LINES, ARM CYLINDER (LONG REACH)	03-018	00
HYDRAULIC LINES, ARM CYLINDER LQ42H00136F1	03-017	00
HYDRAULIC LINES, CYLINDER, BUCKET (LONG REACH)	03-033	00
HYDRAULIC LINES,BOOM (ROT)	03-008	00
HYDRAULIC LINES. BOOM (2 WAY)	03-007	00

Order the manual at mid-west-tech.com >

CYLINDER ASSY, ARM

REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTION
		YN01V00175F1			CYLINDER, ASSY,ARM
1		NSS		1	NOT SERVICED SEPARATELY, TUBE,CYLINDER
2		NSS		1	NOT SERVICED SEPARATELY, ROD,PISTON
3		YN01V00105S003		1	CYLINDER HEAD
4		2438U1018S4		1	BUSHING
5		2438U776S5		1	SNAP RING
6		YN01V00175S006		1	RING, BUFFER
7		YN01V00175S007		1	RING, U
8		YN01V00105S008		1	BACK-UP RING
9		2438U776S9		1	RING
10		ZD12G13000		1	O-RING, ID 129.40 ± 1.05 x OD 135mm
11		LQ01V00001S011		1	RING
12		ZS23C18080		12	SCREW, M18x2.50x80mm
13		YN01V00175S013		1	BEARING, BEARING,CUSHION
14		YN01V00175S014		1	SEAL, SEAL,CUSHION
15		YN01V00175S015		1	PISTON, PISTON
16		LQ01V00001S016		1	RING
17		LQ01V00001S017		2	BACK-UP RING
18		YN01V00175S018		2	RING, SLIDE
19		LQ01V00001S019		2	RING
20		2438U953S21		1	SCREW
21		2436R624S6		1	BALL
22		YN01V00175S022		1	BEARING, BEARING,CUSHION
23		LQ01V00007S025		1	SEAL
24		2438U1104S25		2	STOP
25		2438U1104S26		1	RING
26		YN01V01108P1		4	BUSHING, BUSHING
27		2438U1102S26		4	RING
K		YN01V00175R100		1	KIT, REPAIR ROD SIDE CONSISTS OF ITEM 6X1, 7X1, 8X1, 9X1, 10X1, 11X1
K		YN01V00175R200		1	KIT, REPAIR PISTON SIDE CONSISTS OF ITEM 14X1, 16X1, 17X2, 18X2, 19X2, 23X1
K		YN01V00175R300		1	KIT, REPAIR ALL(ROD + PISTON) CONSISTS OF ITEM 6X1, 7X1, 8X1, 9X1, 10X1, 11X1, 14X1, 16X1, 17X2, 18X2, 19X2, 23X1

MidWestTech | Kobelco SK210-8 Tier III ROPS Hydraulic Excavator Parts Catalog | Public... Order the manual at mid-west-tech.com >

MOTOR ASSY (SWING)

REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTION
51		YN22V00014FA		2	VALVE, Relief (Includes ZD12G03000)
		ZD12G03000		1	O-RING, ID 29.4 ± 0.29 x OD 35mm (Part Of Ref 51)
52		YN20V00004F1		1	VALVE, Assy - See Fig. 07-001[02]
101		YN15V00025S101		1	SHAFT
111		YN15V00025S111		1	CYLINDER
114		YN15V00025S114		1	SPRING
121		NSS		0	NOT SERVICED SEPARATELY, PISTON
122		NSS		0	NOT SERVICED SEPARATELY, SHOE
123		YN15V00025S123		1	PLATE
124		YN15V00025S124		1	PLATE
131		YN15V00025S131		1	PLATE
301		YN15V00035S301		1	BOX, CASE
303		NSS		0	NOT SERVICED SEPARATELY, CASE
351		YN15V00025S351		2	SPOOL
355		YN15V00002S355		2	SPRING
390		NSS		0	NOT SERVICED SEPARATELY, NAME PLATE
391		2437U407S983		2	RIVET
401		ZS23C20045		4	CAP, Screw -- M20x2.5x45mm
443		YN15V00002S011		1	BEARING
444		LQ15V00008S010		1	BEARING
451		NSS		0	NOT SERVICED SEPARATELY, PIN
469		YN15V00002S012		2	PLUG, PLUG
472		YN15V00025S489		1	O-RING
488		ZD12P02800		2	O-RING, ID 27.70 ± 0.27 x OD 34mm
491		YN15V00035S491		1	GASKET, OIL SEAL
702		YN15V00002S014		1	PISTON
706		2441U736S706		1	O-RING
707		2415U188S707		1	O-RING
712		YN15V00025S712		18	SPRING
742		YN15V00025S742		3	PLATE
743		YN15V00025S743		4	PLATE
980		YN15V00035S980		1	PLUG, PLUG
984		YN15V00035S984		1	PLUG, PLUG
985		YN15V00035S985		3	PLUG, PLUG
993		ZE82T08000		1	PLUG, 1/2" PT

MidWestTech | Kobelco SK210-8 Tier III ROPS Hydraulic Excavator Parts Catalog | Public... Order the manual at mid-west-tech.com >

PISTON - ENGINE

REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTION
1		8094740		6	PISTON & RINGS KIT, Standard (Includes Ref 2-4)
1		87317252		6	PISTON & RINGS KIT, 0.4mm Oversize (Includes Ref 2-4)
1		87647551		6	PISTON & RINGS KIT, 0.8mm Oversize (Includes Ref 2-4)
2		4892712		1	PISTON PIN
3		4892713		2	SNAP RING
4		8094845		1	PISTON RINGS KIT, Standard
4		87582180		1	PISTON RINGS KIT, 0.4mm Oversize
4		87582181		1	PISTON RINGS KIT, 0.8mm Oversize

MidWestTech | Kobelco SK210-8 Tier III ROPS Hydraulic Excavator Parts Catalog | Public... Order the manual at mid-west-tech.com >