CX210B / CX210BLR
Crawler Excavator
Tier III

Parts Catalog

Print No. 84384823
Issued 9/2010
Replaces: 87519710NA

CASE CONSTRUCTION

MidWestTech | Case CX210B, CX210BLR Tier III Crawler Excavator Parts Catalog | Publication 84384823
Order the manual at mid-west-tech.com >

ALPHABETICAL INDEX

	FIGURE	SEQ.
ACCESS DOOR - INSULATION	09-06	
AIR CLEANER - WITH NOISE REDUCTION COVERS	02-03A	
AIR CLEANER - WITHOUT NOISE REDUCTION COVERS	02-03	
AIR CONDITIONING - CONDENSER AND RECEIVER-DRIER	09-23	
AIR CONDITIONING - CONDENSER AND RECEIVER-DRIER	09-25	
AIR CONDITIONING - DUCTS	09-20	
AIR CONDITIONING - EVAPORATOR	09-22	
AIR CONDITIONING SYSTEM	09-21	
ARM (2.40 M) - SHORT	09-57	
ARM (2.40 M) - STANDARD	09-56	
ARM (2.94 M) - OPTIONAL	09-59	
ARM (2.94 M) - STANDARD	09-58	
ARM CYLINDER - MOUNTING	09-39	
BATTERY - CABLES	04-14	
BELT AND VENTILATOR - FAN GUARD	02-27	
BLOCK HEATER	02-14A	
BOOM	09-35	
BOOM CYLINDER - MOUNTING	09-37	
BRACKET	04-04	
BRACKET - FAN GUARD	02-34	
BREATHER	02-23	
BUCKET CYLINDER - MOUNTING	09-40	
BUCKET LINKAGE - HEAVY DUTY	09-54	
BUCKET LINKAGE - STANDARD	09-53	
BUCKETS, ESCO - DITCH CLEANING BUCKETS	09-44	
BUCKETS, ESCO - GENERAL PURPOSE BUCKETS	09-42	
BUCKETS, ESCO - HEAVY DUTY BUCKETS	09-42A	
BUCKETS, ESCO - HEAVY DUTY CAST BUCKET	09-43	
BUCKETS, ESCO - SEVERE DUTY BUCKETS	09-42B	
CAB - AIR CONDITIONING	09-24	
CAB - MIRROR, REAR VIEW	09-31	
CAB - ROOF, OPENABLE WINDOW	09-29	
CAB - WINDOW, FRONT	09-30	
CAB - LOWER FRONT AND REAR GLASS AND HANDRAILS	09-27	
CAB - SIDE GLASS AND ELECTRONIC CONTROL UNIT	09-26	
CAB DOOR	09-28	
CAB ELECTRICAL - WIPER, WINDSHIELD	04-10	
CAMSHAFT - GEAR, IDLER	02-17	
CAMSHAFT - VALVE MECHANISM	02-16	
CLAMPS - ARM	09-39	00
CLAMPS - ARM	09-39	01
CLAMPS - ARM	09-39	02
CLAMPS - ARM	09-39	03
CLAMPS - BOOM	09-38	00
CLAMPS - BOOM	09-38	01
CLAMPS - BOOM	09-38	02
CLAMPS - BOOM	09-38	03
CLAMPS - BOOM	09-38	04
CONTROLLER	04-13	
CONTROLS - OPERATORS COMPARTMENT	09-09	
CONVERTER	04-09	
COOLANT RECOVERY SYSTEM	02-06	
COUNTERWEIGHT - SOUNDPROOFING	09-04	
COVER - CYLINDER HEAD	02-10	
CYLINDER ASSY - ARM	08-85	
CYLINDER ASSY, BOOM, LEFT HAND	08-84	

Order the manual at mid-west-tech.com >

CYLINDER ASSY, BOOM, RIGHT HAND	08-83
CYLINDER ASSY, BUCKET	08-86
CYLINDER BLOCK	02-13
CYLINDER BLOCK	02-14
CYLINDER HEAD	02-12
CYLINDER HEAD - VALVE MECHANISM	02-11
DECAL - OPERATORS COMPARTMENT	09-45
DECALS	09-52
DECALS	09-46
DECALS	09-47
DECALS	09-49
DECALS	09-50
DECALS	09-51
DECALS - WARNING	09-48
DOG CHAIN	09-19
ELECTRICAL - CAB	04-07
ELECTRICAL ACCESSORIES - ENGINE	04-01
ELECTRICAL ACCESSORIES - ENGINE	04-02
ELECTRICAL ACCESSORIES - ENGINE	04-03
ENGINE FLYWHEEL HOUSING	02-20
ENGINE FLYWHEEL HOUSING	02-35
ENGINE FLYWHEEL HOUSING	02-36
ENGINE MOUNTING - ENGINE	02-01
ENGINE MOUNTING - ENGINE	02-02
ENGINE WATER CIRCUIT	02-26
ENGINE WATER CIRCUIT - THERMOSTAT	02-25
EXHAUST GAS RECIRCULATION SYSTEM	02-33
EXHAUST PIPE	02-22
EXHAUST SYSTEM - MUFFLER	02-04
FILTERS AND CAPACITIES	00-01
FOOT CONTROL VALVE	08-72A
FRAMES, COVERS - INSULATION	09-05
FRONT TIMING GEAR COVER	02-19
FUEL FILLING PUMP - OPTIONAL	03-03
FUEL FILTER	03-07
FUEL INJECTION PUMP	03-04
FUEL LINES	03-02
FUEL SYSTEM	03-05
FUEL SYSTEM	03-06
FUEL SYSTEM	03-08
FUEL SYSTEM	03-09
FUEL TANK	03-01
GEAR ASSY, REDUCTION MOTOR, SWING	08-54
GEAR PUMP ASSY	08-97
GUARD, BRUSH - CAB BRUSH SCREEN	09-32
GUARD, BRUSH - CAB FRONT GRILLE	09-33
GUIDE, CHAIN	05-02
HARNESS, MAIN - CHASSIS, UPPERSTRUCTURE	04-05
HARNESS, MAIN - RELAY PANEL	04-06
HOOD, ENGINE - INSULATION	09-07
HORN	04-11
HYDRAULIC RESERVOIR	08-01
HYDRAULIC RESERVOIR - PRESSURE SWITCH	08-02
HYDRAULICS - ARM AND BUCKET	08-11
HYDRAULICS - ARM CYLINDER LINE	08-12
HYDRAULICS - BOOM	08-10
HYDRAULICS - BUCKET, 2.40 METER (7FT 10 IN) ARM	08-13
HYDRAULICS - BUCKET, 2.9 METER (9 FT 6 IN) ARM	08-14

Order the manual at mid-west-tech.com >

HYDRAULICS - CONTROL VALVE SUPPLY	08-06
HYDRAULICS - DRAIN LINE	08-08
HYDRAULICS - JOINT, SWIVEL CENTER	08-55
HYDRAULICS - PILOT PRESSURE, RETURN LINES	08-23
HYDRAULICS - PILOT PRESSURE, RETURN LINES	08-24
HYDRAULICS - PILOT PRESSURE, RETURN LINES	08-25
HYDRAULICS - PUMP SUCTION LINE	08-05
HYDRAULICS - RESERVOIR RETURN	08-07
HYDRAULICS - SWING	08-09
HYDRAULICS - TRACK DRIVE	06-05
HYDRAULICS - TRAVEL	06-06
HYDRAULICS, AUXILIARY - DOUBLE ACTING CIRCUIT, HAND OPERATED	08-30
HYDRAULICS, AUXILIARY - DOUBLE ACTING CIRCUIT, HAND OPERATED	08-31
HYDRAULICS, AUXILIARY - MULTI-PURPOSE + 3 WAY VALVE, PEDAL ACTIVATED	08-32
HYDRAULICS, AUXILIARY - MULTI-PURPOSE + 3 WAY VALVE, PEDAL ACTIVATED	08-33
HYDRAULICS, AUXILIARY - MULTI-PURPOSE + 3 WAY VALVE, PEDAL ACTIVATED	08-34
HYDRAULICS, AUXILIARY - MULTI-PURPOSE + 3 WAY VALVE, TRIGGER ACTIVATED	08-36
HYDRAULICS, AUXILIARY - MULTI-PURPOSE + 3 WAY VALVE, TRIGGER ACTIVATED	08-37
HYDRAULICS, AUXILIARY - SECOND ACTING CIRCUIT, HAND OPERATED	08-39
HYDRAULICS, AUXILIARY - SECOND ACTING CIRCUIT, PEDAL ACTIVATED	08-38
HYDRAULICS, AUXILIARY - SINGLE ACTING CIRCUIT, HAND OPERATED	08-28
HYDRAULICS, AUXILIARY - SINGLE ACTING CIRCUIT, HAND OPERATED	08-29
HYDRAULICS, AUXILIARY - SINGLE ACTING CIRCUIT, PEDAL ACTIVATED	08-26
HYDRAULICS, AUXILIARY - SINGLE ACTING CIRCUIT, PEDAL ACTIVATED	08-27
HYDRAULICS, AUXILIARY - MULTI-PURPOSE + 3 WAY VALVE, TRIGGER ACTIVATED	08-35
INTAKE PIPE	02-21
KITS, FREE SWING	08-98
KRJ10290 PUMP ASSY, HYDRAULIC - GEAR PUMP ASSY	08-88
KRJ10290 PUMP ASSY, HYDRAULIC - PISTON	08-87
KRJ10290 PUMP ASSY, HYDRAULIC - REGULATOR	08-90
KRJ10290 PUMP ASSY, HYDRAULIC - REGULATOR	08-91
KRJ10290 PUMP ASSY, HYDRAULIC - VALVE ASSY	08-89
KRJ10310 CONTROL VALVE - SUPPORT	08-56
KRJ10310 VALVE ASSY - CONTROL	08-58
KRJ10310 VALVE ASSY - CONTROL	08-60
KRJ10310 VALVE ASSY - CONTROL	08-61
KRJ10310 VALVE ASSY - CONTROL	08-62
KRJ10310 VALVE ASSY - CONTROL	08-63
KRJ10310 VALVE ASSY - CONTROL	08-59
KRJ15970 PUMP ASSY, HYDRAULIC - GEAR PUMP ASSY	08-93
KRJ15970 PUMP ASSY, HYDRAULIC - PISTON	08-92
KRJ15970 PUMP ASSY, HYDRAULIC - REGULATOR	08-95
KRJ15970 PUMP ASSY, HYDRAULIC - REGULATOR	08-96
KRJ15970 PUMP ASSY, HYDRAULIC - VALVE ASSY	08-94

Order the manual at mid-west-tech.com >

CYLINDER HEAD - VALVE MECHANISM

REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTION
0-14		REF		1	INSTRUCTION, Rocker; See Figure 02-16
0-25		REF		1	INSTRUCTION, Stud; See Figure 02-21
1		87654337		1	CYLINDER HEAD, Incl. 4, 5A, 5B, 7A - 7D, 23, 24A, 57, 58A, 58B; See Figure 02-12; Replaces 87595278
2		87595389		1	CYLINDER HEAD GASKET, Without Holes A & B
2		87595395		1	CYLINDER HEAD GASKET, With Hole A
2		87595396		1	CYLINDER HEAD GASKET, With Holes A & B
3A		438152A1		1	SCREW
3B		438153A1		1	SCREW
3C		87595398		18	SCREW
4		438044A1		16	GUIDE
5A		72109510		8	VALVE SEAT
5B		72109512		8	VALVE SEAT
7A		87595408		5	CUPEL
7B		289076A1		4	CUP
7C		71455287		7	PLUG
7D		353962A1		5	PLUG
10		438043A1		4	HEATER COIL
11		87595410		1	ELEC CONNECTOR
23		87595428		10	NUT
24A		438026A1		8	STUD
24B		438025A1		2	STUD
25		87377930		1	PLUG
47		87595430		2	STUD
57		87528150		4	NOZZLE HOLDER
58A		87377928		4	GASKET
58B		87377929		4	GASKET
59		87379448		8	GUIDE
71		87595463		2	SCREW
192		87595807		4	NUT
201		437881A1		4	GASKET
258		87595816		1	ADAPTER

MidWestTech | Case CX210B, CX210BLR Tier III Crawler Excavator Parts Catalog | Public... Order the manual at mid-west-tech.com >

ENGINE WATER CIRCUIT - THERMOSTAT

REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTION
0-10		REF		1	INSTRUCTION, See Figure 02-34
0-11		REF		1	INSTRUCTION, See Figure 02-11
0-12		REF		1	INSTRUCTION, See Figure 02-13
0-32		REF		1	INSTRUCTION, See Figure 02-26
0-60		REF		1	INSTRUCTION, See Figure 04-01
1A		87596469		1	THERMOSTAT, Incl. 66
1B		87596477		1	THERMOSTAT, Incl. 66
14		289415A1		1	PLUG
15		87596482		1	PIPE
49		87378562		1	PIPE, Incl. 112
66		87378564		2	GASKET
112		87379740		1	PLUG
119		76591841		1	PIPE

MidWestTech | Case CX210B, CX210BLR Tier III Crawler Excavator Parts Catalog | Public... Order the manual at mid-west-tech.com >

ELECTRICAL ACCESSORIES - ENGINE

REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTION
0-11		REF		1	INSTRUCTION, See Figure 02-11
0-25		REF		1	INSTRUCTION, See Figure 02-21
0-33		REF		1	INSTRUCTION, See Figure 02-27
0-50		REF		1	INSTRUCTION, See Figure 02-30
8-10		REF		1	INSTRUCTION, See Figure 04-03
1		87711539		1	STARTER MOTOR, MOTOR, STARTER, Replaces 87597118
2		87709230		1	ALTERNATOR, GENERATOR, Replaces 87560108
7		87597755		2	NUT
16		289045A1		1	BOLT
17		87597767		1	WASHER
18		87597771		1	WASHER
21		87597772		1	BRACKET
23		437982A1		1	SUPPORT
26		87597774		3	SCREW
89		289737A1		1	SENSOR
129B		87336453		1	SENSOR
210		87597864		1	SCREW
293		289982A1		1	CABLE
520		87597867		1	SENSOR
766		71455187		1	SEALING WASHER
782		87597870		2	SCREW
797		87378549		1	SENSOR
898		87379342		1	SENSOR

MidWestTech | Case CX210B, CX210BLR Tier III Crawler Excavator Parts Catalog | Public... Order the manual at mid-west-tech.com >