KOBELCO®

PARTS CATALOG

SK25SR
Compact Excavator

APPLICABLE
ASN PV12001

84404961
Issued 11/2010
Replaces: S4PV1011

MidWestTech | Kobelco SK25SR Compact Excavator Parts Catalog | Publication 84404961

Order the manual at mid-west-tech.com >

ALPHABETICAL INDEX

	FIGURE	SEQ.
BATTERY INSTAL	01-039	
BLOCK ASSY, RELIEF PV15V01005F1	07-029	
BOOM ASSY	03-001	
BOOM ASSY (BREAKER)	05-038	
BRACKET ASSY, SWING	01-002	
BUCKET ASSY, 0.035M3	05-045	
BUCKET ASSY, 0.080M3	05-043	
BUCKET ASSY, 0.080M3	05-046	
BUCKET ASSY, 0.088M3	05-044	
BUCKET ASSY, 0.80M3	03-009	
BUCKET INSTAL	03-008	
CAB ASSY, PH02C00003F3	05-015	01
CAB ASSY, PH02C00003F3	05-015	02
CAB ASSY, PH02C00003F3	05-015	03
CAB ASSY, PH02C00003F4	05-014	01
CAB ASSY, PH02C00003F4	05-014	02
CAB ASSY, PH02C00003F4	05-014	03
CAB INSTAL	05-013	
CAMSHAFT & DRIVING GEAR	08-007	
CANOPY ASSY	01-031	
CLEANER ASSY, AIR	01-009	
CONDENSER ASSY	05-033	
CONTROL ASSY, ENGINE	05-020	
CONTROL ASSY, ENGINE	01-005	
CONTROL BOX ASSY (CAB) (FOR LEFT SIDE)	05-026	
CONTROL BOX ASSY (CAB) (FOR RIGHT SIDE)	05-027	
CONTROL BOX ASSY (CANOPY) (FOR LEFT SIDE)	01-022	
CONTROL BOX ASSY (CANOPY) (FOR RIGHT SIDE)	01-023	
CONTROL LINES, REMOTE	01-025	01
CONTROL LINES, REMOTE	01-025	02
CONTROL LINES, REMOTE (A.B SHIFTER)	05-023	01
CONTROL LINES, REMOTE (A.B SHIFTER)	05-023	02
CONTROL LINES, REMOTE (MULTI)	05-022	01
CONTROL LINES, REMOTE (MULTI)	05-022	02
CONTROL LINES, REMOTE (MULTI)	05-022	03
CONTROL LINES, VALVE	01-026	01
CONTROL LINES, VALVE	01-026	02
CONTROLS OPERATORS (CAB)	05-025	02
CONTROLS, OPERATORS	01-021	01
CONTROLS, OPERATORS	01-021	02
CONTROLS, OPERATORS	01-020	01
CONTROLS, OPERATORS	01-020	02
CONTROLS, OPERATORS (CAB)	05-025	01
CONTROLS, OPERATORS (CAB, A.B SHIFTER)	05-024	01
CONTROLS, OPERATORS (CAB, A.B SHIFTER)	05-024	02
COOLER ASSY	05-029	01
COOLER ASSY	05-029	02
COOLER ASSY	05-031	01
COOLER ASSY	05-031	02
COOLER ASSY, PH20M00009F1	05-032	
COOLING WATER SYSTEM	08-010	
COUNTER WEIGHT, INSTALLATION	01-003	
COUNTERWEIGHT INSTALLATION (GAIN)	05-003	
COVER ASSY, UNDER	01-035	
COVER ASSY, VALVE PW30V01006F1	07-002	
COVER ASSY, VALVE PW30V01009F1	07-005	

Order the manual at mid-west-tech.com >

CRANKSHAFT & PISTON	08-008	
CYLINDER ASSY, ARM PV01V00022F1	07-036	
CYLINDER ASSY, BOOM (CAB) PV01V00026F1	07-035	
CYLINDER ASSY, BOOM (CANOPY) PV01V00021F1	07-034	
CYLINDER ASSY, BUCKET PV01V00035F1	07-037	
CYLINDER ASSY, DOZER PV01V00025F1	07-038	
CYLINDER ASSY, SWING PV01V00024F1	07-039	
CYLINDER BLOCK	08-001	
CYLINDER HEAD AND BONNET	08-004	
CYLINDER INSTALLATION	03-003	
DOOR ASSY, CAB	05-016	
DOZER ASSY	02-010	
DOZER ASSY, LONG	05-037	
ELEC ASSY	05-035	
ENGINE ASSY	01-004	
ENGINE INSTALLATION	01-006	
EXHAUST MANIFOLD & SILENCER	08-006	
FILTER LIST	00-001	
FLYWHEEL HOUSING & OIL SUMP	08-003	
FRAME ASSY, UPP (COOLER)	05-001	
FRAME ASSY, UPP (NIBBLER AND BREAKER)	05-002	
FRAME ASSY, UPPER	01-001	
FUEL INJECTION PUMP	08-011	
FUEL INJECTION VALVE	08-013	
FUEL LINE	08-014	
FUEL LINES	01-011	
GASKET SET	08-017	
GEAR HOUSING	08-002	
GENERATOR	08-016	
GOVERNOR	08-012	
GUARD INSTALLATION	01-033	01
GUARD INSTALLATION	01-033	02
GUARD INSTALLATION	01-034	01
GUARD INSTALLATION	01-034	02
HARNESS ASSY	01-040	01
HARNESS ASSY	01-040	02
HARNESS ASSY	01-040	03
HEATER INSTALLATION	05-028	
HYD LINES, ARM	03-007	
HYD LINES, ARM (LONG)	05-042	
HYD LINES, BOOM	03-002	
HYD LINES, BOOM (BREAKER)	05-039	
HYD LINES, LOW	02-009	
HYD LINES, PUMP (SUCTION DELIVERY)	01-017	
HYD LINES, RETURN	01-019	
HYD LINES, RETURN (BREAKER)	05-008	
HYD LINES, RETURN (NIBBLER & BREAKER)	05-007	
HYD LINES, UPPER (BREAKER)	05-006	01
HYD LINES, UPPER (BREAKER)	05-006	02
HYD LINES, UPPER (MAIN)	01-018	01
HYD LINES, UPPER (MAIN)	01-018	02
HYD LINES, UPPER (NIBBLER & BREAKER)	05-005	02
HYD LINES, UPPER (NIBBLER&BREAKER)	05-005	01
IDLER ADJUST ASSY	02-005	
IDLER ASSY	02-004	
IDLER ASSY, CRAWLER	02-003	
JOINT ASSY, SWIVEL	07-051	
LEVER ASSY, PROPEL	01-024	

Order the manual at mid-west-tech.com >

LIGHT ASSY	03-005	
LIGHT INSTAL	05-017	
LIGHT INSTAL	03-004	
LIGHT WORKING	05-018	
LOW GROUP	02-001	
LUB. OIL SYSTEM	08-009	
MOTOR ASSY (SLEW) PV15V00010F1	07-022	
MOTOR ASSY, PROPELLING (MOTOR ASSY, HYD) PV15V01004F1	07-028	
MOTOR ASSY, PROPELLING (REDUCTION ASSY) PV15V00014F1	07-027	
MOTOR ASSY, SLEWING (MOTOR ASSY, HYD)	07-023	
MOTOR ASSY, SLEWING (REDUCTION ASSY) PV15V01003F1	07-026	
MOTOR INSTAL, SLEWING	01-015	
MUFFLER ASSY	01-010	
NAME PLATE INSTAL (CAB)	06-003	01
NAME PLATE INSTAL (CAB)	06-003	02
NAME PLATE INSTAL (CAB)	06-003	03
NAME PLATE INSTAL (CAB)	06-005	01
NAME PLATE INSTAL (CAB)	06-005	02
NAME PLATE INSTAL (CAB)	06-005	03
NAME PLATE INSTAL (CAB)	06-004	
NAME PLATE INSTAL (CANOPY)	06-001	01
NAME PLATE INSTAL (CANOPY)	06-001	02
NAME PLATE INSTAL (CANOPY)	06-001	03
NAME PLATE INSTAL (R.O.P.S. CANOPY)	06-002	01
NAME PLATE INSTAL (R.O.P.S. CANOPY)	06-002	02
NAME PLATE INSTALL (R.O.P.S. CANOPY)	06-002	03
NUT	00-003	
PAINT COLOR	00-004	
PANEL ASSY	05-030	
PANEL ASSY INSTRUMENT	01-036	01
PANEL ASSY, INSTRUMENT	01-036	02
PANEL ASSY, INSTRUMENT	01-036	03
PANEL ASSY, INSTRUMENT	01-036	04
PANEL ASSY, INSTRUMENT	05-034	03
PANEL ASSY, INSTRUMENT	05-034	04
PANEL ASSY, INSTRUMENT (DECELERATION)	05-034	01
PANEL ASSY, INSTRUMENT (DECELERATION)	05-034	02
PANEL ASSY, L/H	01-038	
PANEL ASSY, R/H	01-037	
PANEL ASSY, R/H	05-036	
PLATE ASSY, FLOOR (CAB)	05-010	
PLATE ASSY, FLOOR (CAB) (NIBBLER AND BREAKER)	05-011	
PLATE ASSY, FLOOR (CANOPY)	01-028	
PLATE ASSY, FLOOR (CANOPY) (NIBBLER AND BREAKER)	05-009	
PLATE ASSY, FLOOR (CANOPY) PW03M00006F1	01-027	
PLUG ASSY PH50T00001F1	07-019	
POWER TAKE-OFF ASSY	01-014	
PUMP ASSY	07-030	02
PUMP ASSY (COOLER MODE)	07-031	02
PUMP ASSY (COOLER MODE) PV10V00004F1	07-031	01
PUMP ASSY PV10V00003F1	07-030	01
PUMP ASSY, GEAR PV10V01001F1	07-032	
PUMP ASSY, GEAR PV10V01002F1	07-033	
R.O.P.S. CANOPY (USA ONLY)	01-032	
RADIATOR ASSY	01-008	
RADIATOR INSTAL	01-007	
RADIO INSTAL (CAB)	05-019	
RING ASSY, SLEWING	02-002	

Order the manual at mid-west-tech.com >

BRACKET ASSY, SWING

REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTION
		NSS		AR	NOT SERVICED SEPARATELY, BRACKET ASSY, SWING
		{PV02B00060F1}		AR	BRACKET ASSY, SWING (For CANOPY)
		{PV02B00060F2}		AR	BRACKET ASSY, SWING (For CAB)
A1		PV02B00038P2		1	BRACKET, BRACKET SWING, Remarks: (F1 ONLY)
A2		{PW02B01202P1}	BTW PV12001 & 12293	1	COVER, REMARKS: (F1 ONLY)
		{PW02B01234P1}	ASN PV12294	1	COVER, REMARKS: (F1 ONLY)
A3		PW02B01159P1	BTW PV12001 & 12293	1	RUBBER SLEEVE, REMARKS: (F1 ONLY)
		{PW02B01236P1}	ASN PV12294	1	RUBBER, REMARKS: (F1 ONLY)
A4		ZS18C10055		2	SCREW, M10x1.50x55mm, (F2 Only)
A5		PW02B01139P2		1	PLATE, REMARKS: (F2 ONLY)
A6		ZS18C10070	BTW PV12001 & 12293	2	SCREW, M10x1.50x70mm, (F1 Only)
		ZS18C10075	ASN PV12294	2	SCREW, M10x1.50x75mm, (F1 Only)
A7		ZW16X10000		2	WASHER, ID 10 x OD 21 x Th 2.0mm, (F2 Only)
A8		ZW26X10000		2	LOCK WASHER, ID 10 x OD 18 x Th 2.5mm
A9		{PW02B01208P1}		1	RUBBER, REMARKS: (F1 ONLY)
A10		PR03H01028P1	BTW PV12001 & 12165	1	GROMMET, REMARKS: (F1 ONLY)
		PW02B01209P1	ASN PV12166	1	GROMMET, REMARKS: (F1 ONLY)
A11		PY01P01043D6		2	CLIP, Wire Ties -- 368mm Long, (F1 Only)
A12		ZN18C10008		2	NUT, M10x1.50mm, (F2 Only)
A13		ZW16H10000		2	WASHER, ID 11 x OD 24 x Th 3.2mm, (F1 Only)
A14		PW02B01203P1	BTW PV12001 & 12293	1	RUBBER, REMARKS: (F1 ONLY)
		PW02B01235P1	ASN PV12294	1	RUBBER, REMARKS: (F1 ONLY)
		{PV02B00061F1}		AR	BRACKET INSTAL, SWING
B1		PV02B01203P1		1	PIN
B2		PV02B01204P1		1	PIN
B3		HS18C10130G1		2	SCREW, M10x1.50x130mm
B4		ZN18C10008		4	NUT, M10x1.50mm
B5		PX02B01038P1		1	WASHER
B6		PW02B01045D1		1	SHIM, (t=0.2)

MidWestTech | Kobelco SK25SR Compact Excavator Parts Catalog | Publication 84404961 Order the manual at mid-west-tech.com >

GUARD INSTALLATION

REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTION
8-16		ZW16X05000		4	WASHER, (M5)
8-17		ZW26X05000		4	WASHER, Lock -- ID 05 x OD 09 x Th 1.3mm
8-18		PH22C01023P1		4	BOLT, M05x0.8x20mm Long
8-19		PW21C01121P1		1	PLATE
8-20		PH21C01150P1	BTW PV10001 & 11014	1	SEAL SHEET, SEAT
		PH21C01150P2	ASN PV11015	1	SEAL SHEET, SEAT
9		PW21C01077P1		1	PLATE
10		PW21C01078P1		1	PLATE
11		PW21C01079P1		1	PLATE
12		PW21C01102P1		1	ROD
18		PW21C01038F1		1	COVER, COVER ASSY
18-1		PW21C01034P1	BTW PV10001 & 10150	1	COVER
		PW21C01034P2	ASN PV10151	1	COVER
18-2		PW21C01128P1		1	HINGE
18-4		PW21C01086P1		2	STRIKER PLATE
18-5		PV21C01090P1		1	PLATE
18-6		PW21C01043P1	BTW PV10001 & 10858	1	FOAM INSULATION
		PW21C01043P2	ASN PV10859	1	INSULATION, INSULATION
18-7		PW21C01097P1		1	FOAM INSULATION
18-9		PW21C01099P1		1	FOAM INSULATION
18-10		PW21C01116D6		1	WEATHERSTRIP
18-11		PW21C01116D7		1	WEATHERSTRIP
18-12		PW21C01116D8		1	WEATHERSTRIP
18-13		PW21C01116D9		1	WEATHERSTRIP
18-14		ZM22C08016		8	BOLT, M08x1.25x16mm (Incls. Washer & Lockwasher)
18-15		ZS41C04008		2	SCREW, M04x0.7x08mm
18-16		PW21C01114P1	BTW PV10001 & 10310	1	GROMMET, TRIM
		PN02C01001DA	ASN PV10311	1	SOFT TRIM
18-17		PW21C01036D3	BTW PV10001 & 10282	1	WEATHERSTRIP

MidWestTech | Kobelco SK25SR Compact Excavator Parts Catalog | Publication 84404961 Order the manual at mid-west-tech.com >

PUMP ASSY PV10V00003F1

REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTION
		PV10V00003R400		1	REPAIR KIT, (COVER ASSY) CONSISTS OF ITEM 25X1, 56X1 27X2 28X1, 29X5,
		PV10V00003R500		1	REPAIR KIT, (SPRING ASSY) CONSISTS OF ITEM 36~42X1, 43X2, 44X1 45~48X2
		PV10V00003R600		1	REPAIR KIT, (PISTON ASSY) CONSISTS OF ITEM 49X1, 50X1, 51X2 52X1, 53X2, 54X1

MidWestTech | Kobelco SK25SR Compact Excavator Parts Catalog | Publication 84404961 Order the manual at mid-west-tech.com >