CX300C Hydraulic Excavator Tier IV

Parts Catalog

Print No. 84426050
Issued 9/2012

CASE CONSTRUCTION

MidWestTech | Case CX300C Tier IV Hydraulic Excavator Parts Catalog | Publication 84426050

Order the manual at mid-west-tech.com >

ALPHABETICAL INDEX

	FIGURE	SEQ.
3-WAY VALVE	08-252-00	01
AIR FILTRATION	02-002-00	01
BACK VIEW MIRRORS	09-038-00	01
BACK VIEW MIRRORS	09-037-00	01
BATTERIES	04-008-00	01
BELT AND VENTILATOR - FAN GUARD	02-033-01	01
BLOCK HEATER	02-012-01	02
BOOM CYLINDER - LEFT - WITH SAFETY VALVE	08-301-01	01
BOOM CYLINDER - LEFT - WITHOUT SAFETY VALVE	08-301-00	01
BOOM CYLINDER - RIGHT - WITH SAFETY VALVE	08-300-01	01
BOOM CYLINDER - RIGHT - WITHOUT SAFETY VALVE	08-300-00	01
BRACKET	04-815-01	01
BRACKET - FAN GUARD	02-110-01	01
BREATHER	02-028-01	01
BUCKET CONTROL	09-300-00	01
CAB - CAB DOOR	09-032-00	01
CAB - ELECTRICAL CIRCUIT	04-011-00	01
CAB - ELECTRICAL CIRCUIT	04-012-00	01
CAB - GLASS - INSTRUMENT PANEL	09-029-00	01
CAB - GLASS - INSTRUMENT PANEL	09-029-01	01
CAB - RADIO PRE-EQUIPMENT	09-036-00	01
CAB - REAR WINDOW - HANDLE - WINDSHIELD WASHER	09-031-00	01
CAB - VISOR	09-034-00	01
CAB - WINDSHIELD - OPENING ROOF - SUN VISOR	09-030-00	01
CAB - WINDSHIELD WASHER	09-033-00	01
CAB AIR CONDITIONING - CAB	09-026-00	01
CAB AIR CONDITIONING - CAB	09-026-01	01
CAB AIR CONDITIONING - FRAME	09-025-00	01
CAB GUARD	09-043-00	01
CAB GUARD - WINDSHIELD, LOWER	09-040-00	01
CAB GUARD - WINDSHIELD, UPPER	09-041-00	01
CAB GUARD - WINDSHIELD, UPPER AND LOWER	09-042-00	01
CAMSHAFT - VALVE MECHANISM	02-014-01	01
CHASSIS ELECTRICAL CIRCUIT	04-001-00	01
CHASSIS ELECTRICAL CIRCUIT	04-001-01	01
CHASSIS ELECTRICAL CIRCUIT	04-001-02	01
CHASSIS ELECTRICAL CIRCUIT	04-001-03	01
CHECK VALVE	08-256-00	01
COMPONENT INDEX	00-001-00	01
CONTROL VALVE	08-200-00	01
CONTROL VALVE - OPTIONAL	08-201-00	01
COUNTERWEIGHT - SOUNDPROOFING	09-004-00	01
COVER	09-036-01	01
COVER - CYLINDER HEAD	02-010-01	01
COWLING	09-005-00	01
COWLING	09-007-00	01
COWLING - ACCESS DOOR	09-006-00	01
COWLING - FRONT RIGHT HAND-SIDE CABINET	09-008-00	01
CYLINDER ASSY, BUCKET	08-303-00	01
CYLINDER BLOCK	02-012-01	01
CYLINDER HEAD	02-011-01	01
CYLINDER HEAD	02-011-02	01
DECAL - OPERATORS COMPARTMENT - AUXILIARY CONTROL	09-403-00	01
DECALS	09-400-00	01
DECALS	09-405-00	01
DECALS	09-406-00	01

Order the manual at mid-west-tech.com >

DECALS	09-404-00	01
DECALS	09-402-00	01
DIA KITS	00-002	00
DIPPER - 2.65 M	09-201-00	01
DIPPER - 2.65 M - BRACKET - OPTIONAL - 01 - HBCV	09-106-01	01
DIPPER - 2.65 M - BRACKET- OPTIONAL - 012 - HBCV	09-106-03	01
DIPPER - 2.65 M BRACKET- OPTIONAL - 02	09-107-01	01
DIPPER - 2.65 M BRACKET- OPTIONAL - 02 - HBCV	09-107-03	01
DIPPER - 3.18 M	09-200-00	01
DIPPER - 3.18 M - BRACKET - OPTIONAL - 01 - HBCV	09-103-03	01
DIPPER - 3.18 M BRACKET - OPTIONAL - 02	09-104-01	01
DIPPER - 3.18 M - BRACKET- OPTIONAL - 012 - HBCV	09-103-05	01
DIPPER - 3.18 M BRACKET- OPTIONAL - 02 - HBCV	09-104-03	01
DIPPER - 3.66 M	09-202-00	01
DIPPER - 3.66 M - BRACKET- OPTIONAL - 012	09-108-01	01
DIPPER - 3.66 M BRACKET- OPTIONAL - 012 - HBCV	09-108-03	01
DIPPER - 3.66 M BRACKET- OPTIONAL - 02	09-109-01	01
DIPPER - 3.66 M BRACKET- OPTIONAL - 02 - HBCV	09-109-03	01
DIPPER - BRACKET	09-111-00	01
DIPPER - BRACKET	09-110-00	01
DIPPER -2.65 M BRACKET- OPTIONAL - 01	09-105-01	01
DIPPER -2.65 M BRACKET- OPTIONAL - 012	09-105-03	01
DIPPER CYLINDER - WITH SAFETY VALVE	08-302-01	01
DIPPER CYLINDER - WITHOUT SAFETY VALVE	08-302-00	01
DITCH CLEANING BUCKET (1010L - 2.20M)	09-314-00	01
DITCH CLEANING BUCKET (1250L - 2.20M)	09-314-01	01
DITCH CLEANING BUCKET (1380L - 2.40M)	09-314-02	01
ELECTRICAL ACCESSORIES - ENGINE	04-060-01	01
ELECTRICAL ACCESSORIES - ENGINE	04-060-03	01
ELECTRICAL ACCESSORIES - ENGINE	04-061-01	01
ELECTRICAL ACCESSORIES - ENGINE	04-060-02	01
ELECTRICAL ACCESSORIES - ENGINE	04-810-01	01
ELECTRICAL CIRCUIT	04-022-00	01
ELECTRICAL CIRCUIT	04-023-00	01
ELECTRICAL CIRCUIT	04-013-00	01
ELECTRICAL CIRCUIT - SAFETY VALVE - BOOM	04-010-00	01
ELECTRICAL CIRCUIT - TRANSFORMER	04-004-00	01
ELECTRONIC UNIT, CONTROL	04-019-00	01
ENGINE FLYWHEEL HOUSING	04-826-01	01
ENGINE FLYWHEEL HOUSING	02-020-01	01
ENGINE MOUNTING	02-022-01	01
ENGINE MOUNTING - ENGINE - OIL CIRCUIT	02-001-00	01
ENGINE MOUNTING - ENGINE - OIL CIRCUIT	02-001-01	01
ENGINE MOUNTING - ENGINE - OIL CIRCUIT	02-001-02	01
ENGINE WATER CIRCUIT	02-031-02	01
ENGINE WATER CIRCUIT	02-032-01	01
ENGINE WATER CIRCUIT	02-032-02	01
ENGINE WATER CIRCUIT - RADIATOR	02-004-00	01
ENGINE WATER CIRCUIT - THERMOSTAT	02-031-01	01
EXHAUST	02-003-00	02
EXHAUST	02-003-00	01
EXHAUST GAS RECIRCULATION SYSTEM	02-057-01	01
EXHAUST PIPE	02-027-01	01
EXHAUST PIPE	02-150-01	01
FOOT CONTROL VALVE	08-270-00	01
FOOT CONTROL VALVE - OPTIONAL	08-271-00	01
FRONT TIMING GEAR COVER	02-020-02	01
FUEL FILLING PUMP - OPTIONAL	03-004-00	01

Order the manual at mid-west-tech.com >

FUEL FILTER	03-041-01	01
FUEL INJECTION PUMP	03-040-01	01
FUEL SYSTEM	03-001-00	01
FUEL SYSTEM	03-001-01	01
FUEL SYSTEM	03-040-02	01
FUEL SYSTEM	03-042-01	01
FUEL SYSTEM - FUEL FILTER	03-043-01	01
FUEL TANK	03-002-00	01
FUEL TANK	03-003-00	01
GENERAL PURPOSE BUCKET - HEAVY DUTY OPTIONS	09-312-00	01
GENERAL PURPOSE BUCKET - HEAVY DUTY OPTIONS	09-312-01	01
GENERAL PURPOSE BUCKET (1060L - 1.10M)	09-310-04	01
GENERAL PURPOSE BUCKET (1180L - 1.20M)	09-310-05	01
GENERAL PURPOSE BUCKET (1300L - 1.30M)	09-310-06	01
GENERAL PURPOSE BUCKET (1430L - 1.40M)	09-310-07	01
GENERAL PURPOSE BUCKET (1550L - 1.50M)	09-310-08	01
GENERAL PURPOSE BUCKET (1700L - 1.60M)	09-310-09	01
GENERAL PURPOSE BUCKET (475L - 0.60M)	09-310-00	01
GENERAL PURPOSE BUCKET (640L - 0.75M)	09-310-01	01
GENERAL PURPOSE BUCKET (810L - 0.90M)	09-310-02	01
GENERAL PURPOSE BUCKET (940L - 1.00M)	09-310-03	01
GUIDE PULLEY	05-004-00	01
GUIDE, CHAIN	05-010-00	01
GUIDE, CHAIN - TRIPLE	05-011-00	01
HAND CONTROL VALVE	08-272-00	01
HIGH PRESSURE PUMP - COUPLING - WITH AUXILIARY HYDRAULICS	08-110-00	01
HIGH PRESSURE PUMP - PUMP, PILOT CONTROL - STANDARD	08-101-00	0
HIGH PRESSURE PUMP - PUMP, PILOT CONTROL - WITH AUXILIARY HYDRAULICS	08-106-00	01
HIGH PRESSURE PUMP - REGULATOR - STANDARD	08-104-00	01
HIGH PRESSURE PUMP - REGULATOR - STANDARD	08-103-00	01
HIGH PRESSURE PUMP - REGULATOR - WITH AUXILIARY HYDRAULICS	08-108-00	01
HIGH PRESSURE PUMP - REGULATOR - WITH AUXILIARY HYDRAULICS	08-109-00	01
HIGH PRESSURE PUMP - SOLENOID VALVE - STANDARD	08-107-00	01
HIGH PRESSURE PUMP - SOLENOID VALVE - STANDARD	08-102-00	01
HIGH PRESSURE PUMP - STANDARD	08-100-00	01
HIGH PRESSURE PUMP - WITH AUXILIARY HYDRAULICS	08-105-00	01
HORN	04-005-00	01
HYDRAULIC CIRCUIT - ATTACHMENT CONTROL VALVE PILOT	08-033-00	01
HYDRAULIC CIRCUIT - BOOM CYLINDER	08-017-00	01
HYDRAULIC CIRCUIT - BOOM CYLINDER	08-012-00	01
HYDRAULIC CIRCUIT - BOOM CYLINDER - WITH SAFETY VALVE	08-016-00	01
HYDRAULIC CIRCUIT - BOOM CYLINDER - WITH SAFETY VALVE	08-014-00	01
HYDRAULIC CIRCUIT - BOOM CYLINDER - WITH SAFETY VALVE	08-015-00	01
HYDRAULIC CIRCUIT - BOOM CYLINDER - WITHOUT SAFETY VALVE	08-013-00	01
HYDRAULIC CIRCUIT - BUCKET CYLINDER - DIPPER 2.65 M	08-020-00	01
HYDRAULIC CIRCUIT - BUCKET CYLINDER - DIPPER 3.18 M	08-021-00	01
HYDRAULIC CIRCUIT - BUCKET CYLINDER - DIPPER 3.66 M	08-022-00	01
HYDRAULIC CIRCUIT - CONTROL VALVE SUPPLY	08-004-00	01
HYDRAULIC CIRCUIT - COOLER	08-006-00	01
HYDRAULIC CIRCUIT - DIPPER CYLINDER - MONOBLOCK BOOM - 6.15 M	08-018-00	01
HYDRAULIC CIRCUIT - DIPPER CYLINDER - WITH SAFETY VALVE	08-019-00	01
HYDRAULIC CIRCUIT - HAND CONTROL PILOT - WITHOUT SAFETY VALVE	08-035-00	01

Order the manual at mid-west-tech.com >