
OPERATOR'S MANUAL

Boomer 40
Boomer 50
Compact Tractor



Part number 84471929
2nd edition English
April 2011
Replaces part number 84275459

NEW HOLLAND AGRICULTURE

MidWestTech | New Holland Boomer 40, 50 Compact Tractor Operator's Manual | Publication 84471929
Order the manual at mid-west-tech.com >

(7)
Position Control Lever

- English **MT40008842**

Location: On the right-hand side control pod, next to the drivers seat and right-hand fender.



(8)
MAINTENANCE OF AIR CLEANER
1. Stop the engine when performing air cleaner maintenance.
2. Do not operate the tractor without air cleaner installed.
3. Clean and inspect air cleaner regularly
Failure to comply could result in machine damage.

- English **MT40195653**

Location: On top of the air cleaner.



(9)
JOYSTICK LEVER USAGE
WARNING
To Avoid Personal Injury
Wrong operation causes serious injury easily.
Push the lever **(1)** in to lock the joystick in neutral.
Failure to comply could result in machine damage.

- English **MT40226388**

Location: On the right-hand fender.



(10)
4WD Control Lever

- English **MT40008742**

Location: Below the left-hand side control pod, next to the 4WD control lever.



MidWestTech | New Holland Boomer 40, 50 Compact Tractor Operator's Manual | Publicati... Order the manual at mid-west-tech.com >