1121F
Wheel Loader
Tier 4

Parts Catalog

Print No. 84590391
Issued 11/2016

CASE
CONSTRUCTION

MidWestTech | Case 1121F Tier 4 Wheel Loader Parts Catalog | Publication 84590391

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

05.100.02		INITIAL STOCKING LIST. LIST A
05.100.03	01	FILTERS
05.100.03	02	CAPACITIES
10.000.01	01	PICTORIAL INDEX - ENGINE
10.000.01	02	PICTORIAL INDEX - ENGINE
10.001.01		ENGINE ASSY
10.001.01	01	ENGINE MOUNTING
10.001.01	02	ENGINE MOUNTING, CRANK CASE VENT
10.001.02		CYLINDER BLOCK & RELATED PARTS
10.001.05		BLOCK HEATER, 120V
10.001.06		BLOCK HEATER, 240V EU MODELS
10.012.01		ENGINE WALL
10.012.04		HOOKS - ENGINE
10.101.01		CYLINDER HEAD & RELATED PARTS
10.101.02		HEAD COVER
10.101.03		ENGINE BREATHERS
10.102.01		OIL SUMP & RELATED PARTS
10.102.03		FLYWHEEL CASE
10.103.01		CRANKSHAFT & RELATED PARTS
10.103.02		FLYWHEEL
10.105.01		PISTON - ENGINE
10.105.02		CONNECTING ROD ENGINE
10.106.01		CAMSHAFT
10.106.02		SHAFT & ROCKER ARMS
10.106.05		POWER TAKE OFF
10.110.01		DAMPER
10.114.01		PULLEY - CRANKSHAFT
10.202.01	01	AIR CLEANER INSTALLATION
10.202.01	02	AIR CLEANER INSTALLATION
10.202.02		AIR CLEANER HARDWARE
10.202.03		SYKLONE AIR PRECLEANER AND ADAPTER
10.206.01		FUEL FILTER & RELATED PARTS
10.206.01	02	FUEL PRE-FILTER
10.206.02	01	FILTER ENGINE OIL
10.206.02	02	OIL PRESSURE REGULATION VALVE
10.214.01		FUEL LINE

Order the manual at mid-west-tech.com >

10.214.02		FUEL FILTER AND CONNECTIONS WITHOUT HEAT
10.214.03		FUEL FILTER WITH HEAT
10.216.01	01	FUEL TANK CONNECTIONS
10.216.01	02	FUEL TANK FILLER CONNECTIONS
10.216.01	03	FUEL TANK
10.218.01	01	INJECTION EQUIPMENT - PIPING
10.218.01	02	FUEL LINES & RELATED PARTS
10.218.02		INJECTION EQUIPMENT - INJECTOR
10.218.AQ	02	FUEL INJECTION PUMP, COMPONENTS
10.247.01		INJECTION PUMP
10.247.01	01	INJECTION PUMP
10.250.01		TURBOCHARGER & RELATED PARTS (5801399733)
10.250.02		TURBOCHARGER PIPES
10.254.01		MUFFLER
10.254.04		INTAKE MANIFOLD
10.254.05		EXHAUST MANIFOLD
10.304.01	01	PUMP, ENGINE OIL & RELATED PARTS
10.304.01	03	AUXILIARY OIL PUMP & RELATED PARTS
10.304.02	01	OIL LEVEL CHECK
10.304.02	02	OIL DIPSTICK
10.304.05		OIL PUMP PIPING
10.400.01		ENGINE COOLING PLUMBING
10.400.01		PIPING - ENGINE COOLING SYSTEM
10.400.02		ENGINE COOLING HARDWARE
10.400.03		SURGE TANK
10.402.01		TEMPERATURE CONTROL (THERMOSTAT) -
10.402.01	02	BLEEDER TUBING - ENGINE COOLING SYSTEM
10.402.02		WATER PUMP & RELATED PARTS
10.402.03		WATER PUMP PIPES
10.408.01		HEAT EXCHANGER
10.414.02	01	STANDARD FAN RELIEF VALVE
10.414.02	02	STANDARD FAN RELIEF VALVE
10.500.01		DEF LINE INSTALLATION
10.500.02		DEF LINE INSTALLATION
10.500.03		DEF TANK ASSEMBLY
10.500.04		DEF TANK COVER, INTERNATIONAL REGION ONLY

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

21.102.00		TRANSMISSION FILTERS
21.102.01		4 SPEED TRANSMISSION FILTER LINES INSTALL
21.116.01		TRANSMISSION MOUNTNG, 4 SPEED
21.116.01	01	SIGHTGLASS INSTALLATION
21.116.02		TRANSMISSION COOLER LINES 4 SPEED WITH BYPASS
21.116.04		TRANSMISSION CONVERTER AND BELL HOUSING GROUP
21.116.05		TRANSMISSION HOUSING
21.116.06		COUNTERSHAFT
21.116.07		TRANSMISSION - CLUTCH ASSY, FIRST
21.116.08		TRANSMISSION - CLUTCH ASSY, SECOND
21.116.09		TRANSMISSION - CLUTCH ASSY, THIRD AND FORTH
21.116.10		TRANSMISSION - CLUTCH ASSY, REVERSE
21.116.11		OUTPUT SHAFT ASSEMBLY
21.116.12		TRANSMISSION OIL PUMP
21.116.12	01	TRANSMISSION OIL PIPING
21.116.13		EMERGENCY STEERING PUMP
21.130.01		TRANSMISSION CONTROLLER INSTALLATION
21.130.02		HYD PUMP WITH VALVE
21.130.02	01	TRANSMISSION SENSORS
21.130.03		HYD INSTALL PUMP WITH VALVE
21.130.04		HYD PUMP WITH VALVE INSTALLATION
21.135.01		RETURN LINE INSTALL
21.315.01		DRIVE SHAFT INSTALLATION, 4 SPEED
21.315.01	01	FRONT DRIVE SHAFT ASSEMBLY, 4 SPEED
21.315.01	02	REAR DRIVE SHAFT ASSEMBLY, 4 SPEED
21.315.01	03	CENTER DRIVE SHAFT ASSEMBLY, 4 SPEED
21.400.00		GEARSHIFT VALVE SYSTEM
21.400.01		TRANSMISSION CONTROL VALVE
25.102.01		DIFFERENTIAL, FRONT AND REAR, OPEN AND LOCK AXLE
31.120.00		PTO 1 SHAFT ASSEMBLY
31.120.00	01	PTO 2 SHAFT ASSEMBLY
33.110.00		PARKING BRAKE
33.120.01		BRAKE PEDAL - RIGHT HAND
33.202.02	01	HYDRAULICS - MAIN BRAKE - PUMP
33.202.02	02	HYDRAULICS - MAIN BRAKE - ACCUMULATOR
33.202.02	03	HYDRAULICS - MAIN BRAKE - VALVE

Order the manual at mid-west-tech.com >