1021F Wheel Loader
Tier IV

Parts Catalog

Print No. 84590392
Issued 1/2012

CASE CONSTRUCTION

MidWestTech | Case 1021F Tier IV Wheel Loader Parts Catalog | Publication 84590392

Order the manual at mid-west-tech.com >

ALPHABETICAL INDEX

	FIGURE	SEQ.
4 SPEED TRANSMISSION FILTER	21.102.01	
AIR CLEANER HARDWARE	10.202.02	
AIR CLEANER INSTALLATION	10.202.01	01
AIR CLEANER INSTALLATION	10.202.01	02
AIR CONDITIONING	50.200.02	
AIR CONDITIONING - CONTROL	50.200.04	
AIR CONDITIONING INSTALLATION	50.200.03	
AIR CONDITIONING LINE INSTALLATION	50.200.05	
ALTERNATOR	55.301.04	
ALTERNATOR INSTALLATION WITH AIR CONDITIONING	55.301.03	
ARM ASSEMBLY MONITOR MOUNTING	90.150.03	
ARTICULATION JOINT INSTALLATION	39.127.01	
AUXILARY STEERING MANIFOLD	41.200.02	03
AUXILIARY OIL PUMP & RELATED PARTS	10.304.01	03
AUXILIARY STEERING ACCUMULATOR AND HARDWARE	41.200.02	02
AUXILIARY STEERING HYDRAULIC LINES AND FITTINGS	41.200.02	01
AXLE COOLER	44.100.03	04
AXLE COOLER	44.100.03	03
AXLE COOLER	44.100.03	02
AXLE COOLER LINE INSTALLATION, HD, LOCK AXLES	44.100.03	05
AXLE COOLER LINE INSTALLATION, STANDARD, OPEN DIFFERENTIAL	44.100.03	01
AXLE MOUNTING, FRONT AND REAR	44.100.01	01
AXLE MOUNTING, FRONT AND REAR	44.100.01	02
BAR MOUNT INSTALLATION	90.150.02	
BATTERY CABLES	55.301.02	
BATTERY CASE COVER INSTALLATION	39.126.02	
BATTERY INSTALLATION	55.301.01	
BLEEDER TUBING - ENGINE COOLING SYSTEM	10.402.01	02
BLOCK HEATER, 120V	10.001.05	
BLOCK HEATER, 240V EU MODELS	10.001.06	
BRAKE ACCUMULATOR HD	33.202.05	02
BRAKE ACCUMULATOR HD	33.202.05	01
BRAKE ACCUMULATOR STANDARD	33.202.04	
BRAKE PEDAL - RIGHT HAND	33.120.01	
BRAKE VALVE	33.202.03	01
BRAKE VALVE INSTALLATION	33.202.03	
BRAKES, HUB DISC, FRONT AND REAR AXLE	33.204.01	
BUCKET MOUNTING	82.100.01	
BYPASS AXLE COOLER	44.100.04	
CAB - CONVENIENCE PACKAGE	90.115.01	
CAB - DOOR MOUNTING	90.154.03	
CAB - FRONT GLASS	90.156.02	
CAB - WINDOW, RIGHT-HAND-LOWER	90.154.02	
CAB - WINDOW, RIGHT-HAND-UPPER	90.154.01	02
CAB - WINDOW, RIGHT-HAND-UPPER - MOUNTING	90.154.01	01
CAB - COMPONENTS	90.160.02	
CAB - DOOR ASSEMBLY	90.154.04	
CAB - EXTERIOR TRIM	90.160.05	
CAB - HEATER AND AIR CONDITIONING DUCTS	50.206.01	01
CAB - HEATER AND AIR CONDITIONING DUCTS	50.206.01	02
CAB - INTERIOR TRIM - COLUMNS - HVT ONLY	90.160.04	02
CAB - INTERIOR TRIM - COLUMNS - TC ONLY	90.160.03	02
CAB - INTERIOR TRIM - CONSOLES - TC ONLY	90.160.03	01
CAB - INTERIOR TRIM - ROOF - HVT ONLY	90.160.04	03
CAB - INTERIOR TRIM - ROOF - TC ONLY	90.160.03	03
CAB - INTERIOR TRIM - STORAGE COMPARTMENTS	90.160.07	

Order the manual at mid-west-tech.com >

CAB - STEERING COLUMN - COVERS, SWITCHES	41.101.01	03
CAB - WIPER, FRONT	55.518.02	
CAB - WIPER, REAR	55.518.03	
CAB AND CANOPY SKIRT	90.600.01	
CAB COMPONENTS	90.150.06	
CAB INTERIOR - MISC	90.150.05	
CAB- INTERIOR TRIM - CONSOLES - HVT ONLY	90.160.04	01
CAB ROOF HARNESS	55.100.11	01
CAB ROOF HARNESS INSTALLATION	55.100.11	
CAB STEERING COLUMN	41.101.01	04
CAB STEERING COLUMN, ACCESSORY	41.101.01	02
CAB STEERING WHEEL	41.101.01	01
CAB WORK LIGHTS	55.404.07	
CAB/CANOPY - MOUNTING	90.150.01	
CAB/CANOPY - REAR GLASS	90.156.01	
CAMSHAFT	10.106.01	
CENTER DRIVE SHAFT ASSEMBLY, 4 SPEED	21.315.01	01
COMPRESSOR, AIR CONDITIONING	50.200.01	
CONNECTING ROD ENGINE	10.105.02	
CONSOLE ACCESS PLATE	90.160.01	
CONTROL INSTALLATION - HGT AND RTT, HVT Z-BAR/XR	55.746.01	01
CONTROL INSTALLATION - HGT AND RTT, TORQUE CONV Z-BAR	55.746.03	
CONTROL INSTALLATION - RTD, HGT, AND RTT, TORQUE CONV XR/LR	55.746.02	
COOLER - TRANSMISSION, HYDRAULIC, FUEL	35.752.01	
COOLING FAN RELIEF VALVE INSTALLATION	35.526.01	02
COOLING FAN RELIEF VALVE INSTALLATION	35.526.01	01
COOLING FAN RELIEF VALVE INSTALLATION-WITH REVERSING	35.526.01	04
COOLING FAN RELIEF VALVE INSTALLATION-WITH REVERSING	35.526.01	05
COOLING FRAME SEALING	39.126.05	
COOLING SYSTEM FRAME	39.126.04	
COOLING SYSTEM FRAME WITH FAN	39.126.03	
COUNTERWEIGHT, HEAVY DUTY INSTALLATION	37.140.02	
COUNTERWEIGHT, STANDARD	37.140.01	
COVER, WASHER BOTTLE INSTALLATION	90.150.07	01
COVERS, SIDE AND REMOTE DRAIN	90.160.08	
CRANKSHAFT & RELATED PARTS	10.103.01	
CYLINDER BLOCK & RELATED PARTS	10.001.02	
CYLINDER HEAD & RELATED PARTS	10.101.01	
DAI KIT, JUMP POST	88.055.04	
DAMPER	10.110.01	
DECALS - COMMON LANGUAGE, EUROPE	90.108.09	
DECALS - COMMON TO MODEL	90.108.01	
DECALS - CUSTOMER ASSISTANCE	90.108.06	
DECALS - ENGLISH	90.108.02	
DECALS - FRENCH CANADIAN	90.108.03	
DECALS - INTERNATIONAL	90.108.05	
DECALS - ROCKER SWITCH, EUROPE	90.108.08	
DECALS - SAFETY, ENGLISH, EUROPE	90.108.07	
DECALS - SPANISH	90.108.04	
DEF LINE INSTALLATION	10.500.02	
DEF LINE INSTALLATION	10.500.01	
DEF TANK ASSEMBLY	10.500.03	
DEF TANK COVER, INTERNATIONAL REGION ONLY	10.500.04	
DIA KIT, 24V TO 12V POWER CONVERTER	88.055.02	
DIA KIT, 3 PIECE RIM	88.088.02	
DIA KIT, ACCESSORY MOUNTING POLE	88.088.01	
DIA KIT, COLD WEATHER PACKAGE	88.055.03	

Order the manual at mid-west-tech.com >

DIA KIT, HYDRAULIC CONVERSION, 2 FUNCTION 2 LEVER TO 3 FUNTION 3 LEVER	88.035.04	
DIA KIT, HYDRAULIC CONVERSION, 2 OR 3 FUNCTION JOYSTICK AND 1 LEVER TO 4 FUNCTION JOYSTICK AND 2 LEVER	88.035.03	
DIA KIT, HYDRAULIC CONVERSION, 3 FUNCTION 3 LEVER TO 3 FUNCTION JOYSTICK 1 LEVER	88.035.02	
DIA KIT, REARVIEW CAMERA	88.055.01	
DIA KIT, RIDE CONTROL	88.035.01	
DIA KIT, RIGHT HAND BRAKE PEDAL	88.033.01	
DIA KIT, VARIABLE SPEED REVERSIBLE COOLING FAN	88.010.01	
DIFFERENTIAL LOCK LINE	44.100.02	
DIFFERENTIAL, FRONT AND REAR, LOCK AXLE	44.106.02	01
DIFFERENTIAL, FRONT AND REAR, OPEN AXLE	44.106.02	
DRIVE SHAFT INSTALLATION, 4 SPEED	21.315.01	
DRIVE SHAFT, LOCK AXLES	44.100.05	01
DRIVE SHAFT, OPEN DIFFERENTIAL	44.100.05	
ELECTRONIC INJECTION	55.440.01	
ENGINE ASSY	10.001.01	
ENGINE BREATHERS	10.101.03	
ENGINE COOLING HARDWARE	10.400.02	
ENGINE COOLING PLUMBING	10.400.04	
ENGINE HARNESS REAR CHASSIS	55.100.03	02
ENGINE HARNESS REAR CHASSIS	55.100.03	01
ENGINE MOUNTING	10.001.01	01
ENGINE MOUNTING, CRANK CASE VENT	10.001.01	02
ENGINE WALL	10.012.01	
ENGINE WALL INSTALL	39.125.02	
EXHAUST MANIFOLD	10.254.05	
FAN RELIEF VALVE	35.526.01	03
FAN RELIEF VALVE WITH REVERSER	35.526.01	06
FILTER ENGINE OIL	10.206.02	01
FILTERS AND CAPACITIES 1021F	00.100.01	
FIRE EXTINGUISHER	88.130.01	
FLYWHEEL	10.103.02	
FLYWHEEL CASE	10.102.03	
FRONT AXLE DIFFERENTIAL CARRIER, LOCK AXLES	44.106.04	01
FRONT AXLE HOUSING, LOCK AXLE	44.101.02	
FRONT AXLE HOUSING, OPEN AXLE	44.101.01	
FRONT AXLE, DIFFERENTIAL CARRIER, OPEN AXLE	44.106.04	
FRONT CHASSIS HARNESS	55.100.04	01
FRONT CHASSIS HARNESS INSTALLATION-TC ONLY	55.100.04	
FRONT CHASSIS INSTALLATION	39.125.01	
FRONT FENDER STANDARD	90.116.01	
FRONT LIGHT ASSEMBLY RH AND LH	55.404.01	02
FRONT LIGHT INSTALLATION	55.404.01	
FUEL FILTER & RELATED PARTS	10.206.01	
FUEL FILTER AND CONNECTIONS WITHOUT HEAT	10.214.02	
FUEL FILTER WITH HEAT	10.214.03	
FUEL LINE	10.214.01	
FUEL LINES & RELATED PARTS	10.218.01	02
FUEL PRE-FILTER	10.206.01	02
FUEL TANK	10.216.01	03
FUEL TANK CONNECTIONS	10.216.01	01
FUEL TANK FILLER CONNECTIONS	10.216.01	02
FULL WHEEL WELL PANEL, INSTALLATION	90.105.03	
GREASE LINE ROUTING	39.105.03	
GRID HEATER	55.414.02	
HARNESS INSTALLATION, CAB BOTTOM	55.100.21	

Order the manual at mid-west-tech.com >

CONTROL INSTALLATION - RTD, HGT, AND RTT, TORQUE CONV XR/LR

REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTION
1		84357743		1	BRACKET, SUPPORTING
2		84357753		1	BRACKET, SUPPORTING
3		84357747		1	BLOCK
4		84355879		1	PROTECTIVE COVER
5		L125983		1	SUPPORT
6		1546497C1		1	SWITCH
7		87363671		1	SUPPORT
8		87694569		1	PLATE
9		87437102		2	BLOCK
10		84307369		1	PROTECTIVE COVER
11		84307069		2	SPACER
12		87534446		1	BRACKET
13		1546498C1		1	SWITCH
14		892-11012		2	LOCK WASHER, M12
15		627-12030		2	BOLT, Hex, M12 x 30, 10.9
16		896-15020		4	WASHER, M20 x 44.5 x 5, HT
17		827-20220		2	BOLT, Hex, M20 x 220, 10.9
18		832-10420		2	LOCK NUT, M20 x 2.5, Cl 8
19		895-11010		8	WASHER, M10 x 20 x 2
20		827-10040		2	BOLT, Hex, M10 x 40, 10.9, Full Thd
21		832-10410		4	LOCK NUT, M10 x 1.5, Cl 8
22		896-11012		6	WASHER, M13.5 x 24.5 x 3, HT
23		627-12040		2	BOLT, Hex, M12 x 40, 10.9, Full Thd
24		829-1412		2	NUT, M12, Cl 10
25		627-12025		1	BOLT, Hex, M12 x 1.75 x 25, 10.9, Full Thd
26		827-12090		1	BOLT, Hex, M12 x 90, 10.9
27		627-10020		2	BOLT, Hex, M10 x 20, 10.9, Full Thd
28		811-12025		2	CARRIAGE BOLT, Short NK, M12 x 25, Cl8.8, Full Thd
29		827-10070		2	BOLT, Hex, M10 x 70, 10.9
30		84365116		2	COVER PLATE
31		895-15008		6	WASHER, M8 x 20 x 1.6
32		627-8035		6	BOLT, Hex, M8 x 35, 10.9

MidWestTech | Case 1021F Tier IV Wheel Loader Parts Catalog | Publication 84590392 Order the manual at mid-west-tech.com >

REAR FENDER LEFT SIDE WIDE

REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTION
1		87552918		1	FENDER, LH
2		86013811		2	STUD, Ball
3		404882A1		2	FASTENER, M6 Spring
4		627-8025		2	BOLT, Hex, M8 x 25, 10.9
5		895-25008		2	WASHER, M8 x 20 x 1.6
6		827-12090		2	BOLT, Hex, M12 x 90, 10.9
7		896-11012		6	WASHER, M13.5 x 24.5 x 3, HT
8		627-6025		2	BOLT, Hex, M6 x 25, 10.9
9		895-25006		2	WASHER, M6 x 18 x 1.6
10		832-10408		2	LOCK NUT, M8 x 1.25, Cl 8
11		896-15008		2	WASHER, M8 x 21.5 x 2.5, HT
12		827-12100		2	BOLT, Hex, M12 x 100, 10.9
13		627-12030		4	BOLT, Hex, M12 x 30, 10.9
14		895-25012		4	WASHER, M12 x 37 x 3
15		14499601		4	WASHER, M12 x 20 x 2.5
16		829-1412		4	NUT, M12, Cl 10
17		896-15012		2	WASHER, M12 x 28.5 x 4, HT
18		832-10410		2	LOCK NUT, M10 x 1.5, Cl 8
19		895-25010		2	WASHER, M11 x 30 x 2.5
20		84490877		1	BRACKET, Mid Fender LH
21		627-10030		2	BOLT, Hex, M10 x 30, 10.9, Full Thd
22		895-15010		2	WASHER, M11 x 24 x 2
23		84370338		1	FENDER, Mid LH

MidWestTech | Case 1021F Tier IV Wheel Loader Parts Catalog | Publication 84590392 Order the manual at mid-west-tech.com >

CAB - WINDOW, RIGHT-HAND-UPPER

REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTION
1		76303230		1	GLASS, Right Window
2		76303242		1	SEAL, Right Window
3		76303159		2	GASKET, Under Hinge
4		76094173		3	SPACER
5		4227144		3	GROMMET, M14 x 25.5 x 19.5, Rubber
6		87472962		1	HINGE, Right Window
7		76303154		1	BRACKET, Hook; Door
8		87664048		8	WASHER, 6.6x12x1.6mm CST
9		76303210		1	PLATE, Hinge
10		10902024		2	SCREW, Hex, M6 x 1 x 12.00mm, Cl 8.8, DAC
11		87664049		7	WASHER, 9x16x1.6mm CST
12		832-10408		4	LOCK NUT, M8 x 1.25, Cl 8
13		76303193		2	GASKET, Service Door Hinge
14		87472961		1	HINGE, Right Door
15		76303192		1	PLATE, Hinge
16		16043924		3	SCREW, Hex, M8 x 35, 8.8, Full Thd
17		84160715		1	BRACKET, Window Handle
18		87522593		2	GASKET, Right Window Latch
19		76303323		1	PLATE, Right Handle
20		10902624		2	SCREW, Hex, M6 x 25, 8.8, Full Thd
21		825-1406		2	NUT, M6, Cl 8
22		76043538		1	HANDLE, Window Latch
23		326361A1		1	BOLT, Hex M6x50mm
24		832-10406		1	NUT, M6 x 1, Cl 8
25		3805251		1	PIN, Guide
26		97399C1		1	HANDLE, Window
27		F64198		2	SPACER, Nylon; .196ID x .580OD
28		R54047		1	PAD, Spacer
29		13311214		2	SCREW, Cross Oval Hd, M5 x 20
30		825-1405		2	NUT, M5, Cl 8
31		895-25005		2	WASHER, M5 x 15 x 1.6
32		87522630		1	CAP COVER, M6

Order the manual at mid-west-tech.com >