586H
588H
Forklift
Tier IV

Parts Catalog

Print No. 84599856
Issued 9/2012

CASE
CONSTRUCTION

MidWestTech | Case 586H, 588H Tier IV Forklift Parts Catalog | Publication 84599856

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

00.000.00		MAIN PICTORIAL INDEX- COMPLETE UNIT
00.000.10		PICTORIAL INDEX, ENGINE ATTACHMENTS
00.000.21		PICTORIAL INDEX, TRANSMISSION
00.000.25		PICTORIAL INDEX, AXLE FRONT
00.000.27		PICTORIAL INDEX, REAR STEERING AXLE
00.000.33		PICTORIAL INDEX, BRAKES & CONTROLS
00.000.35		PICTORIAL INDEX, HYDRAULIC SYSTEMS
00.000.39		PICTORIAL INDEX, FRAME
00.000.41		PICTORIAL INDEX, STEERING
00.000.55		PICTORIAL INDEX, ELECTRICAL SYSTEMS
00.000.90		PICTORIAL INDEX, PLATFORM, CAB, BODYWORK AND DECALS
00.100.03		SERIAL NUMBER PLATE LOCATIONS / INFORMATION
00.100.04		MOVE TO BIC
05.100.01		INITIAL STOCKING LIST, LIST A
05.100.02		INITIAL STOCKING LIST, LIST B
05.100.03		FILTER AND CAPACITIES
05.100.03		FILTERS & CAPACITIES, 586H TIER 4A - RTFL
10.000.00		PICTORIAL INDEX, ENGINE ATTACHMENTS
10.000.00	01	PICTORAIL INDEX, AIR FILTER
10.001.00		ENGINE
10.001.01		ENGINE MOUNTING
10.202.01		AIR CLEANER INSTALLATION
10.202.01	01	AIR CLEANER ASSEMBLY
10.218.01		FUEL LINE INSTALLATION
10.218.01	01	FUEL TANK ASSEMBLY
10.218.01	02	FUEL FILTER, ASSY
10.408.01		AIR COOLER ASSEMBLY AND OIL COOLER ASSEMBLY
10.408.02		CHARGE AIR COOLER, HOSE INSTALLATION
10.408.03	01	OIL COOLER INSTALLATION, HARDWARE AND LINES
10.408.03	02	OIL COOLER INSTALLATION, HARDWARE AND LINES
10.414.01		ENGINE FAN INSTALLATIONS
10.501.01		MUFFLER INSTALLATION, DIESEL PARTICULANT FILTER
10.501.01	01	MUFFLER, ASSY
10.989.01		DIESEL PARTICULANT FILTER, SENSOR

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

21.000.00		PICTORIAL INDEX, TRANSMISSION
21.100.01	01	TRANSMISSION OIL PUMP, 2WD AND 4WD
21.100.02	01	TRANSMISSION OIL FILTER, 2WD AND 4WD
21.104.01	01	TRANSMISSION, OIL COOLER LINE INSTALLATION
21.111.01	00	TRANSMISSION
21.111.01	01	TRANSMISSION HOUSING, 2WD
21.111.01	02	TRANSMISSION HOUSING 4WD
21.111.02		TRANSMISSION, OIL DIPSTICK
21.111.03		TRANSMISSION, MOUNTING PARTS, STANDARD
21.133.01		TRANSMISSION, SHIFT LEVER INSTALLATION
21.133.02		TRANSMISSION SHIFTING UNIT
21.134.03		TRANSMISSION VALVE CONTROL
21.134.04		TRANSMISSION CONTROL VALVE, 4WD
21.140.01		TRANSMISSION, INPUT/PTO SHAFT ASSEMBLY, 2WD AND 4WD
21.154.01		TRANSMISSION SHAFT, PRIMARY AND REVERSE, 2WD AND 4WD
21.154.02	01	TRANSMISSION SHAFT, SECONDARY, 2WD
21.154.02	02	TRANSMISSION SHAFT, SECONDARY 4WD
21.154.03		TRANSMISSION, OUTPUT SHAFT, 4WD
21.182.01		DIFFERENTIAL LOCK INSTALLATION, 2WD AND 4WD
21.700.01		TRANSMISSION TORQUE CONVERTER
25.000.00		PICTORIAL INDEX, AXLE FRONT
25.100.01		FRONT DRIVE HOUSING
25.100.02		FRONT DRIVE HOUSING
25.102.01		FRONT DRIVE BRAKE DIFFERENTIAL
25.102.02		FRONT DRIVE DIFFERENTIAL LOCK
25.102.03		FRONT DRIVE DIFFERENTIAL
25.102.04		FRONT DRIVE RING & PINION
25.102.05		FRONT DRIVE PLANETARY
25.108.01		DRIVE AXLE, DRIVE SHAFT
27.000.00		PICTORIAL INDEX, REAR STEERING AXLE
27.100.01		STEERING AXLE INSTALLATION, 4WD
27.100.02		STEERING AXLE HOUSING, 4WD
27.100.03		STEERING AXLE, REAR DRIVE SHAFTS, 4WD
27.106.01		STEERING AXLE DIFFERENTIAL, 4WD

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

27.106.02		STEERING AXLE, RING AND PINION, 4WD
27.120.01		STEERING AXLE, WHEEL HUB AND BEARINGS, 2WD
27.120.02		STEERING AXLE, PLANETARY GEAR 4WD
27.124.01		STEERING AXLE, DRIVE SHAFT
27.450.01		STEERING AXLE, SWIVEL HOUSING, 4WD
27.550.01		STEERING AXLE INSTALLATION, 2WD
27.550.02		STEERING AXLE HOUSING, 2WD
27.550.03		STEERING AXLE HOUSING SWIVEL, 2WD
33.110.01		TRANSMISSION, PARKING BRAKE
33.120.01		BRAKE PEDAL ASSEMBLYS
33.202.01		BRAKES MASTER CYLINDER, RESERVOIR INSTALLATION
33.202.02		BRAKES, HYDRAULIC LINE INSTALLATION
33.000.00		PICTORIAL INDEX, BRAKES & CONTROLS
35.100.01		MAST ASSEMBLY 6000 LB 4.5M 15 FEET
35.100.01	01	MAST ASSEMBLY HOOK AND SHAFT FRAME
35.100.01	02	MAST ASSEMBLY 6000 LB 6.6 M 22 FEET FREE LIFT
35.100.01	02	MAST CARRIAGE ASSY, HOOK, 84 IN, 15 FT
35.100.01	03	6000 LB 6.6 M (22 FT) FREE LIFT
35.100.02	01	MAST ASSEMBLY 6000 LB FREE LIFT ONLY HYDRAULIC SYSTEM
35.100.02	02	MAST, HOOK AND SHAFT FRAME 6000 LB 22 AND 16 FEET
35.100.03		MAST, 6000 LB, 4.8 M (16 FT) FREE LIFT
35.100.03	01	6000 LB 4.8 M (16 FT) FREE LIFT
35.100.04		MAST, 6000 LB, 6.6 M (22 FT)
35.100.04	01	MAST, 6000 LB, HYDRAULIC SYSTEM
35.100.04	02	MAST ASSEMBLY 6000LB 6.6 M (22FT)
35.100.05		MAST, HOOK AND SHAFT FRAME 6000 LB 60IN 15 AND 22 FEET
35.100.06		MAST, 8000 LB 15 FEET HOOK AND SHAFT FRAME
35.100.06	01	MAST, HOOK AND SHAFT FRAME, 8000 LB
35.100.06	02	MAST, SHAFT FRAME, 8000 LB
35.100.07		MAST, 8000 LB 6.6M 22 FEET
35.100.07	01	MAST, HOOK AND SHAFT FRAME, 8000 LB
35.100.07	02	MAST, SHAFT FRAME, 8000 LB 22 FEET
35.100.07	03	MAST, 8000 LB 22 FEET
35.105.00		PUMP ASSEMBLY, 18 GPM 586H

Order the manual at mid-west-tech.com >