530/540/550/560 Manure Spreaders

Parts Catalog

8-5960

CASE IH AGRICULTURE

MidWestTech | Case 530, 540, 550, 560 Manure Spreader Parts Catalog | Publication 8-59... Order the manual at mid-west-tech.com >

SECTION INDEX

GENERAL 1

HYDRAULICS 8

CHASSIS/MTD. EQUIP. 9

NUMERICAL INDEX 10

Bur 8-5960 Issued December, 1990 Printed in U.S.A.

MidWestTech | Case 530, 540, 550, 560 Manure Spreader Parts Catalog | Publication 8-59... Order the manual at mid-west-tech.com >

GENERAL INFORMATION

Indexes

Section 1 of this catalog contains a SN and P.I.N. location guide, alphabetical index, pictorial index of the sections included, and pictorial index(es) for quick location of hoses and tubes (and other system components in some catalogs). An alphabetical index also appears at the beginning of each section. Section 10 is the Numerical Index which lists all part numbers in alpha/numeric order with their page location and reference number.

Illustration and Text

The arrangement of this parts catalog is for easy identification of parts. All parts are illustrated in "exploded views" in proper relation to each other. Reference numbers used in the illustrations refer to those on the text pages. The text pages list reference number, part number, part description and the quantity required.

Abbreviations

P.I.N. "Product Identification Number"
SN "Serial Number"
NSS "Not Serviced Separately" in the part number column indicates this part is not available for service.
REF "Reference" in the part number column indicates this part has special service information. The page where this information can be found is given in the part description column.
UAR "Use As Required" in the quantity required column indicates the number of parts used is determined by service needs.

Right-Hand and Left-Hand Identification

The reference to right-hand and left-hand in this catalog is identified by the operator standing at the rear of the basic unit (without rear attachment), looking toward the front of the machine (in normal forward travel). For pages covering any machine attachments, right-hand and left-hand are defined by the operator sitting in the position for proper operation of the attachment.

Catalog Revisions and Supplements

Changes to the product may make it necessary to revise or add pages to this catalog. A cover sheet will list all pages released in a revision or supplement. Each new or revised page will have a new issue date. All revised and new pages must be put into the parts catalog as soon as they are received.

Parts Orders

Orders must specify product model, all necessary serial numbers, correct part number, complete description, quantity required, method of shipment, and shipping address.

Text Format Explanation

An assembly may contain many service items. The component parts of an assembly or subassembly are indented. The quantity required column lists the number of assemblies required for a complete machine, and the number of components required in a complete assembly or subassembly.

The example below illustrates the use of indents and other text page elements explained on this page.

REF.	PART NO.	DESCRIPTION	REQ'D.
1	D43567	FILTER ASSEMBLY - hydraulic oil, P.I.N. 7534840 and after	1
	D61903	HEAD ASSEMBLY - filter	1
2	NSS	HEAD - filter, order D61903 head assembly	1
3	D58199	VALVE - bypass	1
	D43800	KIT - filter element, replaces D35700 kit	1
4	NSS	ELEMENT - filter, order D43800 element kit	1
5	A27994	O-RING - filter	1
6	D61948	HOUSING - filter	1
7	REF	CANOPY - ROPS, machinery item, order from Machinery Price List	1
8	843065C1	HOSE - 132 inch long, reservoir to pump	1
9	113-323	BOLT - hex, 7/16 NC x 1-3/4 inch	2
10	814-8030	BOLT - hex, 8 - 1.25 x 30 mm	4

MidWestTech | Case 530, 540, 550, 560 Manure Spreader Parts Catalog | Publication 8-59... Order the manual at mid-west-tech.com >

ALPHABETICAL INDEX

A

Apron
- Cables
  - Models 530, 540 and 550 9-103
  - Model 560 9-107
- Chains
  - Drive
    - Model 560 Only 9-63
    - Models 530, 540 and 550 9-59
  - Heavy Duty Lock Type ..... 9-85 - 9-91
  - Pintle Type ..... 9-93 - 9-97
  - Steel Detachable Type 9-81,9-83
- Controls ..... 9-99 - 9-101B,9-105,9-107
- Drive Line 9-57,9-61
- Gearbox 9-65,9-67
- Gearbox Supports 9-69
- Shaft - front 9-77,9-79
- Shaft - rear 9-77,9-79

Attachments
- Slurry Pan 9-131
- Splash Shield 9-133
- Spring Bar 9-117
- Upper Beater
  - Mounting 9-111,9-113
  - Drive 9-115

Axles and Supports 9-27,9-29

B

Box - spreader
- Bottom ..... 9-3 - 9-11
- Front ..... 9-17 - 9-21
- Left-hand side 9-13,9-15
- Right-hand side 9-13,9-15

C

Cables
- Apron
  - Models 530, 540 and 550 9-103
  - Model 560 9-107
- Widespread
  - Models 530, 540, and 550 9-103
  - Model 560 9-107

Chains
- Apron
  - Drive 9-59,9-63
  - Heavy Duty Lock Type ..... 9-85 - 9-91
  - Pintle Type ..... 9-93 - 9-97
  - Steel Detachable Type 9-81,9-83
- Main Drive
  - 1000 RPM 9-47
  - 540 RPM 9-43,9-45
- Safety - highway 9-133

Clutch

C

Clutch-Cont.
- 1000 RPM 9-49
- 540 RPM 9-43,9-45

Controls
- Apron Drive ..... 9-99 - 9-101B,9-105,9-107
- End Gate 9-121,9-127,9-129
- Slurry Pan 9-131
- Widespread ..... 9-99 - 9-101B,9-105,9-107

Control Valve 8-19
Couplings - hydraulics 8-3
Cylinders - endgate
- Assemblies ..... 8-5 - 8-17
- Mounting 8-3

D

Decals 9-137
Drive Chains - apron
- Model 530, 540, and 550 9-59
- Model 560 9-63

Drive Chains - main
- 1000 RPM 9-47
- 540 RPM 9-43,9-45

Drive Line - apron 9-57,9-61
Drive Line - widespread 9-71,9-73
Drive Shaft
- From Tractor PTO
  - 1000 RPM - Model 560 only 9-35
  - 540 RPM 9-31, 9-33
- Main Front ..... 9-37 - 9-41
- Main - side 9-51,9-55
- Side - shields and supports 9-53,9-55

E

End gate
- Controls 9-121,9-127,9-129
- Gate and Mounting 9-119,9-123,9-125
- Lift Cylinders ..... 8-5 - 8-17

F

Flow Divider Valve 8-19
Front Apron Shaft 9-77,9-79
Front Drive Shaft - main
- 1000 RPM 9-41
- 540 RPM 9-37, 9-39

G

Gearbox
- Apron Drive 9-65,9-67
- Widespread Drive 9-75

Gearbox Supports 9-69

MidWestTech | Case 530, 540, 550, 560 Manure Spreader Parts Catalog | Publication 8-59... Order the manual at mid-west-tech.com >