
NEW HOLLAND

TS90
TS100
TS110

with EconoShift transmission

OPERATOR'S MANUAL



86562958 1/98

NEW HOLLAND

MidWestTech | New Holland TS90, TS100, TS110 EconoShift Tractor Operator's Manual | Publication 86562958

Order the manual at mid-west-tech.com >

CONTENTS

Title	Page
Introduction	
To the owner	0–6
Product identification	0–7
Environmental considerations	0–8
Towing and transporting the tractor	0–9
Safety precautions	0–10
Safety decals	0–16
Universal symbols	0–19
Section 1 – Operation	
Operation – Safety frame, seat and seat belt	1–2–1–4
Operation – Parking brake, foot pedals and instruments	1–5–1–11
Operation – Starting and stopping the engine	1–12–1–15
Operation – Transmission	1–16–1–23
Operation – Independent power take-off (P.T.O.)	1–24–1–27
Operation – Hydraulics system	1–28–1–35
Operation – Three-point linkage	1–36
Operation – Front wheel track adjustment	1–44–1–47
Operation – Rear wheel track adjustment	1–48–1–52
Operation – Ballasting and tires	1–53–1–63
Section 2 – Lubrication and Maintenance	
General Information	2–1–2–6
Lubrication and Maintenance Chart	2–7
Maintenance requirements – Controlled by Warning Lights	2–8–2–10
Maintenance requirements – Every 10 Hours or Daily	2–11–2–12
Maintenance requirements – Every 50 Hours	2–13–2–19
Maintenance requirements – Every 150 Hours	2–20
Maintenance requirements – Every 300 Hours	2–21–2–25
Maintenance requirements – Every 600 Hours	2–26–2–29
Maintenance requirements – Every 1200 Hours or Annually	2–30–2–33
Maintenance requirements – Every 1200 Hours or Two Years	2–34–2–36
Maintenance requirements – As Required	2–37–2–43
Section 3 – Specifications	
Section 4 – First 50–hour Service Forms	
Section 5 – Index	

MidWestTech | New Holland TS90, TS100, TS110 EconoShift Tractor Operator's Manual |... Order the manual at mid-west-tech.com >