

NEW HOLLAND TX66 TX68


REPAIR MANUAL

NEW HOLLAND

SERVICE

Order the manual at mid-west-tech.com >

NOTES FOR SERVICE PARTS CATALOGUE CONSULTING



MidWestTech | New Holland TX66, TX68 Combine Service Manual | Publication 86603389 Order the manual at mid-west-tech.com >

ENGLISH

1 ITEM - Reference - Code of Part Number.

2 PART NR. - Part Number.

3 NT - Note - relating to the Part Number. There is a key to symbols and abbreviations at the bottom of the text page.

4 Q. - Total Quantity of the Part referred to in the page.
The quantity can be replaced by the following indications:
M = supplied in metres. AR = quantity as requested.

5 MODIF. - Modification.
C 0202 = Part valid UNTIL 0202.
D 0300 = Part valid FROM 0300.

6 Implementation of change. Serial number from which the change starts. The numbers are indicated on the identification plate of the model (see page 5).
E.g.: D0300 Serial n° 2503001 means that the part has been installed "FROM" serial number 2503001. Consequently, the parts marked by C0202 were installed UP TO serial number 2502999.

7 [2] Includes item(s) ..... (See English discription)

8 [1.5] Part illustrated in the Group.

9 Technical specifications relating to the Part indicated.

10 Model Trademark.

11 "Section" Code.

12 "Group" name.

13 "Group" code.

14 Page number.

15 Date of printing or updating of page (month-year).

16 Part Description.

17 I.C.-Lexicon code for the identification of Part names in **German** and Spanish (see page 33).

18 **Further description** of the Part. Besides the specific indications of the Part such as size and use, common descriptions can be utilized (see page 34).

19 Specific Notes to the illustrations or to the text.

20 Position of the "Section" on the machine.

21 Running direction (see page 34).

22 Parts illustrated without item number are shown in the following group.

23 General information of the group.

MidWestTech | New Holland TX66, TX68 Combine Service Manual | Publication 86603389 Order the manual at mid-west-tech.com >


CONVERSION CHART

	Foot	Yard	Mile	Inch	Metre
1 Foot	1	0.333	–	12	0.3048
1 Yard	3	1	–	36	0.9144
1 Mile	5280	1760	1	63360	1609.35
1 Inch	0.0833	0.0277	–	1	0.0254
1 Metre	3.281	1.0936	–	39.37	1

1 US bushel	=	35.2391 litre	1 litre = 0.028 US bushel
1 US quart	=	0.9464 litre	1 litre = 1.056 US quart
1 UK bushel	=	36.3687 litre	1 litre = 0.027 UK bushel
1 UK quart	=	1.1365 litre	1 litre = 0.879 UK quart
1 US gallon	=	3.785 litre	1 litre = 0.264 US gallon
1 UK gallon	=	4.5461 litre	1 litre = 0.22 UK gallon
1 barrel	=	158.987 litre	1 litre = 0.0063 barrel

1 acre	= 0.4047 ha	1 ha	= 2.471 acre
1 pound	= 0.4536 kg	1 kg	= 2.204 pound
1 hp	= 0.736 kW	1 kW	= 1.358 hp
1 lb/ in^2	= 0.0689 bar = 6.894 kPa	1 bar 1 kPa	= 14.5 lbs/ in^2 = 0.145 lbs/ in^2
1 pa	= 10 $^{-5}$ bar = 1.450x10^{-4} lbs/ in^2	1 bar 1 lb/ in^2	= 100 kPa = 6.896 kPa
1 kgf.m	= 9.806 Nm	1 Nm	= 0.1019 kgf.m
1 lbf ft	= 0.1385 kgm	1 kgf.m	= 7.22 lbf ft

MidWestTech | New Holland TX66, TX68 Combine Service Manual | Publication 86603389
Order the manual at mid-west-tech.com >



16

MidWestTech | New Holland TX66, TX68 Combine Service Manual | Publication 86603389 Order the manual at mid-west-tech.com >