PARTS CATALOG

LM840
LM850
LM860
TELEHANDLER

86606715NA

NEW HOLLAND CONSTRUCTION

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

00.1		MAINTENANCE PARTS
01.02.1		ENGINE
01.40.0	01	ALTERNATOR
01.40.0	02	ALTERNATOR
01.40.0/A	01	ALTERNATOR
01.40.0/A	02	ALTERNATOR
02.02.3		FAN AND FAN DRIVE
02.04.3	01	FUEL LINES
02.04.3	02	FUEL LINES
02.04.3/A	01	FUEL LINES
02.04.3/A	02	FUEL LINES
02.15.1		MUFFLER
02.17.0		RADIATOR
02.19.1		AIR FILTER
02.19.1/A		AIR FILTER
02.26.0		ENGINE TRANSMISSION INTALLATION
03.28.0		GEARBOX
03.28.0/A		GEARBOX
03.28.0/B	01	GEARBOX, COMPONENTS
03.28.0/B	01A	GEARBOX, COMPONENTS
03.28.0/C	01	GEARBOX, COMPONENTS
03.28.0/C	01A	GEARBOX, COMPONENTS
03.28.0/D		TRANSFER BOX
03.28.0/E	01	ELECTRIC CONTROL VALVE
03.28.0/E	01A	ELECTRIC CONTROL VALVE
03.28.0/E	02	ELECTRIC CONTROL VALVE
03.28.3		ANGLE RETURN BOX
03.38.6		POWER TAKE-OFF ENGINE - ANGLE RETURN BOX
04.38.1		POWER TAKE-OFF, FRONT AXLE
04.38.1/1		POWER TAKE-OFF, FRONT AXLE
04.40.0/0A		FRONT AXLE
04.40.0/0B		CASING, FRONT AXLE
04.40.0/0C		POWER TAKE-OFF, FRONT AXLE
04.40.0/0D		REDUCTION GEAR, FRONT AXLE
04.40.0/0E		REDUCTION GEAR, FRONT AXLE
04.40.0/0F		BRAKE DISCS, FRONT AXLE
04.40.0/0G		STEERING SYSTEM, FRONT AXLE
04.40.0/1		FRONT AXLE
04.40.0/1A		CASING, FRONT AXLE
04.40.0/1B		DIFFERENTIAL, FRONT AXLE
04.40.0/1C		REDUCTION GEAR, FRONT AXLE
04.40.0/1D		BRAKE DISCS, FRONT AXLE
04.40.0/1E		STEERING SYSTEM, FRONT AXLE
04.40.0/1F		FRONT AXLE, SUPPORT
04.40.0/2		FRONT AXLE
04.40.0/2A		CASING, FRONT AXLE
04.40.0/2B		DIFFERENTIAL, FRONT AXLE
04.40.0/2C		REDUCTION GEAR, FRONT AXLE
04.40.0/2D		BRAKE DISCS, FRONT AXLE
04.40.0/2E		STEERING SYSTEM, FRONT AXLE
04.40.0/2F		FRONT AXLE, SUPPORT

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

05.38.4/1		POWER TAKE-OFF, REAR AXLE
05.38.4		POWER TAKE-OFF, REAR AXLE
05.44.0/0A		REAR AXLE
05.44.0/0B		CASING, REAR AXLE
05.44.0/0C		DIFFERENTIAL, REAR AXLE
05.44.0/0D		REDUCTION, REAR AXLE
05.44.0/0E		BRAKE DISCS, REAR AXL
05.44.0/0F		STEERING SYSTEM, REAR AXLE - C2103
05.44.0/1		REAR AXLE
05.44.0/1A		CASING, REAR AXLE
05.44.0/1B		DIFFERENTIAL, REAR AXLE
05.44.0/1C		REDUCTION, REAR AXLE -
05.44.0/1D		BRAKE DISCS, REAR AXLE
05.44.0/1E		STEERING SYSTEM, REAR AXLE
05.44.0/1F		REAR AXLE, SUPPORT
06.75.0		ELECTRICITY - ENGINE, TRANSMISSION
06.75.1		ELECTRICITY, RELAY AND PRINTED CIRCUIT
06.75.2		ELECTRICITY, ACCESSORIES
06.75.2/A	01	ELECTRIC CIRCUIT
06.75.2/A	02	ELECTRIC CIRCUIT
06.75.2/B	01	ELECTRIC CIRCUIT
06.75.2/B	02	ELECTRIC CIRCUIT
06.75.2/C	01	ELECTRIC CIRCUIT
06.75.2/C	02	ELECTRIC CIRCUIT
06.75.2/D	01	ELECTRIC CIRCUIT
06.75.2/D	02	ELECTRIC CIRCUIT
06.75.2/E	01	ELECTRIC CIRCUIT
06.75.2/E	02	ELECTRIC CIRCUIT
06.75.2/F	01	ELECTRIC CIRCUIT
06.75.2/F	02	ELECTRIC CIRCUIT
06.75.2/G		ELECTRICITY - BATTERIES
06.91.1	01	ELECTRICITY, CAB
06.91.1	02	ELECTRICITY, CAB
06.91.4		LIGHTING SYSTEM
06.91.5		AIR CONDITIONING - ELECTRICITY
07.08.5/A	01	CYLINDER, TELESCOPIC, EXTERNAL
07.08.5/A	02	CYLINDER, TELESCOPIC, EXTERNAL
07.08.5/B	01	CYLINDER, TELESCOPIC, INTERNAL
07.08.5/B	02	CYLINDER, TELESCOPIC, INTERNAL
07.08.5/C	01	CYLINDER, TELESCOPIC, EXTERNAL
07.08.5/C	02	CYLINDER, TELESCOPIC, EXTERNAL
07.08.5/D	01	CYLINDER, TELESCOPIC, INTERNAL
07.08.5/D	02	CYLINDER, TELESCOPIC, INTERNAL
07.08.5/E		CYLINDER, TELESCOPIC, EXTERNAL
07.08.5/F		CYLINDER, TELESCOPIC, INTERNAL
07.11.1/A		LIFT CYLINDER, LH
07.11.1/B		LIFT CYLINDER, RH
07.11.1/C		LIFT CYLINDER, LH
07.11.1/D		LIFT CYLINDER, RH
07.11.2		CYLINDER, HYDRAULIC
07.11.3		HYDRAULIC CIRCUIT, LIFTING

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

07.11.5		TILTING CYLINDER
07.11.6		CYLINDER FOR STABILIZER
07.11.7		HYDRAULIC CIRCUIT, STABILIZER
07.21.5	01	CYLINDER, COMPENSATION
07.21.5	02	CYLINDER, COMPENSATION
07.22.1		CYLINDER, LEVELLING SYSTEM
07.22.1/A		CYLINDER, LEVELLING SYSTEM
07.22.2		HYDRAULIC CIRCUIT, LEVELLING SYSTEM
07.22.2/A		HYDRAULIC CIRCUIT, LEVELLING SYSTEM
07.22.2/B		HYDRAULIQUE CIRCUIT LEVELLING CIRCUIT
07.44.1		CYLINDER, LOCKING REAR AXLE
07.44.2		CYLINDER, LOCKING REAR AXLE
07.82.4		MAIN VALVE, DISTRIBUTION
07.82.4/A		MAIN VALVE, DISTRIBUTION
07.82.4/B		MAIN VALVE, DISTRIBUTION
07.82.6		HYDRAULIC, PRINCIPAL CIRCUIT
07.82.6/A		HYDRAULIC, PRINCIPAL CIRCUIT
07.82.6/B		HYDRAULIC, PRINCIPAL CIRCUIT
07.82.6/C	01	HYDRAULIC CIRCUIT, STEERING SYSTEM
07.82.6/C	02	HYDRAULIC CIRCUIT, STEERING SYSTEM
07.82.6/D	01	HYDRAULIC CIRCUIT, STEERING SYSTEM
07.82.6/D	02	HYDRAULIC CIRCUIT, STEERING SYSTEM
07.82.6/E		HYDRAULIC CIRCUIT FOR TELESCOPE
07.82.6/F		HYDRAULIC CIRCUIT FOR TELESCOPE
07.82.6/G		HYDRAULIC CIRCUIT FOR TELESCOPE
07.82.6/H		HYDRAULIC CIRCUIT FOR TELESCOPE
07.82.6/I		HYDRAULIC CIRCUIT, BOOM
07.82.6/J		HYDRAULIC CIRCUIT, BOOM
07.82.6/K		HYDRAULIC CIRCUIT, BOOM
07.82.6/L		HYDRAULIC CIRCUIT, ATTACHMENT BOOM
07.82.8/A		HYDRAULIC CIRCUIT, BOOM CONTROL
07.82.8/B		HYDRAULIC CIRCUIT, BOOM CONTROL
07.95.5		STEERING VALVE
08.83.0		SHEET METAL
08.83.0/A		SHEET METAL
08.87.0		FENDERS
08.98.0		DECALS
08.98.0/1		DECALS
09.07.2/A		BOOM
09.07.2/B		BOOM
09.07.2/C		BOOM
09.07.2/D		BOOM
09.12.9/ 2		FORK, EXTENSION
09.13.0		FLOATING FORKS CARRIERES
09.13.1		FLOATING FORKS CARRIERES
09.13.1/1		FLOATING FORKS CARRIERES
10.10.1		PEDALS AND LINKAGE
10.37.4		HANDBRAKE
10.37.6	01	BRAKE CIRCUIT
10.37.6	02	BRAKE CIRCUIT
10.85.1		SEAT

MidWestTech | New Holland LM840, LM850, LM860 Telehandler Parts Catalog | Publicatio... Order the manual at mid-west-tech.com >

GEARBOX, COMPONENTS

REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTION
1		9968363		3	SCREW
2	1	9968339		2	PLUG
3		9968362		1	COVER
4		9968361		1	WASHER
5		9968360		1	O-RING
6		9968359		1	FILTER
7	2	85813704		AR	KIT, SEALS
8	3	85813703		AR	KIT, SEALS
9		85813644		2	PLUG
10		85813645		1	HOUSING
11		9968218		5	O-RING 9/16"
12	4	85813702		AR	KIT, SEALS
13	5	85813701		AR	KIT, SEALS
14		9968364		1	BREATHER
15		85813646		1	LEVER
16		9968327		1	PIN
17		85813647		1	FLANGE
18		85813648		1	O-RING
19		85813649		1	COLLAR
20		9972263		1	BOOT
21		85813672		3	SCREW
22		85813673		1	FLANGE
23		85813700		1	RING
24		85813674		1	HOUSING
25		85813675		8	SCREW
26		9968313		1	GASKET
27		85813676		1	PUMP, ENGINE OIL
28		9968227		4	WASHER
29		9968221		4	SCREW
30		85813678		1	SEAL, RUBBER

(1) Includes Ref. : 52
(2) Includes Ref. : 32, 43, 51
(3) Includes Ref. : 26, 30, 32, 43, 45, 51 And Fig. 03.28.0/C Ref. : 26 ,27 ,60
(4) Includes Ref.: 5, 11, 18, 52 And Fig. 03.28.0/C Ref.: 2, 38, 64, 67
(5) Includes Ref. : 9, 26, 28, 30, 45 And Fig. 03.28.0/C Ref. : 21, 26, 37, 60

Gearbox 85814417 Type 15978 Serial Number : Until 041718353

LM840 LM850 LM860

MidWestTech | New Holland LM840, LM850, LM860 Telehandler Parts Catalog | Publicatio... Order the manual at mid-west-tech.com >

HYDRAULIC, PRINCIPAL CIRCUIT

REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTION
35		85814703		1	KIT, SEALS
36		85807571		1	KIT, SEALS
37		85807567		4	SCREW M12 x 25
38		85814566		1	CONNECTOR, HYD.
39		85807568		1	O-RING
40		85814569		4	SCREW M10 x 25
41		85814567		1	CONNECTOR, HYD.
42		85807034		1	O-RING
43	1	85814555		1	HOSE, FLEXIBLE
44		85806433		AR	O-RING 2 x 12MM
45	2	85814570		1	CONNECTOR, HYD.
46		85807678		AR	O-RING 1.6 x 18.7MM
47		85814568		2	SCREW
48		85811514		4	WASHER 12MM
49		85807035		4	SCREW
50		85806531		4	WASHER 10MM
51		85814553		2	O-RING
52		85806434		4	CLAMP
53		85806435		2	PLATE
54		85806398		2	SCREW M8 x 45
55		85814574		1	SUPPORT
56		85808117		4	SCREW M12 x 30
57		85806537		3	WASHER 12MM
58		85807713		1	CLIP, HOSE
59	3	85814564		1	HOSE, FLEXIBLE
60		85806502		AR	O-RING 2.4 x 16.3MM
61	4	85806430		1	CONNECTOR, HYD.
62		85806431		AR	O-RING 2.2 x 19.3MM
63	4	85806500		1	CONNECTOR, HYD.
64	5	85814557		1	CONNECTOR, HYD.
65		85814556		1	CONNECTOR, HYD.

(1) Includes Ref. : 44
(2) Includes Ref. : 46
(3) Includes Ref. : 60
(4) Includes Ref. : 62
(5) Includes Ref. : 22

MidWestTech | New Holland LM840, LM850, LM860 Telehandler Parts Catalog | Publicatio... Order the manual at mid-west-tech.com >

HYDRAULIC CIRCUIT, BOOM

REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTION
34		85806613		2	CONNECTOR, HYD.
36		85806601		2	HALF-COLLAR
37		85806608		AR	PLATE
38	1	85806600		2	SCREW M8 x 35
39		85806661		2	SCREW M8 x 40
40		85806377		2	SCREW M6 x 10
41		85806378		1	WASHER 6MM
42		85806661		2	SCREW M8 x 40
43		85813809		1	GUIDE
44	2	85806451		1	KIT, REPAIR Seals
45		85806549		AR	SEAL, RUBBER 16MM,For tube
47		85814479		1	BRACKET
48	3	85806614		4	CONNECTOR, HYD.
51	4	85806615		2	CONNECTOR, HYD.
52		85806494		AR	O-RING 2.2 x 13.3MM
53		85806616		2	COUPLING, QUICK, MALE
54		85806617		2	PLUG
55		85806619		2	PLUG
56		85811753		2	SCREW
57	3	85813812		2	PLUG
58	5	85820656		1	VALVE, HYDRAULIC
59	5	85816465		1	KIT, REPAIR Seals

(1) Includes Ref. : 22, 37
(2) Serial Number : Until 041718869
(3) Includes Ref. : 20
(4) Includes Ref. : 20, 52
(5) Serial Number : 041718870 And After

MidWestTech | New Holland LM840, LM850, LM860 Telehandler Parts Catalog | Publicatio... Order the manual at mid-west-tech.com >