D and DX 35, 40 and 45 Tractors

Repair Manual

86619355

MidWestTech | Case D35, D45, DX40, DX35, D40, DX45 Tractor Service Manual | Publication 86619355

Order the manual at mid-west-tech.com >

SECTION 00 - GENERAL INFORMATION

Chapter 1 - General Information

CONTENTS

Section	Description	Page
00 000	Introduction	00-2
	Safety	00-3
	Technical Information	00-4
	Safety Precautions	00-5
	Safety Decals - D35, D40, D45	00-8
	Instruction Decals - D35, D40, D45	00-9
	Safety Decals - DX35, DX40, DX45	00-12
	Instruction Decals - DX35, DX40, DX45	00-13
	International Symbols	00-17
	Specifications - D35, D40, D45	00-18
	General Dimensions - D35, D40, D45	00-25
	Specifications - DX35, DX40, DX45	00-31
	General Dimensions - DX35, DX40, DX45	00-37
	Minimum Hardware Tightening Torques	00-41
	Special Tools	00-43
	Lubricants	00-44
00 400	Recommended Lubricants	00-44
	Adjustments	00-45
	Tire Inflation Pressure - Adjustments	00-45
00 100	Pre-Season and Pre-Delivery Checklist	00-46

MidWestTech | Case D35, D45, DX40, DX35, D40, DX45 Tractor Service Manual | Publicat... Order the manual at mid-west-tech.com >

Section 41
Steering

Section 44
2WD Front Axle

Section 55
Electrical

Section 90
Platform

D and DX 35, 40 and 45 Tractors

Repair Manual

86620537

CASE

MidWestTech | Case D35, D45, DX40, DX35, D40, DX45 Tractor Service Manual | Publicat... Order the manual at mid-west-tech.com >

Section 25
4WD Front Axle

Section 27
Differential, Rear Axle

Section 29
Hydrostatic Transmission

Section 31
Power Take-Off (PTO) Systems

Section 33
Brakes

Section 35
Hydraulic System

D and DX 35, 40 and 45 Tractors

Repair Manual

86620536

CASE

MidWestTech | Case D35, D45, DX40, DX35, D40, DX45 Tractor Service Manual | Publicat... Order the manual at mid-west-tech.com >