# NEW HOLLAND CONSTRUCTION

## LW170
## LW170TC
## LW190
## LW230
## LW270



86641697
JULY,2001

# OPERATOR'S MANUAL

NEW HOLLAND

MidWestTech | New Holland LW170, LW170TC, LW190, LW230, LW270 Wheel Loader Ope... Order the manual at mid-west-tech.com >

# TABLE OF CONTENTS


| TITLE | PAGE |
|---|---|
| Safety rules | I-VIII |
| Safety plates and their locations on the machine | 1 |
| Safety components | 5 |
| Stability | 6 |
| Noise and vibration levels | 7 |
| Identification data | 8 |
| Controls | 10 |
| Instrumentation | 17 |
| Warning and indicator lights | 18 |
| Keystart switch | 20 |
| Control switches | 21 |
| Cab | 23 |
| Driver's seat adjustement | 25 |
| Fire protection | 25 |
| Cab heating and ventilation | 26 |
| Windshield wiper | 27 |
| Safety belt | 28 |
| Accessories | 28 |
| Radio | 29 |
| Auxiliary 12 V power socket | 30 |
| Outer 24 V power sockets | 30 |
| Operating instructions | 31 |
| Preliminary instructions and run-in period | 32 |
| Before starting | 33 |
| Instructions for the starting and stopping of the loader | 34 |
| Precautions for operation in cold weather | 37 |
| Moving the machine | 38 |
| Towing | 39 |
| Travel with chains | 40 |
| Transporting the machine | 40 |
| Measures to be taken in case of emergency | 41 |
| Exhausted batteries | 41 |

| TITLE | PAGE |
|---|---|
| Releasing the parking brake | 43 |
| Road transfers | 44 |
| Loader operation | 49 |
| Operating tips | 53 |
| Equipment | 55 |
| Periodical inspection | 58 |
| Maintenance | 59 |
| Tools | 61 |
| Access panels for maintenance operations | 62 |
| Position of filling plugs/caps | 63 |
| Main greasing points | 64 |
| Fluid capacity and maintenance intervention table LW170-LW190-LW230 | 65 |
| Fluid capacity and maintenance intervention table LW270 | 67 |
| Every 10 working hours | 69 |
| Every 50 working hours | 72 |
| Every 250 working hours | 74 |
| Tires and wheels | 83 |
| Every 500 working hours | 85 |
| Every 1000 working hours | 89 |
| Every 1500 working hours | 94 |
| Every 2000 working hours | 95 |
| Every 6000 working hours | 98 |
| Variable periodic operations | 99 |
| Location of fuses | 102 |
| Specifications LW170 | 104 |
| Specifications LW170TC | 105 |
| Specifications LW190 | 113 |
| Specifications LW230 | 114 |
| Specifications LW270 | 115 |
| Troubleshooting chart | 116 |
| Machine groups electric diagrams | 121 |
| Dealer Delivery Service Report Forms | Last Page |


MidWestTech | New Holland LW170, LW170TC, LW190, LW230, LW270 Wheel Loader Ope... Order the manual at mid-west-tech.com >