JX55, JX65, JX75, JX85, JX95 Tractors

Parts Catalog

Print No. 87052971PC
Issued 03/2019

CASE IH AGRICULTURE

MidWestTech | Case JX55, JX65, JX75, JX85, JX95 Tractor Parts Catalog | Publication 87...
Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

0.01.0	01	OPTIONAL EQUIPMENT
0.01.0	02	OPTIONAL EQUIPMENT
0.05.4	01	MAINTENANCE PARTS - FILTERS
05.100.03		FILTERS & CAPACITIES, JX55
05.100.03	01	FILTER & CAPACITIES, JX65
05.100.03	01	FILTERS & CAPACITIES, JX65
05.100.03	02	FILTER & CAPACITIES, JX75
05.100.03	02	FILTERS & CAPACITIES, JX75
05.100.03	03	FILTER & CAPACITIES, JX85
05.100.03	03	FILTERS & CAPACITIES, JX85
05.100.03	04	FILTER & CAPACITIES, JX95
05.100.03	04	FILTERS & CAPACITIES, JX95
05.100.03	05	FILTER & CAPACITIES, JX55
MAIN		MAIN SECTIONS
SEC. 01	01	ENGINE
SEC. 01	02	ENGINE
SEC. 02		ENGINE EQUIP.
SEC. 03		TRANSMISSION
SEC. 04		FRONT AXLE
SEC. 05		REAR AXLE
SEC. 06		ELECTRICAL
SEC. 07		HYDRAULICS
SEC. 08		SHEET METAL
SEC. 09		LINKAGE
SEC. 10		DRIVER'S COMPARTMENT
SEC. 11	01	TRACTION
SEC. 11	02	TRACTION
SEC. 13		DECALS
0.02.0 SEC.	01	ENGINE
0.02.0 SEC.	02	ENGINE
0.02.1	01	ENGINE (BEFORE S/N 13286)
0.02.1	02	ENGINE (AFTER S/N 13287)
0.02.1	03	ENGINE (AFTER S/N 13287)
0.02.1/01	01	ENGINE (BEFORE S/N 13286)

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

0.02.1/01	02	ENGINE (AFTER S/N 13287)
0.02.1/01	03	ENGINE (AFTER S/N 13287)
0.02.1/02	01	ENGINE (BEFORE S/N 13286)
0.02.1/02	02	ENGINE (AFTER S/N 13287)
0.04.0	01	CRANKCASE AND CYLINDERS (BEFORE S/N 13286)
0.04.0	02	CRANKCASE AND CYLINDERS (AFTER S/N 13287)
0.04.0/01	01	CRANKCASE AND CYLINDERS (BEFORE S/N 13286)
0.04.0/01	02	CRANKCASE AND CYLINDERS (AFTER S/N 13287)
0.04.0/02	01	CRANKCASE AND CYLINDERS (BEFORE S/N 13286)
0.04.0/02	02	CRANKCASE AND CYLINDERS (AFTER S/N 13287)
0.04.0/03	01	CRANKCASE AND CYLINDERS (BEFORE S/N 13286)
0.04.0/03	02	CRANKCASE AND CYLINDERS (AFTER S/N 13287)
0.04.0/04	01	CRANKCASE AND CYLINDERS (BEFORE S/N 13286)
0.04.0/04	02	CRANKCASE AND CYLINDERS (AFTER S/N 13287)
0.04.2		OIL SUMP
0.04.2/01	01	OIL SUMP
0.04.2/01	02	OIL SUMP
0.04.3	01	COVERS & GASKETS, FRONT (BEFORE S/N 13286)
0.04.3	02	COVERS & GASKETS, REAR (BEFORE S/N 13286)
0.04.3/01	01	COVERS & GASKETS, FRONT (BEFORE S/N 13286)
0.04.3/01	02	COVERS & GASKETS, REAR (BEFORE S/N 13286)
0.04.3/02	01	COVERS & GASKETS, FRONT (AFTER S/N 13287)
0.04.3/02	02	COVERS & GASKETS, REAR (AFTER S/N 13287)
0.04.5		BREATHER
0.06.0	01	CYLINDER HEAD ASSEMBLY (BEFORE S/N 13286)
0.06.0	02	VALVES (BEFORE S/N 13286)
0.06.0/01	01	CYLINDER HEAD (BEFORE S/N 13286)
0.06.0/01	02	VALVES (BEFORE S/N 13286)
0.06.0/02	01	CYLINDER HEAD ASSEMBLY (AFTER S/N 13287)
0.06.0/02	02	VALVES (AFTER S/N 13287)
0.06.0/03	01	CYLINDER HEAD ASSEMBLY (AFTER S/N 13287)
0.06.0/03	02	VALVES (AFTER S/N 13287)
0.06.0/04	01	CYLINDER HEAD (AFTER S/N 13287)
0.06.0/04	02	VALVES (AFTER S/N 13287)

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

0.06.0/05	01	CYLINDER HEAD (AFTER S/N 13287)
0.06.0/05	02	VALVES (AFTER S/N 13287)
0.07.1	01	INTAKE MANIFOLD (BEFORE S/N 13286)
0.07.1	02	INTAKE MANIFOLD (AFTER S/N 13287)
0.07.1	03	INTAKE MANIFOLD (AFTER S/N 13287)
0.07.1/01		INTAKE MANIFOLD (BEFORE S/N 13286)
0.07.1/02		INTAKE MANIFOLD (BEFORE S/N 13286)
0.07.1/03		INTAKE MANIFOLD (AFTER S/N 13287)
0.07.6	01	EXHAUST MANIFOLD
0.07.6	02	EXHAUST MANIFOLD (BEFORE S/N 13286)
0.07.6	03	EXHAUST MANIFOLD (AFTER S/N 13287)
0.07.6/01	01	EXHAUST MANIFOLD
0.07.6/01	02	EXHAUST MANIFOLD (BEFORE S/N 13286)
0.07.6/02		EXHAUST MANIFOLD (BEFORE S/N 13286)
0.07.6/03		EXHAUST MANIFOLD (AFTER S/N 13287)
0.08.0	01	CRANKSHAFT
0.08.0	02	CRANKSHAFT (BEFORE S/N 13286)
0.08.0	03	CRANKSHAFT (AFTER S/N 13287)
0.08.0/01		CRANKSHAFT
0.08.1		CONNECTING ROD (BEFORE S/N 13286)
0.08.1/01		CONNECTING ROD (AFTER S/N 13287)
0.08.2		PISTON (BEFORE S/N 13286)
0.08.2/01		PISTON (AFTER S/N 13287)
0.08.3		FLYWHEEL
0.08.3/01	01	FLYWHEEL (BEFORE S/N 13286)
0.08.3/01	02	FLYWHEEL (AFTER S/N 13287)
0.08.3/02		FLYWHEEL (BEFORE S/N 13286)
0.08.3/03		FLYWHEEL (BEFORE S/N 13286)
0.08.3/04		FLYWHEEL (AFTER S/N 13287)
0.08.4		PULLEY AND HUB
0.08.4/01		PULLEY AND HUB
0.10.0		DRIVE GEARS
0.10.5	01	DYNAMIC BALANCER, GEARS & SHAFTS
0.10.5	02	DYNAMIC BALANCER, GEARS & SHAFTS

Order the manual at mid-west-tech.com >

COVERS & GASKETS, REAR (AFTER S/N 13287)

REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTION
1		80280854		2	SCREW M14 x 2 x 35
1		16613324		2	SCREW Hex, M14 x 100mm M14 x 1.5 x 100
2		11200174		4	BELLEVILLE WASHER M14 Bolt Size x 32mm OD x 3.4mm Thk
3		99485219		1	COVER
4		10839710		2	DOWEL M10 x 15.00mm
5		4658441		2	DOWEL 10mm OD x 20mm L
6		16102311		1	THIN NUT Thin, M8 x 1.25, Cl 04
7		4607466		1	OPERATOR TIMING REF/ OPERATOR TIMING REF/
8		13543721		1	STUD M8 x 16 x 35
9		4849994		1	GASKET 0.8mm Thk
10		98489586		1	COVER
11		98400797		1	GASKET 47mm ID x 62mm OD x 0.8mm Thk
12		4670802		1	COVER
13		17094960		1	SEAL
14		16104121		1	NUT M8 x 1.25, Cl 10
15		504127327		1	SEAL 114.8mm ID x 134.8mm OD x 13mm Thk
16		16043924		4	BOLT Hex, M8 x 1.25 x 35mm, Cl 8.8, Full Thd
17		12638501		5	WASHER 8.15mm ID x 15mm OD x 1.5mm Thk

MidWestTech | Case JX55, JX65, JX75, JX85, JX95 Tractor Parts Catalog | Publication 87... Order the manual at mid-west-tech.com >

INJECTION PUMP, TOP COVER & ADJUSTMENT SCREW

REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTION
1		500324962		1	FUEL INJECTION PUMP
1		500324962R		1	REMAN-INJECTION PUMP REMAN-INJECTION PUMP
1		500324962C		1	CORE-INJECTION PUMP CORE-INJECTION PUMP Return Number
2		79071368		1	ORIFICE
3		9982759		1	SLEEVE
4		15896221		1	NUT Hex, M6, 5.20mm High, Cl 10
5		14305624		4	HEX SOC SCREW M6 x 35mm, Cl 8.8
6		9968208		1	COVER Incl. Ref. 4, 16
7		9966150		1	GASKET
8		9008557		1	O-RING 2mm Thk x 6.5mm ID
9		9970412		1	SPINDLE
10		9970310		1	ADJUSTMENT SCREW
11		9970473		1	BRUSH HOLDER
12		9971837		1	KIT
13		9967823		1	GASKET
14		9971690		1	SPRING
15		79071400		1	SEAL
16		9970437		1	STUD

MidWestTech | Case JX55, JX65, JX75, JX85, JX95 Tractor Parts Catalog | Publication 87... Order the manual at mid-west-tech.com >

(VAR.007) NORTH AMERICA VERSION - SEAT, SUPPORT AND COMPONENT PARTS

REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTION
1		5091981		1	DRIVER SEAT
2		5080316		1	SEAT CUSHION
3		5080312		1	BACKREST
4		5080309		2	ROLLER
5		5080248		9	SPRING WASHER
6		5080294		5	BOLT
7		5080297		2	SPACER
8		5080298		1	RIVET
9		5080303		2	BOLT
10		5080204		1	PIN
11		5080307		1	GAS STRUT
12		5080305		2	COTTER PIN
13		5080299		2	BOLT
14		5080295		6	BUSHING
15		5080308		1	ROD
16		5080289		4	RING
17		5080282		4	U-BRACKET
18		5080274		4	BOLT
19		5080236		2	NUT
20		5080290		2	WASHER
21		5080288		1	ROD
22		5080293		1	FRAME
23		5080283		1	KNOB
24		5080287		1	SPRING
25		5080285		1	SUPPORT
26		5080286		1	PIN
27		5080304		1	ADJUSTMENT SCREW Hex, 1/4" - 20 x 3/4", Gr 5
28		5080301		1	RETAINER

JX55-CASE IH TRACTOR - TIER 1/TIER 2 JX65-CASE IH TRACTOR - TIER 1/TIER 2 JX75-CASE IH TRACTOR - TIER 1/TIER 2 JX85-CASE IH TRACTOR - TIER 1/TIER 2 JX95-CASE IH TRACTOR - TIER 1/TIER 2

Order the manual at mid-west-tech.com >