NEW HOLLAND

LOADER BACKHOE

B95LR

PARTS CATALOG

87364130 NA

Issued 02-2006

NEW HOLLAND

www.newhollandconstruction.com

MidWestTech | New Holland B95LR Loader Backhoe Parts Catalog | Publication 87364130

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

636A	05	ACCESSORY ENGINE - BRACKET MUFFLER
636A	06	ACCESSORY ENGINE - STARTER
SEC. 02	00	FUEL TANK - MUFFLER - RADIATOR - AIR CLEANER - CHASSIS
1.14.0	01	FUEL TANK & RELATED PARTS
1.15.0	01	MUFFLER & EXTENSIONS
1.15.0	02	MUFFLER & EXTENSIONS
1.17.2	01	EXPANSION TANK
1.19.1	01	AIR CLEANER & HOSES
1.21.5/ 1	01	FRAME (CENTER PIVOT)
175	01	AIR INTAKE CAP & PRE-CLEANER
176	01	AIR INTAKE CAP & PRE-CLEANER
203	01	FRONT WEIGHTS
215	01	FRONT WEIGHTS
636	01	RADIATOR
636	02	RADIATOR
636/ 1	01	RADIATOR
636/ 2	02	RADIATOR
637	01	RADIATOR
637	02	RADIATOR
637/ 1	01	RADIATOR
637/ 2	01	RADIATOR
637/ 3	01	RADIATOR
SEC. 03	00	TRANSMISSION 1/2
SEC. 03	01	TRANSMISSION 2/2
1.28.0	01	GEARING SPEED GEAR
1.28.0/ A	01	TRANSMISSIONGEARING SPEED GEAR (2WD POWER-SHUTTLE)
1.28.0/ A	02	TRANSMISSIONGEARING SPEED GEAR (2WD POWER-SHUTTLE)
1.28.0/ A	03	TRANSMISSIONGEARING SPEED GEAR (2WD POWER-SHUTTLE)
1.28.0/ A	04	TRANSMISSIONGEARING SPEED GEAR (2WD POWER-SHUTTLE)
1.28.0/ A	05	TRANSMISSIONGEARING SPEED GEAR (2WD POWER-SHUTTLE)
1.28.0/ A	06	TRANSMISSIONGEARING SPEED GEAR (2WD POWER-SHUTTLE)
1.28.0/ A	07	TRANSMISSIONGEARING SPEED GEAR (2WD POWER-SHUTTLE)
1.28.0/ B	01	TRANSMISSIONGEARING SPEED GEAR (4WD POWER-SHUTTLE)
1.28.0/ B	02	TRANSMISSIONGEARING SPEED GEAR (4WD POWER-SHUTTLE)
1.28.0/ B	03	TRANSMISSIONGEARING SPEED GEAR (4WD POWER-SHUTTLE)
1.28.0/ B	04	TRANSMISSIONGEARING SPEED GEAR (4WD POWER-SHUTTLE)
1.28.0/ B	05	TRANSMISSIONGEARING SPEED GEAR (4WD POWER-SHUTTLE)
1.28.0/ B	06	TRANSMISSIONGEARING SPEED GEAR (4WD POWER-SHUTTLE)
1.28.0/ B	07	TRANSMISSIONGEARING SPEED GEAR (4WD POWER-SHUTTLE)
1.28.0/ B	08	TRANSMISSIONGEARING SPEED GEAR (4WD POWER-SHUTTLE)
1.28.6	01	GEAR FILTER PIPES (POWER-SHUTTLE)
1.29.1	01	TRANSMISSION ESTERNALSHIFTING CONTROLS (POWER-SHUTTLE)
1.38.1	01	FRONT & REAR DRIVESHAFT (POWER-SHUTTLE)
1.39.8	01	TRANSMISSION OIL COOLING PIPES (POWER-SHUTTLE)
SEC. 04	00	FRONT AXLE
1.40.0	01	FRONT AXLE (2WD)
1.40.0	02	FRONT AXLE (2WD)
402	01	4WD FRONT AXLE, HOUSING, BUSHINGS & SUPPORTS
402	02	4WD FRONT AXLE, SWIVEL HOUSING & STEERING CYLINDER
402	03	4WD FRONT AXLE, HUBS
402	04	4WD FRONT AXLE, RING GEAR & PINION ASSEMBLY
402	05	4WD FRONT AXLE, DIFFERENTIAL

MidWestTech | New Holland B95LR Loader Backhoe Parts Catalog | Publication 87364130 Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

402	06	4WD FRONT AXLE, DRIVE SHAFT
415	01	FRONT AXLE - (4WD) W/GEAR,BEVEL
415	02	FRONT AXLE - (4WD) W/GEAR,BEVEL
415	03	FRONT AXLE - (4WD) W/GEAR,BEVEL
415	04	FRONT AXLE - (4WD) W/GEAR,BEVEL
415	05	FRONT AXLE - (4WD) W/GEAR,BEVEL
415	06	FRONT AXLE - (4WD) W/GEAR,BEVEL
SEC. 05	00	REAR AXLE
1.44.0E	01	REAR AXLE (POWER-SHUTTLE) (CENTER PIVOT)
1.44.0E	02	REAR AXLE (POWER-SHUTTLE) (CENTER PIVOT)
1.44.0E	03	REAR AXLE (POWER-SHUTTLE) (CENTER PIVOT)
1.44.0E	04	REAR AXLE (POWER-SHUTTLE) (CENTER PIVOT)
SEC. 06	00	ELECTRICAL
1.75.2/ 3	01	CHASSIS HARNESS & GROUND WIRE (POWER SHUTTLE)
1.75.2/ 3	02	BATTERY LOCK-OUT SWITCH & GROUND WIRE (POWER SHUTTLE)
1.75.2/ 3	03	ENGINE HARNESS (POWER SHUTTLE)
131	01	SINGLE BATTERY
321	01	DOUBLE BATTERY
995	01	COLD START
995	02	COLD START
SEC. 07	00	SLIDES VALVES
1.82.0	01	HYDRAULIC OIL RESERVOIR
1.82.3	01	HYDRAULIC PUMP (35+35-154L/MM)
1.82.3/ 1	01	HYDRAULIC PUMP (40+35-165L/MM)
1.82.3/ 2	01	HYDRAULIC PUMP (40+35-165L/MM)
1.82.6	01A	HYDRAULIC SYSTEM PIPING (CENTER PIVOT)
1.82.6	01B	FRONT HYDRAULIC PUMP INTAKE & OUTLET HOSES (CENTER PIVOT)
1.82.6	02A	HYDRAULIC SYSTEM PIPING(CENTER PIVOT)
1.82.6	02B	REAR HYDRAULIC PUMP STABILIZER, LOADER & BACKHOE VALVE HOSES (CENTER PIVOT)
1.82.6	03A	HYDRAULIC SYSTEM PIPING(CENTER PIVOT)
1.82.6	03B	QUICK RELEASE COUPLERS & HOSES (CENTER PIVOT)
1.82.6	04A	RETURN MANIFOLD HOSES (CENTER PIVOT)
1.82.6	04B	RETURN MANIFOLD HOSES (CENTER PIVOT)
1.82.6	05F	OIL COOLER & FILTER HOSES (CENTER PIVOT)
1.82.6	05G	HYDRAULIC SYSTEM PIPING (CENTER PIVOT)
1.82.6	06A	FILTER ASSEMBLY & HOSE TO RETURN MANIFOLD (CENTER PIVOT)
1.82.6	06B	FILTER ASSEMBLY & HOSE TO RETURN MANIFOLD (CENTER PIVOT)
1.82.6	07	HYDRAULIC SYSTEM PIPING
1.82.6	08A	LOADER LIFT CYLINDER HOSES (CENTER PIVOT)
1.82.6	08C	LOADER LIFT CYLINDER HOSES (CENTER PIVOT)
1.82.6	09A	LOADER BUCKET CYLINDER HOSES (CENTER PIVOT)
1.82.6	09B	LOADER BUCKET CYLINDER HOSES (CENTER PIVOT)
1.82.6	10A	HYDRAULIC SYSTEM PIPING NA (CENTER PIVOT)
1.82.6	11A	BACKHOE CONTROL VALVE HOSES (CENTER PIVOT)
1.82.6	11B	HYDRAULIC SYSTEM PIPING(CENTER PIVOT)
1.82.6	12B	HYDRAULIC SYSTEM PIPING(CENTER PIVOT)
1.82.6	13A	ROTATION PLATE HOSE CLAMPS (CENTER PIVOT)
1.82.6	16	BACKHOE CONTROL VALVE(CENTER PIVOT)
1.82.6	17	DIPPER VALVE SECTION (CENTER PIVOT)
1.82.6	18	BUCKET, SWING, & BOOM VALVE SECTION (CENTER PIVOT)
302	01	TWO-SECTION CONTROL VALVE FOR LOADER

MidWestTech | New Holland B95LR Loader Backhoe Parts Catalog | Publication 87364130 Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

339	03	LOADER CONTROL VALVE, THREE SECTION, RELIEF & CHECK VALVES (CENTER PIVOT)
344	01	STABILIZER CONTROL VALVE, TWO SECTION (CENTER PIVOT)
344	02	STABILIZER CONTROL VALVE, LH & RH SECTION (CENTER PIVOT)
356	01	STABILIZER CONTROL VALVE, TREE SECTION (CENTER PIVOT)
356	02	STABILIZER CONTROL VALVE, THIRD SECTION (CENTER PIVOT)
391	01	LOCK VALVE FOR BUCKET 4X1 / 6X1
391/ 1	01	LOCK VALVE ON LOADER TILTING CYLINDERS
391/ 1	02	LOCK VALVE ON LOADER LIFT CYLINDERS
391/ 1	03	LOCK VALVE ON LOADER LIFT CYLINDERS
392	01	LOCKING VALVE ON BACKHOE LIFT AND DIPP. CYLINDER
392	02	BACKHOE LIFT & DIPPERSTICK CYLINDER LOCK VALVE
437/ 1	01	GLIDE RIDE VALVE,HYDRAULIC SYSTEM FOR MACHINE FRAME LEVELLING & ON/OFF SWITCH
698	01	GLIDE RIDE VALVE,HYDRAULIC SYSTEM FOR MACHINE FRAME LEVELLING & ON/OFF SWITCH
708	01	THREE-SECTION CONTROL VALVE FOR LOADER
708/ 1	01	KIT OF CONVERSION FROM 2 TO 3 SPOOLS
721	01	TELESCOPIC CONTROL VALVE, 3 SECTIONS(CENTER PIVOT)
721	02	HED TELESCOPIC CONTORL VALVE, SECTION HOSES(CENTER PIVOT)
721	03	HED CYLINDER PISTON END HYDRAULIC LINES(CENTER PIVOT)
721	04	HED CYLINDER ROD END HYDRAULIC LINES(CENTER PIVOT)
721	05	HED FOOT PEDAL, CABLE & DECALS(CENTER PIVOT)
SEC. 08	00	BODY & HOOD
1.87.2	01	CAB SCREEN
1.87.8	01	CAB FASTENERS
SEC. 09	00	LOADER 1/1
SEC. 09	01	BACKHOE 1/2
SEC. 09	02	BACKHOE 2/2
1.88.01	01	TRANSPORT LOCK" REAR LOCKING" (CENTER PIVOT)
1.88.01	02	TRANSPORT LOCK" REAR LOCKING" (CENTER PIVOT)
1.88.01/ 2	01	"TRANSPORT LOCK" ON/OFF SWITCH, VALVE & HOSES
1.88.01/ 2	02	TRANSPORT LOCK HOOK, CYLINDER & HOSE (SIDE SHIFT,CENTER PIVOT)
1.88.08	01	SWING POST ASSEMBLY, BUSHINGS & PINS
1.88.08	02	SWING POST PINS & TRANSPORT LOCK HOOK
1.88.09	01	DISTRIBUTOR VALVE SUPPORT (CENTER PIVOT)
1.88.11	01	ARMS AND JOINTS
1.88.11/ 1B	01	LIFT CYLINDER
1.88.11/ 2	02	LOADER BUCKET CONTROL CYLINDER
1.88.11/ 2A	01	LOADER BUCKET CONTROL CYLINDER
1.88.11/ 3	01	LIFT CYLINDER AND BUCKET PIPES
1.88.11/ 5	01	SELF-LEVELING LINKAGE, LOADER CONTROLS (CENTER PIVOT)
1.88.11/ 5	02	SELF-LEVELING LINKAGE, LOADER ARM (CENTER PIVOT)
1.88.11/ 6	02	STABILIZER CYLINDERS (CENTER PIVOT)
1.88.11/ 7	01	PIPES FOR STABILIZER CYLINDERS (CENTER PIVOT)
1.88.11/ 8	01	RETURN TO DIG SENSOR
1.88.11/ 9A	01	CYLINDERS AND ROTATION PLATE
1.88.11/ 9C	01	SWING CYLINDERS BACKHOE
1.88.12/ 3	01	FRONT CONTROL VALVE SUPPORT AND TRANSMISSIONS (CENTER PIVOT)
120	01	SILENT HAMMER CB65S
120/ 1	01	HAMMER CB65B
200	01	SHOVEL AND REAR LIFTING HOOKS

Order the manual at mid-west-tech.com >

REAR AXLE (POWER-SHUTTLE) (CENTER PIVOT)

REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTION
1		E1ADDN4286		1	RING
2		E188EB9		1	SPRING Differential Lock Coupler
3		C5NN4N064A		1	COUPLING
4		E189EB9		1	WASHER Differential Lock, Coupler Stop
5		957E4221		1	BEARING, CONE
6		510892		1	BEARING, CUP RH
7		E186EB9		1	ADAPTER Differential Lock Gear Case
8		957E4292B		4	PINION, DRIVE
9		D9NN4230AA		4	CARRIER
10		81816246		1	HOUSING
11		957E4228		2	WASHER RH
12		E185EB9		2	BUSHING RH
13		81803445		1	GEAR
14		81876885		1	SPIDER
15		C5NN4239A		1	GEAR RH
16		82959375		1	BEARING, CUP
17		510884		1	BEARING, CONE
18		43104S		8	BOLT Cap, HH, G8, Self-Locking, 1/2"-13 x 2-7/8"
19		E2NN4209DA		1	GEAR SET 4,62
20		81824478		1	BEARING ASSY
21		960E4627		1	RING, SNAP
22		82958961		1	BEARING ASSY
23		81845711		1	BEARING, CONE
24		87090S94		1	O-RING 4.625" ID x .139" Thk
25		81847146		1	RETAINER
26		87346427		AR	PLATE
26		87346228		AR	PLATE
26		87346229		AR	PLATE
26		87346231		AR	PLATE
26		87346232		AR	PLATE
27		9706729		2	SCREW Cap, HH, G5, 7/16"-14 x 1"
28		83957533		12	BOLT HH, G8, 1/2"-20 x 1-5/8"
29		380135S43		12	NUT Lock, G2, 1/2"-20
30		52491		1	CUP
31		D8NN4616AA		1	CUP
32		83949810		1	FLANGE
33		D3NN4676A		1	SEAL PROTECTION

From To S/N XXX

Order the manual at mid-west-tech.com >

STANDARD 1M3 BUCKET WITH FORKS AND TINE

REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTION
1		9968144		2	FORK
2		9969170		2	ROD
3		9968146		2	SUPPORT
4		9968147		4	PIN, ROLL
5		9968148		4	PIN
6		9968149		2	PIN
7		9968150		2	PIN, SPLIT (COTTER)
8		9968151		2	SCREW M10X90
9		9968152		2	NUT M10
10		9968153		1	SUPPORT
11		9968154		1	SUPPORT
12		9968155		1	SUPPORT
13		9968156		2	U-BRACKET
14		85801486		1	KIT FORKS
15		85801034		1	EDGE, CUTTING
16		85801470		16	NUT 5/8"-11
17		85801371		16	BOLT
18		85802992		4	O-RING
19		85802993		4	PIN
20		85801051		4	PIN
21		85811440		8	LUG

Order the manual at mid-west-tech.com >

A/C FILTER & CONDENSER ATTACHING GROUP

REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTION
1		14496534		4	WASHER
2		16043421		2	SCREW
3		16104111		2	NUT
4		87315252		1	BRACKET
5		85819184		7	SCREW
6	1	85804065		1	SENDER UNIT
7		87315214		1	BRACKET
8		87315219		1	BRACKET
9		87315221		1	BRACKET RH
10		87315225		1	BRACKET LH
11		87315236		1	BRACKET
12		87315239		2	COLLAR
13		87314566		1	CONDENSER
14		87315241		1	FILTER, AIR
15		16043621		4	SCREW
16		85819185		1	GASKET
17	2	87319438		1	SUPPORT
18	2	14040711		8	WASHER
19	2	87319441		1	SUPPORT

(1) Includes 20
(2) Only For Version Without Intercooler

From To S/N XXX

Order the manual at mid-west-tech.com >