NEW HOLLAND

LOADER BACKHOE

B115

PARTS CATALOG

87364132 NA

Issued 02-2006

NEW HOLLAND

www.newhollandconstruction.com

MidWestTech | New Holland B115 Loader Backhoe Parts Catalog | Publication 87364132

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

636A	06	ACCESSORY ENGINE - STARTER
638A	01	ACCESSORY ENGINE
638A	02	ACCESSORY ENGINE - VENTILATOR
638A	03	ACCESSORY ENGINE - STARTER
638A	04	ACCESSORY ENGINE- ALTERNATOR
638A	05	ACCESSORY ENGINE - BRACKET MUFFLER
639A	01	ACCESSORY ENGINE
639A	02	ACCESSORY ENGINE - VENTILATOR
639A	03	ACCESSORY ENGINE - STARTER
639A	04	ACCESSORY ENGINE- ALTERNATOR
SEC. 02	00	FUEL TANK - MUFFLER - RADIATOR - AIR CLEANER - CHASSIS
1.14.0	01	FUEL TANK & RELATED PARTS
1.15.0	01	MUFFLER & EXTENSIONS
1.15.0	02	MUFFLER & EXTENSIONS
1.17.2	01	EXPANSION TANK
1.19.1	01	AIR CLEANER & HOSES
1.21.5/ 2	01	FRAME (CENTER PIVOT)
175	01	AIR INTAKE CAP & PRE-CLEANER
176	01	AIR INTAKE CAP & PRE-CLEANER
202	01	FRONT WEIGHTS
638	01	RADIATOR
638	02	RADIATOR
639	01	RADIATOR
639	02	RADIATOR
639	03	RADIATOR
SEC. 03	00	TRANSMISSION 1/2
SEC. 03	01	TRANSMISSION 2/2
1.28.0	01	GEARING SPEED GEAR
1.28.0/ A	01	TRANSMISSIONGEARING SPEED GEAR (2WD POWER-SHUTTLE)
1.28.0/ A	02	TRANSMISSIONGEARING SPEED GEAR (2WD POWER-SHUTTLE)
1.28.0/ A	03	TRANSMISSIONGEARING SPEED GEAR (2WD POWER-SHUTTLE)
1.28.0/ A	04	TRANSMISSIONGEARING SPEED GEAR (2WD POWER-SHUTTLE)
1.28.0/ A	05	TRANSMISSIONGEARING SPEED GEAR (2WD POWER-SHUTTLE)
1.28.0/ A	06	TRANSMISSIONGEARING SPEED GEAR (2WD POWER-SHUTTLE)
1.28.0/ A	07	TRANSMISSIONGEARING SPEED GEAR (2WD POWER-SHUTTLE)
1.28.0/ C	01	TRANSMISSIONGEARING SPEED GEAR (4WD POWER-SHIFT)
1.28.0/ C	02	TRANSMISSIONGEARING SPEED GEAR (4WD POWER-SHIFT)
1.28.0/ C	03	TRANSMISSIONGEARING SPEED GEAR (4WD POWER-SHIFT)
1.28.0/ C	04	TRANSMISSIONGEARING SPEED GEAR (4WD POWER-SHIFT)
1.28.0/ C	05	TRANSMISSIONGEARING SPEED GEAR (4WD POWER-SHIFT)
1.28.0/ C	06	TRANSMISSIONGEARING SPEED GEAR (4WD POWER-SHIFT)
1.28.0/ C	07	TRANSMISSIONGEARING SPEED GEAR (4WD POWER-SHIFT)
1.28.0/ C	08	TRANSMISSIONGEARING SPEED GEAR (4WD POWER-SHIFT)
1.28.0/ C	09	TRANSMISSIONGEARING SPEED GEAR (4WD POWER-SHIFT)
1.28.0/ C	10	TRANSMISSIONGEARING SPEED GEAR (4WD POWER-SHIFT)
1.28.0/ C	11A	TRANSMISSION (4WD, 4WS, POWER-SHIFT)
1.28.0/ C	12	TRANSMISSIONGEARING SPEED GEAR (4WD POWER-SHIFT)
1.28.0/ C	13A	TRANSMISSION (4WD, 4WS POWER-SHIFT)
1.28.0/ C	14A	TRANSMISSION (4WD, 4WS POWER-SHIFT)
1.28.0/ C	15	TRANSMISSIONGEARING SPEED GEAR (4WD POWER-SHIFT)
1.28.0/ C	16	TRANSMISSIONGEARING SPEED GEAR (4WD POWER-SHIFT)
1.28.6/ 1	01	GEAR FILTER PIPES (POWER-SHIFT)

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

1.38.1/ 1	01	FRONT & REAR DRIVESHAFT (POWER-SHIFT)
1.39.8	01	TRANSMISSION OIL COOLING PIPES (POWER-SHUTTLE)
1.39.8/ 1	01	TRANSMISSION OIL COOLING PIPES (POWER-SHIFT)
SEC. 04	00	FRONT AXLE
400	01	FRONT AXLE (4WS) - BOX
400	02	FRONT AXLE (4WS) - BOX
400	03	FRONT AXLE (4WS) - STEERING AXLES
400	04	FRONT AXLE (4WS) - BEVEL GEAR PAIR
400	05	FRONT AXLE (4WS) - BEVEL GEAR PAIR
400	06	FRONT AXLE (4WS) - DIFFERENTIAL LOCKING
400	06A	SELF-LOCKING FRONT AXLE: DIFFERENTIAL AUTOMATIC LOCKING 4WS
400	07	FRONT AXLE (4WS) - AXLE-SHAFT ARTICULATED
400	08	FRONT AXLE (4WS) - HUBS
400	09	FRONT AXLE (4WS) - HUBS
SEC. 05	00	REAR AXLE
400A	01	REAR AXLE, RH & CENTER HOUSING
400A	02	REAR AXLE, LH HOUSING & BUSHINGS
400A	03	REAR AXLE, RH SWIVEL HOUSING, STEERING CYLINDER & SENSOR
400A	04	REAR AXLE, LH SWIVEL HOUSING
400A	05	REAR AXLE, RING GEAR & PINION ASSEMBLY
400A	06	REAR AXLE, PINION SHIMS
400A	07	REAR AXLE, DIFFERENTIAL (STANDARD)
400A	08	SELF-LOCKING REAR AXLE, DIFFERENTIAL (SELF LOCKING)
400A	09	REAR AXLE, BRAKES
400A	10	REAR AXLE, WHEEL CARRIER & HUB
400A	11	REAR AXLE, PLANETARY GEARS & COVER
SEC. 06	00	ELECTRICAL
1.75.2/ 5	01	CHASSIS HARNESS & GROUND WIRE (POWER SHIFT)
1.75.2/ 5	02	BATTERY LOCK-OUT SWITCH & GROUND WIRE (POWER SHIFT)
1.75.2/ 5	03	ENGINE HARNESS (POWER SHIFT)
131	01	SINGLE BATTERY
321	01	DOUBLE BATTERY
995	01	COLD START
995	02	COLD START
SEC. 07	00	SLIDES VALVES
1.82.0	01	HYDRAULIC OIL RESERVOIR
1.82.3	01	HYDRAULIC PUMP (35+35-154L/MM)
1.82.3/ 1	01	HYDRAULIC PUMP (40+35-165L/MM)
1.82.3/ 2	01	HYDRAULIC PUMP (40+35-165L/MM)
1.82.6	01	HYDRAULIC SYSTEM PIPING
1.82.6	02	HYDRAULIC SYSTEM PIPING
1.82.6	04C	HYDRAULIC SYSTEM PIPING(CENTER PIVOT)
1.82.6	05B	HYDRAULIC SYSTEM PIPING(CENTER PIVOT)
1.82.6	05C	HYDRAULIC SYSTEM PIPING(CENTER PIVOT)
1.82.6	06B	FILTER ASSEMBLY & HOSE TO RETURN MANIFOLD (CENTER PIVOT)
1.82.6	07A	HYDRAULIC SYSTEM PIPING
1.82.6	08B	HYDRAULIC SYSTEM PIPING
1.82.6	10	HYDRAULIC SYSTEM PIPING NA 4WS (CENTER PIVOT)
1.82.6	11B	HYDRAULIC SYSTEM PIPING(CENTER PIVOT)
1.82.6	12B	HYDRAULIC SYSTEM PIPING(CENTER PIVOT)
1.82.6	13B	HYDRAULIC SYSTEM PIPING(CENTER PIVOT)
300	01	BACKHOE CONTROL VALVE, 6 SECTIONS (CENTER PIVOT)

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

392	02	BACKHOE LIFT & DIPPERSTICK CYLINDER LOCK VALVE
437/ 1	01	GLIDE RIDE VALVE,HYDRAULIC SYSTEM FOR MACHINE FRAME LEVELLING & ON/OFF SWITCH
698	01	GLIDE RIDE VALVE,HYDRAULIC SYSTEM FOR MACHINE FRAME LEVELLING & ON/OFF SWITCH
702/ 1	02	PEDAL-OPERATED TELESCOPIC DIPPER HYDRAULIC SYSTEM (CENTER PIVOT)
703	01	PEDAL-OPERATED TELESCOPIC DIPPER HYDRAULIC SYSTEM
703	02	PEDAL-OPERATED TELESCOPIC DIPPER HYDRAULIC SYSTEM
703	03	PEDAL-OPERATED TELESCOPIC DIPPER HYDRAULIC SYSTEM
703	04	PEDAL-OPERATED TELESCOPIC DIPPER HYDRAULIC SYSTEM
703	05	PEDAL-OPERATED TELESCOPIC DIPPER HYDRAULIC SYSTEM
708	01	THREE-SECTION CONTROL VALVE FOR LOADER
708/ 1	01	KIT OF CONVERSION FROM 2 TO 3 SPOOLS
727/ 3	01	HYDRAULIC SYSTEM PRESETTING FOR TELESCOPIC LINKS PEDAL OPERATED(CENTER PIVOT)
SEC. 08	00	BODY & HOOD
1.87.2	01	CAB SCREEN
1.87.8	01	CAB FASTENERS
SEC. 09	00	LOADER 1/1
SEC. 09	01	BACKHOE 1/2
SEC. 09	02	BACKHOE 2/2
1.88.01/ 2	02	TRANSPORT LOCK HOOK, CYLINDER & HOSE (SIDE SHIFT,CENTER PIVOT)
1.88.01/ 3	01	HYDRAULIC SYSTEM FOR "TRANSPORT LOCK" REAR LOCKING
1.88.01/ 3	02	HYDRAULIC SYSTEM FOR "TRANSPORT LOCK" REAR LOCKING
1.88.08	01	SWING POST ASSEMBLY, BUSHINGS & PINS
1.88.08	02	SWING POST PINS & TRANSPORT LOCK HOOK
1.88.09/ 1	01	DISTRIBUTOR VALVE SUPPORT (SIDE SHIFT)
1.88.11/ A	01	ARMS AND JOINTS
1.88.11/ 1C	01	LIFT CYLINDER
1.88.11/ 2B	01	LOADER BUCKET CONTROL CYLINDER
1.88.11/ 3A	01	LIFT CYLINDER AND BUCKET PIPES
1.88.11/ 6	02	STABILIZER CYLINDERS (CENTER PIVOT)
1.88.11/ 7A	01	PIPES FOR STABILIZER CYLINDERS (CENTER PIVOT)
1.88.11/ 8	01	RETURN TO DIG SENSOR
1.88.11/ 9A	01	CYLINDERS AND ROTATION PLATE
1.88.11/ 9C	01	SWING CYLINDERS BACKHOE
1.88.12/ 3	01	FRONT CONTROL VALVE SUPPORT AND TRANSMISSIONS (CENTER PIVOT)
120	01	SILENT HAMMER CB65S
120/ 1	01	HAMMER CB65B
200	01	SHOVEL AND REAR LIFTING HOOKS
416-417	01	SYSTEM HAMMER COMPONENTS (CAB)
469	01	BUCKET 6X1 (1,15 M3) WITH BLADE
469	02	BUCKET 6X1 (1,15 M3) WITH BLADE
469/ A	01	HYDRAULIC CYLINDER (BUCKET 4X1-6X1)
469/ 1	01	BUCKET 6X1 (1,15 M3) WITH BLADE "COMMON GREY"
469/ 2	01	BUCKET 6X1 (1,15 M3) WITH BLADE "COMMON GREY"
470	01	BUCKET 6X1 (1,15 M3) WITH TINE
470	02	BUCKET 6X1 (1,15 M3) WITH TINE
470/ 1	01	BUCKET 6X1 (1,15 M3) WITH TINE "COMMON GREY"
470/ 2	01	BUCKET 6X1 (1,15 M3) WITH TINE "COMMON GREY"
475	01	BUCKET 4X1 (1,15 M3) WITH BLADE
475	02	BUCKET 4X1 (1,15 M3) WITH BLADE

Order the manual at mid-west-tech.com >

FRONT CONTROL VALVE SUPPORT AND TRANSMISSIONS (CENTER PIVOT)

REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTION
1		85804376		1	JOINT, UNIVERSAL
2		16102311		3	NUT
3		85801564		1	TIE-ROD
4		16102911		3	NUT LH
5		85804375		3	JOINT, UNIVERSAL
6		85805616		1	PIN
7		85805692		1	PIN
8		85801566		1	TIE-ROD
9		85805690		1	LEVER, IDLER
10		85802738		2	PIN
11		11991971		2	YOKE
12		85801562		1	TIE-ROD
13		14048211		4	NUT M8X1,25
16		14568887		AR	BUTTON
17		85802842		1	BOOT
18		15540321		2	SCREW Cap, HH, CL 8.8, M12 x 1.25 x 25
19		11190779		6	WASHER, LOCK
20		85801518		1	JOINT, UNIVERSAL
21		85802494		2	BUSHING
22	1	85817789		1	SUPPORT
22	2	87312027		1	SUPPORT
23		11112821		4	BOLT M12X40
24		85804539		1	BOOT W/CAB
25		85808422		6	PLUG W/CAB

(1) UP TO S/N XXX
(2) FROM TO S/N XXX

Order the manual at mid-west-tech.com >

POWER STEERING MOTOR, WHEEL & COLUMN (4WS)

REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTION
1	1	85804837		1	STEERING HYDRAULIC
1	2	87360432		1	STEERING HYDRAULIC
2		85801879		1	KNOB
3		10615774		4	WASHER, LOCK 10x18x2
4	1	85804705		4	SCREW 3/8"-16x7/8"
4	2	14432334		4	SCREW M10x22
5	1, 3	85824197		1	GAS STRUT
5	2	87328136		1	SHOCK ABSORBER
6	1	85805545		1	STEERING COLUMN
6	2	87324867		1	STEERING COLUMN
7		85801976		1	BELLOWS
8		85820105		1	COVER, CAP
9		10791414		1	NUT M16x1.5
10		4998760		1	WASHER M16x1.5
11		5148946		1	STEERING WHEEL
12		85805774		1	SOFT TRIM
13		85805773		1	SOFT TRIM
14		14303324		4	SCREW
15		11190574		4	WASHER, LOCK 10x20x2.3
16	3	85824197		1	GAS STRUT

(1) UP TO S/N XXX
(2) FROM TO S/N XXX
(3) Only for 85805545

Order the manual at mid-west-tech.com >

4 LEVER BACKHOE CONTROLS, CONSOLE, LEVERS & BELLCRANK

REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTION
1		85804780		4	ARM, TRIP
2		85803382		4	BOOT
3		13272477		10	SCREW M4x20
4		85802647		1	SUPPORT
5		15540421		2	SCREW
6		83962919		2	HANDLE R.H.
7		85804782		1	PIN
8		85803540		1	PLATE
9		16101511		6	NUT M12x1.25
10		11190779		6	WASHER, LOCK
11		85804801		1	LEVER, IDLER
12		85802494		12	BUSHING
13		85804787		1	LEVER, IDLER
14		13940370		1	PIN, ROLL
15		85804794		1	LEVER, IDLER
16		85804791		1	LEVER, IDLER
17		85805239		1	CONSOLE
18		83962918		2	HANDLE L.H.
19		85804781		1	COVER
20		13812631		1	DOWEL M12x1.25
21		85803917		1	DECAL
22		85802227		1	PLUG

Mechanical Version

Order the manual at mid-west-tech.com >