CASE

PROFESSIONAL PARTNER

PARTS CATALOG
CRAWLER DOZER

650K
SERIES 3

87364208 NA

Issued 01Dec06

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

02-01	ENGINE - MOUNTING
02-02	FAN - FAN BELT
02-03	RADIATOR - MOUNTING
02-04	RADIATOR ASSY
02-05	COOLANT RECOVERY SYSTEM
02-06	AIR CLEANER - MOUNTING
02-07	AIR CLEANER ASSY
02-08	MUFFLER - EXHAUST SYSTEM
02-09	ENGINE
02-10	CYLINDER BLOCK
02-11	CYLINDER BLOCK
02-12	OIL PUMP, PAN
02-13	GEAR COVER - REAR HOUSING
02-14	CYLINDER BLOCK - COVERS
02-15	FLYWHEEL HOUSING
02-16	BREATHER - ENGINE
02-17	CYLINDER HEAD
02-18	CYLINDER HEAD - COVERS
02-19	CYLINDER HEAD - VALVE MECHANISM
02-20	MANIFOLD - INTAKE
02-21	MANIFOLD - EXHAUST
02-22	CRANKSHAFT
02-23	PISTONS - CONNECTING ROD
02-24	PISTONS - CONNECTING ROD
02-25	FLYWHEEL - ENGINE
02-26	PULLEY - CRANKSHAFT
02-27	DYNAMIC BALANCER, GEARS & SHAFTS
02-28	CAMSHAFT
02-29	TURBOCHARGER
02-30	ENGINE, OIL
02-31	OIL PUMP - ENGINE
02-32	OIL FILTERS - ENGINE
02-33	PIPING - ENGINE OIL
02-34	OIL FILTER AND COOLER
02-35	WATER PUMP
02-36	COOLING SYSTEM - ENGINE
02-37	THERMOSTAT - ENGINE COOLING SYSTEM
02-38	WATER PUMP - CONTROL
02-39	FAN DRIVE
02-40	POWER TAKE-OFF
02-41	ENGINE - LIFT HOOK
03-01	CONTROLS, THROTTLE - CABLE AND HAND LEVER
03-02	CONTROLS, THROTTLE - DECELERATOR PEDAL AND CROSS SHAFT
03-03	CONTROLS, THROTTLE - LINKAGE AT ENGINE
03-04	FUEL TANK
03-05	FUEL LINES
03-06	FUEL INJECTION PUMP
03-07	FUEL INJECTION SYSTEM
03-08	FUEL INJECTION SYSTEM
03-09	FUEL INJECTION SYSTEM
03-10	FUEL FILTER

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

03-11	FUEL PUMP
03-12	FUEL INJECTION SYSTEM
03-13	FUEL INJECTION SYSTEM
04-01	STARTER
04-02	ALTERNATOR ASSY (MODELS WITHOUT AIR CONDITIONING)
04-03	ALTERNATOR ASSY (MODELS WITH AIR CONDITIONING)
04-04	ALTERNATOR MOUNTING
04-05	BATTERY, SINGLE - CABLES
04-06	BATTERY, DUAL - CANOPY, ROPS
04-07	BATTERY, DUAL - CAB
04-08	HARNESS, ENGINE - FUSES AND RELAYS
04-09	HARNESS, ENGINE (RIGHT-HAND SIDE) - ALTERNATOR
04-10	HARNESS, ENGINE (LEFT-HAND SIDE AND REAR)
04-11	HARNESS, ENGINE AND REAR WIRE HARNESS
04-12	HARNESS, FRONT CONSOLE AND SWITCHES - CANOPY, ROPS
04-13	HARNESS, FRONT CONSOLE AND SWITCHES - CAB
04-14	HARNESS, CAB/CANOPY - HARNESS, MICROCONTROLLER
04-15	CONSOLE, FRONT - CANOPY, ROPS
04-16	CONSOLE, FRONT - CAB
04-17	INSTRUMENT CLUSTER
04-18	LAMPS, ROPS CAB
04-19	LAMPS, ROPS CANOPY
04-20	ALARM, BACKUP - HORN
04-21	GRID HEATER - CABLES (W/O TEMP. SWITCH CONNNECTIONS; IF USED)
04-21A	GRID HEATER - CABLES (W/ TEMP. SWITCH CONNNECTIONS; IF USED)
04-22	GRID HEATER - SYSTEM CONTROL (W/O TEMP. SWITCH CONNNECTIONS; IF USED)
04-22A	GRID HEATER - SYSTEM CONTROL (W/ TEMP. SWITCH CONNNECTIONS; IF USED)
04-23	WIPER, FRONT - CAB
04-24	WIPER, REAR - CAB
05-01	FRAME, TRACK - ROLLER AND RECOIL HOUSING
05-02	FRAME, TRACK - COVERS (CLT OR SEALED TRACK CHAIN; IF USED)
05-02A	FRAME, TRACK - COVERS
05-03	SPROCKET, TRACK
05-04	TRACK ADJUSTER AND IDLER - MOUNTING
05-05	TRACK ADJUSTER
05-06	TRACK IDLER
05-07	TRACK ROLLER
05-08	TRACK GUARDS
05-09	TRACK CHAIN, SEALED
05-10	TRACK CHAIN, CASE LUBRICATED
05-11	TRACK CHAIN, EXTENDED LIFE
06-01	MOUNTING - PUMP, HYDROSTATIC TANDEM AND DRIVESHAFT
06-02	HYDROSTATICS - PUMP, TANDEM SUPPLY AND RETURN TO FILTER
06-03	HYDROSTATICS - MOTOR, DRIVE
06-04	DIAGNOSTIC LINES
06-05	MOUNTING - FINAL DRIVE
06-06	COVERS - FINAL DRIVE
06-07	FINAL DRIVE ASSY, DROP HOUSING
06-08	FINAL DRIVE ASSY, HUB
06-09	FILTER ASSY

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

06-10	CONTROLS, FORWARD AND REVERSE
06-11	HYDROSTATIC MOTOR
06-12	HYDROSTATIC MOTOR
06-13	PUMP ASSY - COMBINATION
06-14	PUMP ASSY - COMBINATION
07-01	BRAKES - PEDALS AND LINKAGE
07-02	BRAKE LINES
07-03	BRAKE, PARKING/LOCKOUT LEVERS
08-01	RESERVOIR, HYDRAULIC - COVERS
08-02	HYDRAULICS, EQUIPMENT - RESERVOIR TO PUMP AND CONTROL VALVE
08-02A	PUMP ASSY, HYDRAULIC - MODELS WITH PTO
08-03	HYDRAULICS, EQUIPMENT - CONTROL VALVE TO THERMAL BYPASS VALVE AND FILTER
08-04	VALVE ASSEMBLY, THERMAL BYPASS
08-05	HYDRAULICS - LIFT CIRCUIT
08-06	HYDRAULICS - TILT AND ANGLE CIRCUITS
08-07	HYDRAULICS - TILT CIRCUIT
08-08	HYDRAULICS - ANGLE CIRCUIT
08-09	HYDRAULICS - RIPPER, VALVE TO REAR OF TRACTOR
08-10	HYDRAULICS - RIPPER, REAR OF TRACTOR TO CYLINDERS
08-11	CYLINDER ASSY - LIFT
08-12	CYLINDER ASSY - TILT
08-13	CYLINDER ASSY - ANGLE
08-14	CYLINDER ASSY - RIPPER
08-15	VALVE, CONTROL - MOUNTING
08-16	CONTROLS - LEVER AND LINKAGE, THREE SPOOL VALVE
08-17	CONTROLS - LEVER AND LINKAGE, FOURTH SPOOL
08-18	VALVE, CONTROL
08-19	VALVE ASSY, RELIEF
08-20	SECTION ASSEMBLY - LIFT
08-21	SECTION ASSEMBLY - TILT, ANGLE, AND AUXILIARY
08-22	VALVE ASSY, CHECK - VALVE ASSY, ANTI-CAVITATION
08-23	VALVE ASSY, RELIEF
09-01	FRAME, LIFT - CYLINDERS, MOUNTING
09-02	DOZER BLADE - MOUNTING
09-03	BLADE, DOZER - EDGES, CUTTING
09-04	SHIELDS, DOZER HYDRAULICS
09-05	RIPPER
09-06	COUNTERWEIGHT, FRONT - HOOK, TOWING
09-07	DRAWBAR - HOOK, TOWING
09-08	FRAME, MAIN
09-09	MOUNTING - FUEL TANK/HYDRAULIC RESERVOIR
09-10	DOOR, REAR - TANK, HYDRAULIC OIL
09-11	DOORS, REAR
09-12	HOOD AND SIDE PANELS
09-13	GUARD, RADIATOR BRUSH SCREEN - GRILLE, HOOD
09-13A	GUARD, RADIATOR BRUSH SCREEN - GRILLE, HOOD (W/ X-BRACE; IF USED)
09-14	SEAT ASSY, MECHANICAL SUSPENSION - MOUNTING
09-15	SEAT ASSY, MECHANICAL SUSPENSION
09-16	SEAT ASSY, AIR SUSPENSION - MOUNTING
09-17	SEAT ASSY, AIR SUSPENSION

Order the manual at mid-west-tech.com >

LAMPS, ROPS CAB

REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTION
1		87370159		1	HARNESS, WIRE, Cab Lamps
		REF			INSTRUCTION, STANDARD CAB LIGHT PACKAGE
2		(87584890)		3	12V, 55W; Front and Rear Flood and Work Lamps; Incl. 1312210C2 Heavy Duty H-3 Bulb; (2 Front/1Rear)
		1312210C2		1	BULB, 12V, 55W Heavy Duty H-3 Bulb
3		614-10016		3	BOLT, Hex, M10 x 16, 8.8, Full Thd
4		895-15010		3	WASHER, M11 x 24 x 2
5		L18331		2	STRAP, CABLE
		REF			INSTRUCTION, CAB WORK LIGHTS WITHOUT SWEEPS
6		(87584890)		6	12V, 55W; Front and Rear Flood and Work Lamps; Incl. 1312210C2 Heavy Duty H-3 Bulb; (2 Front/1Rear)
		1312210C2		1	BULB, 12V, 55W Heavy Duty H-3 Bulb
7		87563194		2	BRACKET, Front Lamp Bracket
8		614-10016		6	BOLT, Hex, M10 x 16, 8.8, Full Thd
9		895-15010		6	WASHER, M11 x 24 x 2
10		627-16040		4	BOLT, Hex, M16 x 40, 10.9, Bracket Mounting, Front Lamps
11		896-11016		4	WASHER, M17.5 x 30 x 4, HT
12		L18331		4	STRAP, CABLE
		REF			INSTRUCTION, CAB WORK LIGHTS WITH SWEEPS
13		(87584890)		6	12V, 55W; Front and Rear Flood and Work Lamps; Incl. 1312210C2 Heavy Duty H-3 Bulb; (2 Front/1Rear)
		1312210C2		1	BULB, 12V, 55W, Heavy Duty H-3 Bulb
14		87563194		2	BRACKET, Front Lamp Bracket; Uses Existing Sweep Hardware
15		614-10016		6	BOLT, Hex, M10 x 16, 8.8, Full Thd
16		895-15010		6	WASHER, M11 x 24 x 2
17		L11541		7	STRAP, 7-8 Inch Nylon Strap

MidWestTech | Case 650K Series 3 Crawler Dozer Parts Catalog | Publication 87364208NA Order the manual at mid-west-tech.com >

FRAME, TRACK - COVERS

REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTION
REF		REF			INSTRUCTION, Larger Cutouts allowing 87565113 Track Frame Spacer Plate to be used between Main Frame and Track Frame; See Fig. 09-08, Ref 36 for Spacer Plate
		(87582609)			Kit, Track Covers; Incl. 1, 2, 7 - 19
1		436963A1		2	COVER ASSY, Idler; Left-Hand
2		436966A1		2	COVER ASSY, Idler; Right-Hand
3		413-820		4	BOLT, Hex, 1/2"-13 x 1 1/4", G5, Full Thd
3A		413-812		4	BOLT, Hex, 1/2"-13 x 3/4", G5, Full Thd, Not Illustrated
4		496-21053		8	WASHER, 17/32" x 1 1/6" x .134"
5		129-857		4	NUT, Sq, 1/2"-13
6		336371A1		4	PIN, Nut Retainer
7		436969A1		2	COVER ASSY, Idler
8		87582608		1	COVER ASSY, Cover Assy, Right-Hand; Inner
9		87582603		1	COVER ASSY, Cover Assy, Left-Hand; Inner
10		87582607		1	COVER ASSY, Cover Assy, Right-Hand; Inner
11		87582602		1	COVER ASSY, Cover Assy, Left-Hand; Inner
12		87585234		1	COVER ASSY, Cover Assy, Right-Hand; Outer
13		87585233		1	COVER ASSY, Cover Assy, Left-Hand; Outer
14		87582606		1	COVER ASSY, Cover Assy, Right-Hand; Inner
15		87582601		1	COVER ASSY, Cover Assy, Left-Hand; Inner
16		(87582605)		1	Cover Assy, Right-Hand; Inner
17		(87582604)		1	Cover Assy, Left-Hand; Inner
18		87585231		1	COVER ASSY, Cover Assy, Right-Hand; Outer
19		87585232		1	COVER ASSY, Cover Assy, Left-Hand; Outer
20		413-820		42	BOLT, Hex, 1/2"-13 x 1 1/4", G5, Full Thd
21		496-21053		42	WASHER, 17/32" x 1 1/6" x .134"
22		129-857		38	NUT, Sq, 1/2"-13
23		336371A1		42	PIN, Nut Retainer

MidWestTech | Case 650K Series 3 Crawler Dozer Parts Catalog | Publication 87364208NA Order the manual at mid-west-tech.com >

CYLINDER ASSY - RIPPER

REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTION
		86994129		1	CYLINDER ASSY., 83 ID x 206 mm strk; Ripper; Right-Hand; Incl. Ref 1, 2 - 19
		86994131		1	CYLINDER ASSY., 83 ID x 206 mm strk; Ripper; Left-Hand; Incl. Ref 1A - 19
1		G100608		1	CYLINDER, Tube; Right-Hand; Incl. Ref 2
1A		G100609		1	CYLINDER, Tube; Left-Hand; Incl. Ref 2
2		30634		2	BUSHING
3		86642312		1	SCREW, SELF TAP, Hex Hd, #8 x 3/8"
4		G100617		1	ROD, Incl. Ref 5
5		30634		2	BUSHING
6		G100642		1	PISTON
7		1542972C1		1	CAP CYLINDER END
		1543265C1		1	KIT, GASKET, Incl. Ref 8 - 15
8		D95143		1	SEAL
9		G102425		1	BUSHING, LARGE
10		1542875C1		1	SET OF PARTS, Seal Kit; Order 1543265C1 Kit
11		238-5236		1	O-RING, -236, 70 Duro, 3.234" ID x .139" Thk
12		D38858		1	GASKET
13		G102287		1	SEAL
14		S109444		1	RING
15		S109445		2	RING
16		86982437		1	BOLT, SPECIAL, 1 x 2-1/2; With Washer
18		219-1		1	NIPPLE, LUBE, 1/8"-27 x .66 lg
19		219-55		1	NIPPLE, LUBE, 90°, 1/8" NPT x .84" lg

MidWestTech | Case 650K Series 3 Crawler Dozer Parts Catalog | Publication 87364208NA Order the manual at mid-west-tech.com >