CASE

PROFESSIONAL PARTNER

PARTS CATALOG
CRAWLER DOZER

750K
SERIES 3

87364210 NA

Issued 01Dec06

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

02-01	ENGINE - MOUNTING
02-02	FAN - FAN BELT
02-03	RADIATOR - MOUNTING
02-04	RADIATOR ASSY
02-05	COOLANT RECOVERY SYSTEM
02-06	AIR CLEANER - MOUNTING
02-07	AIR CLEANER ASSY
02-08	MUFFLER - EXHAUST SYSTEM
02-09	ENGINE
02-10	CYLINDER BLOCK
02-11	CYLINDER BLOCK
02-12	OIL PUMP, PAN
02-13	GEAR COVER - REAR HOUSING
02-14	CYLINDER BLOCK - COVERS
02-15	FLYWHEEL HOUSING
02-16	BREATHER - ENGINE
02-17	CYLINDER HEAD
02-18	CYLINDER HEAD - COVERS
02-19	CYLINDER HEAD - VALVE MECHANISM
02-20	MANIFOLD - INTAKE
02-21	MANIFOLD - EXHAUST
02-22	CRANKSHAFT
02-23	PISTONS - CONNECTING ROD
02-24	PISTONS - CONNECTING ROD
02-25	FLYWHEEL - ENGINE
02-26	PULLEY - CRANKSHAFT
02-27	DYNAMIC BALANCER, GEARS & SHAFTS
02-28	CAMSHAFT
02-29	TURBOCHARGER
02-30	ENGINE, OIL
02-31	OIL PUMP - ENGINE
02-32	OIL FILTERS - ENGINE
02-33	PIPING - ENGINE OIL
02-34	OIL FILTER AND COOLER
02-35	WATER PUMP
02-36	COOLING SYSTEM - ENGINE
02-37	THERMOSTAT - ENGINE COOLING SYSTEM
02-38	WATER PUMP - CONTROL
02-39	FAN DRIVE
02-40	POWER TAKE-OFF
02-41	ENGINE - LIFT HOOK
03-01	CONTROLS, THROTTLE - CABLE AND HAND LEVER
03-02	CONTROLS, THROTTLE - DECELERATOR PEDAL AND CROSS SHAFT
03-03	CONTROLS, THROTTLE - LINKAGE AT ENGINE
03-04	FUEL TANK
03-05	FUEL LINES
03-06	FUEL INJECTION PUMP
03-07	FUEL INJECTION SYSTEM
03-08	FUEL INJECTION SYSTEM
03-09	FUEL INJECTION SYSTEM
03-10	FUEL FILTER

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

03-11	FUEL PUMP
03-12	FUEL INJECTION SYSTEM
03-13	FUEL INJECTION SYSTEM
04-01	STARTER
04-02	ALTERNATOR ASSY (MODELS WITHOUT AIR CONDITIONING)
04-03	ALTERNATOR ASSY (MODELS WITH AIR CONDITIONING)
04-04	ALTERNATOR MOUNTING
04-05	BATTERY, SINGLE - CABLES
04-06	BATTERY, DUAL - CANOPY, ROPS
04-07	BATTERY, DUAL - CAB
04-08	HARNESS, ENGINE - FUSES AND RELAYS
04-09	HARNESS, ENGINE (RIGHT-HAND SIDE) - ALTERNATOR
04-10	HARNESS, ENGINE (LEFT-HAND SIDE AND REAR)
04-11	HARNESS, ENGINE AND REAR WIRE HARNESS
04-12	HARNESS, FRONT CONSOLE AND SWITCHES - CANOPY, ROPS
04-13	HARNESS, FRONT CONSOLE AND SWITCHES - CAB
04-14	HARNESS, CAB/CANOPY - HARNESS, MICROCONTROLLER
04-15	CONSOLE, FRONT - CANOPY, ROPS
04-16	CONSOLE, FRONT - CAB
04-17	INSTRUMENT CLUSTER
04-18	LAMPS, ROPS CAB
04-19	LAMPS, ROPS CANOPY
04-20	ALARM, BACKUP - HORN
04-21	GRID HEATER - CABLES (W/O TEMP. SWITCH CONNNECTIONS; IF USED)
04-21A	GRID HEATER - CABLES (W/ TEMP. SWITCH CONNNECTIONS; IF USED)
04-22	GRID HEATER - SYSTEM CONTROL (W/O TEMP. SWITCH CONNNECTIONS; IF USED)
04-22A	GRID HEATER - SYSTEM CONTROL (W/ TEMP. SWITCH CONNNECTIONS; IF USED)
04-23	WIPER, FRONT - CAB
04-24	WIPER, REAR - CAB
05-01	FRAME, TRACK - ROLLER AND RECOIL HOUSING
05-02	FRAME, TRACK - COVERS (CLT OR SEALED TRACK CHAIN; IF USED)
05-02A	FRAME, TRACK - COVERS
05-03	SPROCKET, TRACK
05-04	TRACK ADJUSTER AND IDLER - MOUNTING
05-05	TRACK ADJUSTER
05-06	TRACK IDLER
05-07	TRACK ROLLER
05-08	TRACK GUARDS
05-09	TRACK CHAIN, SEALED
05-10	TRACK CHAIN, CASE LUBRICATED
05-11	TRACK CHAIN, EXTENDED LIFE
06-01	MOUNTING - PUMP, HYDROSTATIC TANDEM AND DRIVESHAFT
06-02	HYDROSTATICS - PUMP, TANDEM SUPPLY AND RETURN TO FILTER
06-03	HYDROSTATICS - MOTOR, DRIVE
06-04	DIAGNOSTIC LINES
06-05	MOUNTING - FINAL DRIVE
06-06	COVERS - FINAL DRIVE
06-07	FINAL DRIVE ASSY, DROP HOUSING
06-08	FINAL DRIVE ASSY, HUB
06-09	FILTER ASSY

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

06-10	CONTROLS, FORWARD AND REVERSE
06-11	HYDROSTATIC MOTOR
06-12	HYDROSTATIC MOTOR
06-13	PUMP ASSY - COMBINATION
06-14	PUMP ASSY - COMBINATION
07-01	BRAKES - PEDALS AND LINKAGE
07-02	BRAKE LINES
07-03	BRAKE, PARKING/LOCKOUT LEVERS
08-01	RESERVOIR, HYDRAULIC - COVERS
08-02	HYDRAULICS, EQUIPMENT - RESERVOIR TO PUMP AND CONTROL VALVE
08-02A	PUMP ASSY, HYDRAULIC - MODELS WITH PTO
08-03	HYDRAULICS, EQUIPMENT - CONTROL VALVE TO THERMAL BYPASS VALVE AND FILTER
08-04	VALVE ASSEMBLY, THERMAL BYPASS
08-05	HYDRAULICS - LIFT CIRCUIT
08-06	HYDRAULICS - TILT AND ANGLE CIRCUITS
08-07	HYDRAULICS - TILT CIRCUIT
08-08	HYDRAULICS - ANGLE CIRCUIT
08-09	HYDRAULICS - RIPPER, VALVE TO REAR OF TRACTOR
08-10	HYDRAULICS - RIPPER, REAR OF TRACTOR TO CYLINDERS
08-11	CYLINDER ASSY - LIFT
08-12	CYLINDER ASSY - TILT
08-13	CYLINDER ASSY - ANGLE
08-14	CYLINDER ASSY - RIPPER
08-15	VALVE, CONTROL - MOUNTING
08-16	CONTROLS - LEVER AND LINKAGE, THREE SPOOL VALVE
08-17	CONTROLS - LEVER AND LINKAGE, FOURTH SPOOL
08-18	VALVE, CONTROL
08-19	VALVE ASSY, RELIEF
08-20	SECTION ASSEMBLY - LIFT
08-21	SECTION ASSEMBLY - TILT, ANGLE, AND AUXILIARY
08-22	VALVE ASSY, CHECK - VALVE ASSY, ANTI-CAVITATION
08-23	VALVE ASSY, RELIEF
09-01	FRAME, LIFT - CYLINDERS, MOUNTING
09-02	DOZER BLADE - MOUNTING
09-03	BLADE, DOZER - EDGES, CUTTING
09-04	SHIELDS, DOZER HYDRAULICS
09-05	RIPPER
09-06	COUNTERWEIGHT, FRONT - HOOK, TOWING
09-07	DRAWBAR - HOOK, TOWING
09-08	FRAME, MAIN
09-09	MOUNTING - FUEL TANK/HYDRAULIC RESERVOIR
09-10	DOOR, REAR - TANK, HYDRAULIC OIL
09-11	DOORS, REAR
09-12	HOOD AND SIDE PANELS
09-13	GUARD, RADIATOR BRUSH SCREEN - GRILLE, HOOD
09-13A	GUARD, RADIATOR BRUSH SCREEN - GRILLE, HOOD (W/ X-BRACE; IF USED)
09-14	SEAT ASSY, MECHANICAL SUSPENSION - MOUNTING
09-15	SEAT ASSY, MECHANICAL SUSPENSION
09-16	SEAT ASSY, AIR SUSPENSION - MOUNTING
09-17	SEAT ASSY, AIR SUSPENSION

Order the manual at mid-west-tech.com >

TRACK CHAIN, SEALED

REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTION
		418602A1		2	TRACK ASSY, CRAWLER, 457 mm (18 inch); Chain; Incl. Shoes; Incl. 407014A1, Ref 1 - 8; 9, 10, 11
		87404007		2	TRACK ASSY, CRAWLER, 508 mm (20 inch); Chain; Incl. Shoes; Incl. 407014A1, Ref 1 - 8; 9A, 10, 11
		418605A1		2	TRACK ASSY, CRAWLER, 610 mm (24 inch); Chain; Incl. Shoes; Incl. 407014A1, Ref 1 - 8; 9B, 10, 11
		418609A1		2	TRACK ASSY, CRAWLER, 711 mm (28 inch); Chain; Incl. Shoes; Incl. 407014A1, Ref 1 - 8; 9C, 10, 11
		407014A1		1	CHAIN, TRACK, Incl. Ref 1 - 8; Order 418496A1, Ref 25
1		295178A2		39	LINK, Right-Hand
2		295177A2		39	LINK, Left-Hand
3		R56517		38	BUSHING, 123,5 mm (4-7/8 in) OD; Link
4		R50211		156	WASHER
5		R49792		38	PIN, LARGE, 183 x 33 mm
6		R54349		1	PIN, Master Link
7		R56516		1	BUSHING, 108 mm (4-1/4 in) OD; Master Link
8		R50210		2	SPACER
9		295181A1		39	SHOE, TRACK, 457 mm (18 inch)
9A		300199A1		39	SHOE, 508 mm (20 inch)
9B		295182A1		39	SHOE, 610 mm (24 inch)
9C		295183A1		39	SHOE, 711 mm (28 inch)
10		295318A1		156	BOLT, 5/8 NF x 2-1/8
11		R25688		156	NUT, 5/8 NF
		REF			INSTRUCTION, CHAIN UNIT KIT
		300214A2		1	KIT, Incl. Ref 12 - 18; Incl. Instructions
12		295178A2		1	LINK, Right-Hand
13		295177A2		1	LINK, Left-Hand
14		R49792		2	PIN, LARGE, 183 x 33 mm
15		R50210		2	SPACER
16		R56516		1	BUSHING, 108 mm (4-1/4 in) OD; Master Link
17		R54349		1	PIN, Master Link
18		R50211		8	WASHER

MidWestTech | Case 750K Series 3 Crawler Dozer Parts Catalog | Publication 87364210NA Order the manual at mid-west-tech.com >

CYLINDER ASSY - ANGLE

REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTION
		412359A1		2	CYLINDER ASSY., 89 ID x 396 mm Stroke; Angle; Incl. Ref 1 - 21
1		87434175		1	TUBE, Incl. Ref 2, 3
2		86625138		1	PLUG, Hex Soc, 7/8"-14 ORB, Incl. Ref 3
3		237-6010		1	O-RING, 10-1, 90 Duro, .755" ID x .097" Thk
4		407539A1		1	BUSHING
5		103-21281		2	RING, SNAP, 2.812", Int, #281
6		430296A1		1	ROD, PISTON, 45 mm (1-3/4 inch) dia
7		407538A1		1	BUSHING
8		103-21281		2	RING, SNAP, 2.812", Int, #281
9		355529A1		1	GLAND
		250741A1		1	KIT, Incl. Ref 10 - 16
10		NSS		1	NOT SERVICED SEPARATELY, Kit, Seal; Order 250741A1
11		238-5235		1	O-RING, -235, 70 Duro, 3.109" ID x .139" Thk
12		D38858		1	GASKET
13		G102425		1	BUSHING, LARGE
14		D95143		1	SEAL
15		190332A1		1	SEAL
16		G100711		1	RING, WEAR, Wear
17		1986982C1		1	PISTON
18		86642312		1	SCREW, SELF TAP, Hex Hd, #8 x 3/8"
19		86982437		1	BOLT, SPECIAL
21		219-1		1	NIPPLE, LUBE, 1/8"-27 x .66 lg

MidWestTech | Case 750K Series 3 Crawler Dozer Parts Catalog | Publication 87364210NA Order the manual at mid-west-tech.com >

HOOD AND SIDE PANELS

REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTION
1		87446374		1	PLATE, COVER
2		87355874		1	DOOR ASSY., Right-Hand; Incl. Ref 4, 5; Replaces 87421310
3		87355875		1	DOOR ASSY., Left-Hand; Incl. Ref 4, 5; Replaces 87421307
4		R56221		1	LATCH, LOCK; Tri/Mark Vendor Part Number 12166-16; Used With 87421310, 87421307 Doors
4		87353954		1	LATCH, LOCK; Tri/Mark Vendor Part Number 18530; Heavy Duty; Used With 87355874, 87355875 Doors
5		151-567		4	RIVET, Pop, 1/5" x .625"
6		430363A2		2	PLATE, COVER, Incl. Ref 7
7		A161780		3	BUMPER
8		449674A1		4	SEAL
9		418479A2		4	PIN
10		832-10412		4	NUT, LOCK, M12 x 1.75, Cl 8
11		431707A3		1	HINGE, Left-Hand
12		431708A3		1	HINGE, Right-Hand
13		811-12040		4	BOLT, CARRIAGE, Short NK, M12 x 40, Cl8.8, Full Thd
14		896-11012		4	WASHER, M13.5 x 24.5 x 3, HT
15		832-10412		4	NUT, LOCK, M12 x 1.75, Cl 8
16		627-12030		4	BOLT, Hex, M12 x 30, 10.9
17		896-11012		4	WASHER, M13.5 x 24.5 x 3, HT
18		346104A1		2-4	MOUNTING PARTS, Bumper; 75.13 mm (3 in) Long; Upper and Lower; Some Models Use Two Upper and Two of 87330642 Lower
18		87330642		2	BUMPER, 59.8 mm (2-3/8 in) Long; Replaces Two 346104A1 75.13 mm (3 in) Long Lower Bumpers Used On Some Models
19		425-115		4	NUT, 5/16"-24, G5, 5/16
20		419392A2		2	PLATE, RETAINING
21		627-6020		4	BOLT, Hex, M6 x 20, 10.9
22		896-11006		AR	WASHER, M6 x 13 x 2, HT
23		R29799		2	SHOCK ABSORBER
24		R40262		2	WASHER

MidWestTech | Case 750K Series 3 Crawler Dozer Parts Catalog | Publication 87364210NA Order the manual at mid-west-tech.com >