380B Tractor

Parts Catalog

8-7440

CASE IH AGRICULTURE

MidWestTech | Case 380B Tractor Parts Catalog | Publication 8-7440

Order the manual at mid-west-tech.com >

ALPHABETICAL INDEX

A

Air cleaner 2-11
Coopers (With safety element) 2-13
Coopers (Without safety element) 2-11
Donaldson 2-15
Alternator 4-23
Alternator mounting 4-21
Alternator shield 4-21

B

Battery cables 4-15
Battery tray 4-15
Brake master cylinder 7-7
Brake pedals 7-3
Brake reservoir and pipes 7-5

C

Cable clips 4-25
Cable straps 4-25
Camshaft 2-33
Clutch controls 6-37
Clutch housing 6-7
Clutch housing top cover 6-9
Clutch:
Laycock 11 inch 6-3
Rockford 12 inch heavy duty 6-5
Connecting rods 2-37
Coolant manifold 2-7
Crankshaft and bearings 2-35
Cylinder block 2-31
Front cover 2-29
Side cover 2-31
Cylinder head 2-27

D

Decals 9-43,45,47
Differential 6-33
Differential brakes 7-9
Differential lock 6-51
Draft control 8-27
Cylinder and valve assembly 8-31
External levers and linkage 8-37
Hydraulic housing 8-29
Internal control linkage 8-35
Unloading and flow control valve 8-33

E

Engine service kits:
Crankcase gaskets 2-49
Cylinder head gaskets 2-47
Ether starting 2-17
Exhaust downswept 2-21
Exhaust vertical 2-19

F

Fan, engine cooling 2-5
Flasher unit 4-11
Flywheel 2-35
Flywheel housing 2-31
Foot accelerator 3-15
Forward and reverse control 6-49
Front axles:
Straight adjustable 5-19
Swept back cast 5-21
Front bolsters:
Cast 9-3
Fabricated 9-5
Front wheels 5-29
Fuel filter 3-5
Fuel filters and connections 3-3
Fuel injection nozzle 3-9
Fuel injection pump 3-11
Fuel injection tubes 3-7
Fuel lines 3-19
Fuel shut-off control 3-13
Fuel tank 3-19
Fuse box 4-11

G

Governor control 3-17

H

Harnesses:
Fenders 4-3
Main cable 4-3
Tail and stop light 4-5
Hood and side panels 9-9
Hydraulic power supply:
Multiple control valve 8-9
Multiple control valve and tubes 8-7

I

IPTO control 6-55
Independent power take off 6-53
Instrument housing 9-11
Instruments and switches 4-9
Intake manifold 2-17

L

Lights 4-5
Headlights 4-7
ROPS canopy 4-13

MidWestTech | Case 380B Tractor Parts Catalog | Publication 8-7440 Order the manual at mid-west-tech.com >

ALPHABETICAL INDEX

L

Lights-Cont.
Tail and stop 4-5

O

Oil cooler system 8-5
Oil filter hydraulic 8-3
Oil filter, engine 2-39
Oil pan, engine 2-43
Oil pump, engine 2-41
Oil pump, hydraulic 8-7
Operator platforms 9-13

P

Park brake hand lever 7-13
Park brake linkage 7-11
Pistons and sleeves 2-37
Power steering cylinder:
Adjustable front axles 5-15
Swept back cast front axle 5-17
Power steering cylinders and hoses 5-7
Adjustable front axle 5-7
Swept back cast front axle 5-7
Power steering tubes (Front) 5-5
Power steering tubes (Rear) 5-9
With forward and reverse 5-11
Power steering valve 5-13

R

Radiator and connections 2-3
Radiator grille 9-7
Range shift control 6-41
With forward and reverse 6-43
Range shift control (internal) 6-45
With forward and reverse attachment 6-47
Range transmission 6-31
Rear axle and carrier 6-35
Rear fenders 9-15
Rear frame 6-21
Oil level gauge 6-23
Top cover 6-27,29
Transfer oil pump 6-25
Rear wheels:
24 Inch 6-59
Integral disc type 6-57
Regulator valve assembly:
Forward and reverse 8-13
Regulator valve mounting plate:
Forward and reverse 8-11
Remote auxiliary valve assembly:

R

Remote auxiliary valve assembly:-Cont.
With one check valve 8-23
Without check valve 8-21
Remote auxiliary valve control:
1st, 2nd and 3rd bank 8-25
Remote auxiliary valves:
1st and 2nd bank tubes 8-17
1st and 2nd bank couplings 8-17
1st, 2nd and 3rd bank 8-15
3rd bank tubes and couplings 8-19
Roll over protection frame:
2 post canopy headliner 9-31
2 post ROPS 9-27
2 post ROPS canopy 9-29

S

Seat belts 9-25
Seat deck 9-17
Seats:
Static seat 9-23
Suspension seat 19,21
Service engines 2-45
Slow moving vehicle emblem 9-33
Speed shift control 6-39
Speed transmission 6-11,13
With forward and reverse 6-15,17,19
Starter motors:
Bosch 4-17
Lucas 4-19
Steering support 5-3
Steering wheel 5-3
Swinging drawbar 9-41

T

Thermostat 2-7
Three point hitch 9-35
Fixed lower links 9-39
Upper links 9-37
Tie rods:
Adjustable straight front axle 5-27
Swept back cast front axle 5-21

V

Valve housing cover 2-23
Valve mechanism 2-25

W

Water pump 2-5
Water pump carrier 2-7
Wheel hubs:
Adjustable straight front axle 5-23
Swept back cast front axle 5-25

MidWestTech | Case 380B Tractor Parts Catalog | Publication 8-7440 Order the manual at mid-west-tech.com >