CASE

PROFESSIONAL PARTNER

OPERATOR'S MANUAL

WHEEL LOADER

721E
821E
TIER 3

87479861 NA
Replaces 87364251 NA

Issued 03-2008

MidWestTech | Case 721E, 821E Tier 3 Wheel Loader Operator's Manual | Publication 874... Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

CHAPTER 1
GENERAL INFORMATION
To the Owner 1-1
Machine Components 1-5

CHAPTER 2
SAFETY, AND DECALS
Table of Contents 2-1
Safety Rules 2-3
Personal Safety 2-3
Utility Safety 2-4
Decals 2-11

CHAPTER 3
INSTRUMENTS AND CONTROLS
Table of Contents 3-1
Access Doors and Covers 3-3
Cab 3-5
Front Console 3-14
Instrument Panel Indicators 3-15
Control Levers 3-32
Side Console 3-37
Climate Control 3-38

CHAPTER 4
OPERATING INSTRUCTIONS
Table of Contents 4-1
Control Levers 4-13

CHAPTER 5
LUBRICATION, FILTERS, AND FLUIDS
Table of Contents 5-1
Servicing Instructions 5-3
Support Strut for Loader Lift Arms 5-4
Releasing Pressure in the Hydraulic System 5-5
Fluids and Lubricants 5-6
Engine Oil Viscosity / Temperature Ranges 5-7
Daily Inspections 5-10
Lubrication and Maintenance Quick Reference Chart 5-11
Access Doors and Fill Locations 5-12
Scheduled Maintenance 5-14

CHAPTER 6
MAINTENANCE AND ADJUSTMENTS
Table of Contents 6-1
Cab Service 6-20

CHAPTER 7
ELECTRICAL
Table of Contents 7-1
Electrical System 7-3
Batteries 7-5
Fuses and Relays 7-7
Machine Lights 7-10

MidWestTech | Case 721E, 821E Tier 3 Wheel Loader Operator's Manual | Publication 874... Order the manual at mid-west-tech.com >

521E
621E
721E
821E
921E
Wheel Loader
Joystick Steering System

Operator's Manual

Supplement to Operator's Manuals
87479803, 87583968, 87479861, 87480042

Print No. 84227623
English 04/10
Replaces 84186924, 84186927, 84186930

CASE CONSTRUCTION

MidWestTech | Case 721E, 821E Tier 3 Wheel Loader Operator's Manual | Publication 874... Order the manual at mid-west-tech.com >