CASE

PROFESSIONAL PARTNER

PARTS CATALOG
VIBRATORY ROLLER

DV210
TIER III

87481031

Issued June 09

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

00.000.01		DV210 PICTORIAL INDEX
00.001.01		QUICK REFERENCE - FILTERS / BELT 545 (ND142652)
00.002.01		QUICK REFERENCE - FUSES / BULBS 540 (ND142658)
10.000.01		ENGINE - SECTION PICTORIAL 1/1
10.012.01		MOUNTING, ENGINE 105 (ND142591)
10.102.13		DRAIN, ENGINE OIL 108 (ND142618)
10.202.02		AIR CLEANER, ENGINE 135 (ND142602)
10.202.04		COVER, AIR INLET 192 (ND142637)
10.206.01		FILTERS, ENGINE 105 (ND142591)
10.216.07		CAP/ PARTS, FUEL TANK 80 (ND142601)
10.254.10		MUFFLER, ENGINE EXHAUST 135 (ND142602)
10.406.03		DRAIN, RADIATOR 130 (ND142619)
10.406.17		RADIATOR, ENGINE COOLING 125 (ND142613)
10.414.22		GUARD, FAN 591 (ND142649)
35.000.01		HYDRAULIC SYSTEMS - SECTION PICTORIAL 1/1
35.310.04		TILT HYDRAULICS, HOOD AND PLATFORM 385 (ND142628)
35.310.05		PUMP, HYDRAULIC HAND - PLATFORM TILTING 382-17 382-17-1 382-17-2 (ND067870)
35.353.01	01	HYDRAULIC SYSTEM OF TRAVEL - FILTER / VALVE 350 (ND142625) 1/4
35.353.01	02	HYDRAULIC SYSTEM OF TRAVEL - LINES 350 (ND142625) 2/4
35.353.01	03	HYDRAULIC SYSTEM OF TRAVEL - VALVE 350 (ND142625) 3/4
35.353.01	04	VALVE, CONTROL 350-1 (ND135224) 4/4
35.353.12		LINES, FRONT DRUM DRIVE 300 (ND142623)
35.353.17		LINES, REAR DRUM DRIVE 310 (ND142624)
35.565.03		EDGE CUTTER HYDRAULICS 550-1 (ND132351)
35.700.06		PUMP, MAIN HYDRAULIC MACHINE 105 (ND142591)
35.750.05		TANK PARTS, HYDRAULIC 80 (ND142601)
35.752.02		LINES, HYDRAULIC FAN DRIVE 370 (ND142627)
35.752.04		PUMP, HYDRAULIC FAN DRIVE 105 (ND142591)
35.910.40		LINES, FRONT VIBRATORY DRUM 300 (ND142623)
35.910.45		LINES, REAR VIBRATORY DRUM 310 (ND142624)
39.000.01		FRAME COMPONENTS - SECTION PICTORIAL 1/1
39.100.01	01	FRAME, FRONT 50 (ND138811)
39.100.01	02	MIRROR INSTALL, FRONT FRAME 156 (ND138073)
39.100.02	01	FRAME, REAR 60 (ND142590)
39.100.02	02	COMPONENTS, REAR FRAME 80 (ND142601)
39.100.72		NOISE REDUCTION 207 (ND142646)
39.100.73	01	ARTICULATION JOINT 65 (ND135248)
39.100.73	02	BRACKET, ARTICULATION JOINT 65-1 (ND125961)
39.100.79		SCRAPER, SMOOTH DRUM 55 (ND125942)
39.100.84		SCRAPER, SMOOTH DRUM TILTABLE 56 (ND129684)
41.000.01		STEERING SYSTEMS - SECTION PICTORIAL 1/1
41.101.01	01	CONTROLS, STEERING / TRAVEL / SEAT 185 (ND126037)
41.101.01	02	CONTROL, STEERING / TRAVEL 185-1 (ND126019)
41.200.33		LINES, HYDRAULIC STEERING 364 (ND142626)
41.216.18		CYLINDERS, STEERING 70 (ND124634)
50.000.01		CAB CLIMATE CONTROL - SECTION PICTORIAL 1/1
50.100.01		HEATER INSTALL 600 (ND142642)
55.000.01		ELECTRICAL SYSTEMS - SECTION PICTORIAL 1/1
55.100.14		ELECTRICAL INSTALL 408 (ND142661)
55.404.57		HEADLAMPS, CAB 416 (ND131528)

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

55.408.03		HORN, BACK UP ALARM 415 (ND131539)
55.410.08		HARNESS, CAB UPPER INTERIOR 410 (ND131527)
55.418.32		DASH BOARD 408-1 (ND143127)
55.514.17		BEACON, ROTATING / FLASHING 413 (ND131540)
55.640.07		ELECTRICAL DISTRIBUTION 408-2 (ND142668)
55.640.10		THERMOMETER, INFRARED 555 (ND142645)
75.000.01		SOIL PREPARATION - SECTION PICTORIAL 1/1
75.120.01		PIPE, WATER SPRINKLING 94-1 (ND125947)
75.120.02		WATER SPRINKLING SYSTEM / PUMP 94 (ND125968)
75.120.03		WATER TANK 93 (ND126012)
75.200.10		DRUM, SMOOTH VIBRATORY 1 (ND125932)
75.200.40		VIBRATOR, DRUM 1-20 (ND125932)
75.200.50	01	CUTTER, EDGE 550 (ND132269)
75.200.50	02	ROLLER ASSY, EDGE CUTTER 550-9 (ND098294)
90.000.01		PLATFORM, CAB, BODYWORK AND DECALS - SECTION PICTORIAL 1/1
90.100.35		HOOD INSTAL, ENGINE 200 (ND142604)
90.108.05		DECALS, NA MODEL
90.108.06		DECALS, NA WARNING
90.108.07		DECALS, NA ISO
90.110.17		PLATFORM 155 (ND125990)
90.110.18		CAB / PLATFORM MOUNTING 170 (ND125963)
90.110.19		COLUMN, PLATFORM 187 (ND142632)
90.120.20		CAB COMPONENTS 165C (ND129431)
90.154.22	01	DOORS, CAB 165A (ND129431)
90.154.22	02	GLASS, CAB 165B (ND129431)

Order the manual at mid-west-tech.com >

DV210 PICTORIAL INDEX

REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTION
		REF			INSTRUCTION, DV210 Pictorial Index
10		REF			INSTRUCTION, Engine Section - See Figure 10.000.01
35		REF			INSTRUCTION, Hydraulic Systems Section - See Figure 35.000.01
39		REF			INSTRUCTION, Frame Components - See Figure 39.000.01
41		REF			INSTRUCTION, Steering Section - See Figure 41.000.01
50		REF			INSTRUCTION, Cab Climate Control Section - See Figure 50.000.01
55		REF			INSTRUCTION, Electrical Systems Section - See Figure 55.000.01
75		REF			INSTRUCTION, Soil Preparation Section - See Figure 75.000.01
90		REF			INSTRUCTION, Platform, Cab, Bodywork And Decals Section - See Figure 90.000.01

MidWestTech | Case DV210 Tier III Vibratory Roller Parts Catalog | Publication 87481031 Order the manual at mid-west-tech.com >

FRAME COMPONENTS - SECTION PICTORIAL 1/1

REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTION
		REF			INSTRUCTION, Frame Components - Section Pictorial
1		REF			INSTRUCTION, Frame, Front - For Service Breakdown See Figure 39.100.01 (01)
2		REF			INSTRUCTION, Mirror Instal, Front Frame - For Service Breakdown See Figure 39.100.01 (02)
3		REF			INSTRUCTION, Frame, Rear - For Service Breakdown See Figure 39.100.02 (01)
4		REF			INSTRUCTION, Components, Rear Frame - For Service Breakdown See Figure 39.100.02 (02)
5		REF			INSTRUCTION, Noise Reduction - For Service Breakdown See Figure 39.100.72
6		REF			INSTRUCTION, Articulation Joint - For Service Breakdown See Figure 39.100.73 (01)
7		REF			INSTRUCTION, Bracket, Articulation Joint - For Service Breakdown See Figure 39.100.73 (02)
8		REF			INSTRUCTION, Scraper, Smooth Drum - For Service Breakdown See Figure 39.100.79
9		REF			INSTRUCTION, Scraper, Smooth Drum Tiltable - For Service Breakdown See Figure 39.100.84

MidWestTech | Case DV210 Tier III Vibratory Roller Parts Catalog | Publication 87481031 Order the manual at mid-west-tech.com >

PLATFORM, CAB, BODYWORK AND DECALS - SECTION PICTORIAL 1/1

REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTION
		REF			INSTRUCTION, Platform, Cab, Bodywork And DecalS - Section Pictorial
1		REF			INSTRUCTION, Hood Instal, Engine - For Service Breakdown See Figure 90.100.35
2		REF			INSTRUCTION, NA Model Decals - For Service Breakdown See Figure 90.108.05
3		REF			INSTRUCTION, NA Warning Decals - For Service Breakdown See Figure 90.108.06
4		REF			INSTRUCTION, NA ISO Decals - For Service Breakdown See Figure 90.108.07
5		REF			INSTRUCTION, Platform - For Service Breakdown See Figure 90.110.17
6		REF			INSTRUCTION, Platform Mounting - For Service Breakdown See Figure 90.110.18
7		REF			INSTRUCTION, Column, Platform - For Service Breakdown See Figure 90.110.19
8		REF			INSTRUCTION, Cab Components - For Service Breakdown See Figure 90.120.20
9		REF			INSTRUCTION, Doors, Cab - For Service Breakdown See Figure 90.154.22 (01)
10		REF			INSTRUCTION, Glass, Cab - For Service Breakdown See Figure 90.154.22 (02)

MidWestTech | Case DV210 Tier III Vibratory Roller Parts Catalog | Publication 87481031 Order the manual at mid-west-tech.com >